



# INSTALLATION AND MAINTENANCE MANUAL

## for

# SERIES ST700 TURBINE-POWERED STARTERS



### ▲ WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.  
READ THIS MANUAL BEFORE OPERATING TOOL.**

**FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.**

- For safety, top performance, and maximum durability of parts, do not operate Series ST700 Starters at air pressures over the pressure rating stamped on the nameplate. Use supply lines of adequate size as directed in the installation instructions in this manual.
- Always turn off the air or gas supply and disconnect the air or gas supply hose before installing, removing or adjusting any accessory on this starter, or before performing any maintenance on this starter.
- Series ST700 Starters are designed for gas operation. They are not totally sealed in dynamic operation since the exhaust must be vented or piped away and there is a possibility of leakage around the output shaft when rotating.
- Caution should be taken when operating these starters on gas because of the danger of fire, explosion, or inhalation. After assembling a starter, always test it in accordance with the procedures outlined in this manual. Never install a reassembled starter that has not been tested in accordance with the procedures in this manual.
- Operate this starter only when properly installed on the engine.
- Do not lubricate starters with flammable or volatile liquids such as kerosene or jet fuel.
- For personal protection, do not remove any labels. Replace any damaged label.
- Use only recommended Ingersoll-Rand accessories.

### NOTICE

The use of other than genuine Ingersoll-Rand replacement parts may result in safety hazards, decreased starter performance, and increased maintenance, and may invalidate all warranties.

Ingersoll-Rand is not responsible for customer modification of starters for applications on which Ingersoll-Rand was not consulted.

Repairs should be made only by authorized trained personnel. Consult your nearest Ingersoll-Rand Authorized Servicer.

Specific test data, when applicable, can be found in the Special Instructions Section of this manual.

It is the responsibility of the employer to place the information in this manual into the hands of the operator.

Refer All Communications to the Nearest  
Ingersoll-Rand Office or Distributor.

© Ingersoll-Rand Company 1998


Printed in U.S.A.


**INGERSOLL-RAND®**  
**ENGINE STARTING SYSTEMS**


## WARNING LABEL IDENTIFICATION


### ▲ WARNING

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

	<b>▲ WARNING</b>
	Always wear eye protection when operating or performing maintenance on this starter.

	<b>▲ WARNING</b>
	Always wear hearing protection when operating this starter.

	<b>▲ WARNING</b>
	Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this starter, or before performing any maintenance on this starter.

	<b>▲ WARNING</b>
	Do not use damaged, frayed or deteriorated air hoses and fittings.

### NOTICE

For natural gas operation, starter main exhaust must be piped away.

To pipe the Drive Housing vent, remove the Drive Housing Plug and replace it with a suitable tubing line. The tubing must vent at a safe location and must not be interconnected with any other exhaust lines which might introduce a back pressure on the Drive Housing Vent.

### NOTICE

ST900-267 Strainer or equivalent is required for all starters used in GAS applications.

# CONTENTS

	<b>Page</b>
Installation .....	4-6
Mounting Dimensions .....	7-9
Piping Diagrams .....	10-13
How to Order .....	14
Detailed Illustrations .....	15, 16, 19
Parts Listing .....	17-18, 20-23
Exhaust Kit .....	24
Disassembly .....	25-29
Assembly .....	29-35
Testing the Starter .....	35
Troubleshooting .....	36, 37
Index .....	38

# PLACING THE STARTER IN SERVICE

## INSTALLATION

For maximum performance, read this manual prior to the installation or operation of Series ST700 Turbine-Powered Starters.

### General Information

1. It is strongly recommended that on all vehicular installations and on stationary engines subject to vibration, that hoses of the specified diameter be used instead of rigid pipe connections to the starter. Vehicle and engine vibration will soon loosen rigid pipe connections, whereas hoses will absorb the vibration, and connections will remain tight
2. This starter is designed for flange mounting at the inlet. The furnished Flange Mounting Kit is required for installation. All piping, hoses and valving must be clean prior to installation. Make sure that the starter inlet remains free of dirt and foreign material during installation.
3. In the actual mounting of a starter, it may be best to have the hose connections already made at the receiver and to have the starter end of the hose handy for attaching to the starter.
4. Engine design often demands that the starter be mounted underneath in extremely close quarters, and even though two of the mounting bolt holes are easy to reach, the third one is often less accessible. To install a starter, the following tools are required: regular ratchet wrench, sockets, universal joint, socket extension and a single or double-end box wrench.
5. The efficiency of an Air Starter can be greatly impaired by an improper hook-up. Hoses smaller than those recommended will reduce the volume of air to the motor and the use of reducers for piped-away applications in the exhaust port will restrict the exhaust causing back pressure to the motor resulting in reduced performance. The number of tees and elbows, and the length of the supply line should be kept to a minimum. Use 1-1/2" hose or pipe for supply lines up to 15 feet long; use 2" hose or pipe if the supply line is over 15 feet long.
6. A leak in any of the connections in live air lines means that the system will drain overnight and will have to be re-pressurized the next morning by use of another vehicle or compressor. **Make your connections bubble tight to avoid unnecessary costs and delays.** On all threaded connections throughout the system, use Ingersoll-Rand No. SMB-441 Sealant, non-hardening No. 2 Permatex or Loctite® Pipe Sealant. After all connections have been made, check each joint with a soap bubble test. There must be no leaks in live air lines. The slightest leak will cause the system to lose pressure overnight.

Always run the air supply line from the side or top of the receiver, never at or near the bottom. Moisture in the air collects at the bottom of the receiver resulting in damage which could cause the valves to become inoperative. Periodically open the petcock at the bottom of the tank to drain the water.

7. Whenever a hazardous gas is being used to operate the starter, **there must be no leaks in inlet or exhaust piping or from any other starter joints. All discharges should be piped away to a safe area.**
8. We recommend installation of a "glad hand" for emergency re-pressurizing of the system. To keep the "glad hand" clean and free of dirt, and to protect it from damage, a second "glad hand" closed by a pipe plug can be mated to it, or a "glad hand" protector bracket can be used.
9. It is **required** that a strainer be installed in the inlet line for each starter. Ingersoll-Rand offers 5 strainers: ST900-267-24 for 1 1/2 inch lines, ST900-267-32 and ST900-267-32F for 2 inch lines, ST900-267-48 for 3 inch lines and ST900-267-64 for 4 inch lines. These 300 mesh strainers provide 50 micron filtration and offer significant protection against supply line contaminants which could damage the turbine components. Replacement elements are ST900-266-24 for 1 1/2 inch, ST900-266-32 for 2 inch pipe thread, ST900-266-32F for 2 inch flange, ST900-266-48 for 3 inch flange and ST900-266-64 for 4 inch lines.

### Orientation of the Starter

It is recommended that starters be ordered to proper orientation for your specific mounting to the required engine or for your specific installation. However, if the starter must be reoriented for installation, proceed as follows:

1. Refer to the dimension illustration on pages 7, 8 and 9 and note that the Drive Housing can be located in any one of sixteen radial positions relative to the Gear Case and the air inlet can be located in any one of four radial positions relative to the Drive Housing.
2. Study the engine mounting requirements, and determine the required orientation of the Drive Housing relative to the Gear Case. If the Drive Housing has to be reoriented, remove the eight Drive Housing Cap Screws and rotate the Drive Housing to its required position. Separation of the Drive Housing from the Gear Case is not required. Reinstall the Drive Housing Cap Screws and tighten to 28 ft-lb (38 Nm) torque.
3. After the Drive Housing is properly oriented relative to the Gear Case, determine if the inlet port will be favorably located for hose installation. If either or both of these members must be reoriented, use an 8 mm hex-head wrench to remove the four motor housing cover cap screws, and rotate the motor housing and/or motor housing cover to its desired position.

## PLACING THE STARTER IN SERVICE

### NOTICE

**Do not separate the Motor Housing from the Intermediate Gear case as gear lubrication oil will be lost.**

Reinstall the motor housing cover cap screws and alternately tighten them to 60 ft-lb (81.4 Nm) torque in 20 ft-lb (27 Nm) increments.

### Mounting the Starter

1. Study the appropriate piping diagrams on pages 10, 11, 12 and 13 and install as indicated.
2. The air receiver tank for a starter installation must have a working pressure rating equal to or greater than the maximum pressure at which the starter will be operated.
3. When connecting the starter to a receiver tank that is already in service, bleed off the air pressure in the tank prior to installing the starter.

### ▲ WARNING

**Bleed off the air pressure through a valve or petcock. Do not remove a plug from the tank while the tank is still pressurized.**

Drain off any water that may have accumulated in the bottom of the tank.

4. Using a 1-1/2" short nipple, install the SRV150 Starter Relay Valve on the end of the receiver tank as shown in the piping diagram.

### NOTICE

**Make certain the connection is made to the inlet side of the Relay Valve indicated by the word "IN", cast on the valve body.**

5. For air installations, install the Starter Control Valve (SMB-618) on the dash panel (for vehicular installations) or some other appropriate panel (for stationary installations). An optional control circuit utilizing an electric solenoid control valve and a panel mounted switch are available. Mount the 12V Solenoid Valve (150BMP-1051B) securely and preferably in a vertical position away from any concentration of heat, vibration or contamination. Connect the leads to the operator's starting switch which should be located on the dashboard or control panel.
6. Attach Starter Instruction Label (TA-STR-100) to the control panel adjacent to the Starter Control Valve.
7. Mount the Air Pressure Gauge (150BMP-1064) on or adjacent to the control panel. It should be located where it is readily visible to the operator.
8. Connect the Starter Control Valve to the Relay Valve with 1/4" hose. Install a tee in this line with a short feeder hose to the Pressure Gauge.

### NOTICE

**Make certain the hose is connected to the supply side (marked "SUP") of the Starter Control Valve.**

9. To determine the exact length of 1-1/2" air hose required, run a piece of heavy duty hose or some other flexible tubing of the same diameter from the Relay Valve on the receiver to the starter location on the engine.
10. Attach the 1-1/2" air hose to the outlet side of the Relay Valve, and run the hose through the frame, etc. to its final position at the starter location.
11. At this point, determine whether or not it is feasible or practical to attach the hose to the starter before or after the starter is actually mounted. In many cases it may be necessary to attach the hose to the starter before mounting.
12. If possible, liberally grease the teeth on the ring gear with a good quality sticky gear grease. This will help promote the life of the ring gear and the starter Pinion.
13. Move the starter into position, and mount it on the flywheel housing. Tighten the mounting bolts to 100 ft-lb (136 Nm) torque.
14. **For Pre-Engaged Models**, install a 1/4" hose line from the delivery side (marked "DEL") of the starter Control Valve or Solenoid Valve to the "IN" port on the Starter Drive Housing.

### NOTICE

**Inadvertent application of air pressure to the "OUT" port will result in Drive malfunction (Pinion will fail to retract). If this condition occurs, loosen Drive Housing Cap Screws (38) to vent Gear Case (28). Also, loosen Housing Plugs (10) and (11) to vent Motor.**

15. Install a 1/4" hose line from the "OUT" port on the Starter Drive Housing to the small pipe tapped portion top of the Starter Relay Valve or Solenoid Valve.
16. If the exhaust is to be piped away, remove the standard Splash Deflector which is located at the rear of the Housing Exhaust Cover and replace the Assembly with the 1/4" N.P.T. pipe plug supplied with the starter.
17. Pressurize the complete starting system and check every connection with a soap bubble test. **There must be no leaks in live air lines or other connections.**

## **PLACING THE STARTER IN SERVICE**

### **Barring Over the Engine**

Occasionally, for setting injectors and/or for timing purposes, it may be desirable to bar over the engine in such a manner that any given piston can be stopped at any given location. This is very easily done with a Series ST700 Turbine Starter.

Remove the Deflector Retaining Screw (5), the Deflector Return Spring (4) and the Splash Deflector (3). If piped-away exhaust is being used, remove piping so that you can gain access to the hole at the center of the Housing Exhaust Cover. Remove the 1/4" pipe plug.

### **For Models with Inertia Drive:**

1. Manually engage pinion and insert a 1/4" hex wrench through the hole in the Housing Cover to engage the hex drive recess at the rear of the Motor Assembly.
2. Manually rotate the Motor Assembly until the engine is cranked to the desired position.

### **For Models with Pre-Engaged Drive:**


1. Disconnect the 1/4" hose at the "OUT" port on the Drive Housing, and plug the hole in the Drive Housing with a 1/4" pipe plug.
2. Engage the Drive Pinion with the flywheel by applying a minimum of 70 psig (4.8 bar/483 kPa) to the "IN" port on the Drive Housing.
3. Insert a 1/4" hex wrench through the hole in the Housing Exhaust Cover to engage the hex drive recess in the rear of the Motor Assembly.
4. Manually rotate the Motor Assembly until the engine is cranked to the desired position.








# ST700 PRE-ENGAGED MOUNTING DIMENSIONS



1. THE SPLASH DEFLECTOR ASSEMBLY MUST BE REMOVED FOR ACCESSING THE 1/4" HOLE DRIVE BARRING HOLE OR WHEN INSTALLING A PIPED AWAY EXHAUST.
2. BEFORE REMOVING THE HEX. PLUG THE STARTER MUST BE REASONABLY LEVEL TO PREVENT DRAINING THE OIL FROM THE GEAR CASE.
3. WHEN THE HEX PLUG IS REMOVED A SLIGHT AMOUNT OF OIL MAY LEAK FROM THE HOLE. (THIS IS NORMAL.)
4. BEFORE REASSEMBLY CLEAN ALL OIL FROM THE THREADS AND APPLY PIPE THREAD SEALANT (I-R NO. SMB-441 OR EQUIVALENT) TO PREVENT OIL LEAKAGE.

ORIENTATION OPTIONS	
INLET	DRIVE HOUSING
4 @ 90°	18 @ 22° 172°



- NOTES:
1. STARTERS SHOULD BE INSTALLED ON THE ENGINE WITH THE EXHAUST POINTED DOWN.
  2. THESE MODELS ARE NOT APPROVED FOR APPLICATIONS WHERE THE STARTER IS EXPOSED TO THE TRANSMISSION FLUID.
  3. DRIVE HOUSING ORIENTATION CODE IS BASED ON POSITION OF MOUNTING HOLE OPPOSITE THE PINION OPENING.
  4. STANDARD ORIENTATION SHOWN (OE) WILL BE SHIPPED UNLESS OTHERWISE SPECIFIED.
  5. PLEASE READ THE INSTRUCTIONS BEFORE ATTEMPTING TO REORIENT.
  6. STARTER WEIGHT = 88 LBS (44.5 Kg)

DUAL DIMENSIONS MM (INCH)

PLACING THE STARTER IN SERVICE


(Dwg. TPA1278-4)

# PLACING THE STARTER IN SERVICE


## PIPING DIAGRAMS

### PRE-ENGAGED SYSTEM (SERIES ST700 SHOWN)

#### Typical Vehicular Installation



#### Typical Stationary Installation



★ INGERSOLL-RAND PART NUMBER


TO PIPE THE DRIVE HOUSING VENT, REMOVE THE DRIVE HOUSING PLUG AND REPLACE IT WITH A SUITABLE TUBING LINE. THE TUBING MUST VENT AT A SAFE LOCATION AND MUST NOT BE INTERCONNECTED WITH ANY OTHER EXHAUST LINES WHICH MIGHT INTRODUCE A BACK PRESSURE ON THE DRIVE HOUSING VENT.

(Dwg. TPA1282-3)


# PLACING THE STARTER IN SERVICE

## PIPING DIAGRAMS INERTIA TYPE SYSTEM (SERIES ST700 SHOWN)

### Typical Vehicular Installation



### Typical Stationary Installation




\*\* FOR NATURAL GAS OPERATION, STARTER MAIN EXHAUST MUST BE PIPED AWAY.

TO PIPE THE DRIVE HOUSING VENT, REMOVE THE DRIVE HOUSING PLUG AND REPLACE IT WITH A SUITABLE TUBING LINE. THE TUBING MUST VENT AT A SAFE LOCATION AND MUST NOT BE INTERCONNECTED WITH ANY OTHER EXHAUST LINES WHICH MIGHT INTRODUCE A BACK PRESSURE ON THE DRIVE HOUSING VENT.


(Dwg. TPA1283-3)

# PLACING THE STARTER IN SERVICE

## PIPING DIAGRAMS PRE-ENGAGED SYSTEM (SERIES ST700 SHOWN) Typical Installation with Engine Pre-lube System when Supply Pressure is over Rated Starter Pressure




## Typical Installation with Engine Pre-lube System



(Dwg. TPA1281-3)

### Typical Multiple Starter Installation



\*\* FOR NATURAL GAS OPERATION, STARTER MAIN EXHAUST MUST BE PIPED AWAY.

TO PIPE THE DRIVE HOUSING VENT, REMOVE THE DRIVE HOUSING PLUG AND REPLACE IT WITH A SUITABLE TUBING LINE. THE TUBING MUST VENT AT A SAFE LOCATION AND MUST NOT BE INTERCONNECTED WITH ANY OTHER EXHAUST LINES WHICH MIGHT INTRODUCE A BACK PRESSURE ON THE DRIVE HOUSING VENT.


(Dwg. TPA1284-4)

PLACING THE STARTER IN SERVICE

# PLACING THE STARTER IN SERVICE

Series ST700 Turbine-Powered Starters are designed for air or gas operation in off-highway, marine and stationary applications.


## HOW TO ORDER A STARTER



MODEL	SUPPLY PRESSURE PSIG/KPa MAX. *	DRIVE	PINION DATA			
		I-R NO.	NO. OF TEETH	D.P.	P.D.	PA
ST750GBDI03R31	150/1034	20BM-299-1	12/12	6/8	2.00"	20°
ST750GBDI03L32	150/1034	20BM-299-3	12/12	6/8	2.00"	20°
ST799GBDI03R31	90/621	20BM-299-1	12/12	6/8	2.00"	20°
ST799GBDI03L32	90/621	20BM-299-3	12/12	6/8	2.00"	20°

↑ MUST BE SPECIFIED WHEN ORDERING


(Dwg. TPD1176)



MODEL	SUPPLY PRESSURE PSIG/KPa MAX. *	PINION DATA			
		NO. OF TEETH	D.P.	P.D.	PA
ST750GBDP03R31	150/1034	12/12	6/8	2.00"	20°
ST750GBDP03L32	150/1034	12/12	6/8	2.00"	20°
ST750GCDP03R25	150/1034	11/12	6/8	2.00"	20°
ST750GBDP03L26	150/1034	12/12	6/8	2.00"	20°
ST799GBDP03R31	90/621	12/12	6/8	2.00"	20°
ST799GBDP03L32	90/621	12/12	6/8	2.00"	20°
ST799GCDP03R25	90/621	11/12	6/8	2.00"	20°
ST799GBDP03L26	90/621	12/12	6/8	2.00"	20°

↑ MUST BE SPECIFIED WHEN ORDERING

(Dwg. TPD1177)




MODEL	SUPPLY PRESSURE PSIG/KPa MAX. *	PINION DATA			
		NO. OF TEETH	D.P.	P.D.	PA
ST750GDDP09R51	150/1034	15	6/8	2.50"	20°
ST750GDDP09L52	150/1034	15	6/8	2.50"	20°
ST799GDDP09R51	90/621	15	6/8	2.50"	20°

↑ MUST BE SPECIFIED WHEN ORDERING


(Dwg. TPD1178)

**For different models or special applications, contact you nearest Ingersoll-Rand Distributor or SALES HEADQUARTERS, Engine Starting Systems, P.O. Box 1776, Liberty Corner, NJ 07938 (908) 647-6000**


# SERIES ST700 TURBINE-POWERED STARTERS



- ST750GDDP03R31
- ST750GDDP03L32
- ST750GCDP03R25
- ST750GCDP03L26
- ST799GDDP03R31
- ST799GDDP03L32
- ST799GCDP03R25
- ST799GCDP03L26




- ST750GBD103R31
- ST750GBD103L32
- ST799GBD103R31
- ST799GBD103L32



- ST750GDDP09R51
- ST750GDDP09L52
- ST799GDDP09R51
- ST799GDDP09L52

MAINTENANCE SECTION

# ST750 TURBINE STARTER (INERTIA)





## INERTIA DRIVE

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

	Housing Exhaust Cover Assembly .....	ST700-A562		Planet Gear Frame Assembly .....	ST700-A108
1	Housing Exhaust Cover .....	ST700-562	18	Planet Gear Frame .....	ST700-108
2	Exhaust Cover Seal .....	SS800-67	◆ 19	Planet Gear (3) .....	ST700-10
*	Exhaust Cover Plug .....	ST700-K37	◆ 20	Planet Gear Needle Roller Bearing (3) .....	ST700-363
3	Splash Deflector .....	ST700-735	*	Planet Gear Needle (18) .....	ST700-363-R
4	Deflector Return Spring .....	D10-275	◆ 21	Bearing Spacer (6) .....	ST700-364
5	Deflector Retaining Screw .....	ST700-737	◆ 22	Planet Gear Shaft (3) .....	ST700-191
6	Starter Assembly Cap Screw (4) .....	ST900-2574	23	Gear Shaft Retaining Washer (2) .....	ST700-100
7	Cap Screw Washer (4) .....	SS800-26	◆ 24	Rear Gear Frame Bearing .....	TA-22
	Motor Housing Assembly .....	ST700-A40	25	Front Bearing Spacer .....	ST700-90
8	Motor Housing .....	ST700-40	26	Intermediate Pinion .....	SS800B-17
10	Housing Plug (2) .....	CE110-29	27	Intermediate Retaining Screw .....	SS800-732
11	Housing Plug Inlet Boss .....	R0H-377	28	Gear Case .....	SS800-37
*	Nameplate .....	ST700-301	29	Drive Gear .....	SS810-9
*	Nameplate Screw (4) .....	R4K-302	◆ 30	Front Drive Gear Bearing .....	BU-359
◆ 12	Motor Assembly		◆ 31	Rear Drive Gear Bearing .....	SS800-359
	for Model ST750GBDI03R31 .....	ST750R-A53	32	Gear Case Cover .....	SS810-678
	for Model ST750GBDI03L32 .....	ST750L-A53	◆ 33	Gear Case Cover O-ring .....	SS800-244
	for Model ST799GBDI03R31 .....	ST799R-A53	◆ 34	Drive Gear Shaft Seal .....	SS810-272
	for Model ST799GBDI03L32 .....	ST799L-A53	◆ 35	Drive Housing O-ring .....	SS800-152
12A	Cylinder O-ring Seal (2) .....	ST700-67	36	Starter Drive	
12B	Housing O-ring Seal (2) .....	Y327-032		for Models ST750GBDI03R31	
	Intermediate Gear Case Assembly .....	ST700-A37		and ST799GBDI03R31 .....	20BM-299-1
13	Intermediate Gear Case .....	ST700-37		for Models ST750GBDI03L32	
◆ 14	Rear Gear Case O-ring .....	Y327-163		and ST799GBDI03L32 .....	20BM-299-3
◆ 15	Front Gear Case O-ring .....	Y327-162	37	Drive Gear Key (2) .....	20BM-610
◆ 16	Planet Gear Frame Shaft Seal .....	ST700-272	38	Drive Housing .....	SS810-300
◆ 16A	Spacer Ring .....	ST700-323	◆ 39	Drive Housing Bearing .....	SS660-363-13
◆ 17	Front Gear Frame Bearing .....	SS800-22	40	Drive Housing Cap Screw (8) .....	SS810-744

\* Not illustrated.

◆ Indicates Tune-up Kit part.

MAINTENANCE SECTION


**INERTIA DRIVE (Continued)**

**PART NUMBER FOR ORDERING** 

**PART NUMBER FOR ORDERING** 

41	Drive Housing Cap Screw Lock Washer (8) . . . . .	TE223A-415	*	Tune-up Kit (for ST750 models with left hand rotation) includes illustrated parts 12, 14, 16, 16A, 17, 19, 20, 21, 22, 24 and 42A . . . . .	ST750L-TK3
42	Inlet Flange Kit (includes Inlet Flange, Flange Mounting Bolts and Lock Washers) . . . . .	ST700-K166	*	Tune-up Kit (for ST799 models with left hand rotation) includes 12, 14, 16, 16A, 17, 19, 20, 21, 22, 24 and 42A . . . . .	ST799R-TK4
43	Flange Mounting Hardware Kit (includes Flange Mounting Bolts and Lock Washers) . . . . .	ST700-K167	*	Tune-up Kit (for ST799 models with left hand rotation) includes 12, 14, 16, 16A, 17, 19, 20, 21, 22, 24 and 42A . . . . .	ST799R-TK5
*	Planet Gear Kit (includes illustrated parts 14, 19 [3], 20 [54], 21 [6] and 22 [3]) . . . . .	ST700-K10	*	Tune-up Kit (for Inertia drive models) includes illustrated parts 30, 31, 33, 34, 35 and 39 . . . . .	ST700I-TK6
*	Tune-up Kit (includes illustrated parts: 14, 15, 16, 16A, 17, 19, 20, 21, 22 and 42A) . . . . .	ST700-TK1			
*	Tune-up Kit (for ST750 models with right hand rotation) includes illustrated parts 12, 14, 16, 16A, 17, 19, 20, 21, 22, 24 and 42A . . . . .	ST750R-TK2			

\* Not illustrated.



SERIES ST700 TURBINE STARTER (PRE-ENGAGED)

## PRE-ENGAGED DRIVE

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

	Housing Exhaust Cover Assembly .....	ST700-A562		Planet Gear Frame Assembly .....	ST700-A108
1	Housing Exhaust Cover .....	ST700-562	18	Planet Gear Frame .....	ST700-108
2	Exhaust Cover Seal .....	SS800-67	◆ 19	Planet Gear (3) .....	ST700-10
*	Exhaust Cover Plug .....	ST700-K37	◆ 20	Planet Gear Needle Roller Gearing (3) .....	ST700-363
3	Splash Deflector .....	ST700-735	*	Planet Gear Needle Roller (18) .....	ST700-363-R
4	Deflector Return Spring .....	D10-275	◆ 21	Bearing Spacer (6) .....	ST700-364
5	Deflector Retaining Screw .....	ST700-737	◆ 22	Planet Gear Shaft (3) .....	ST700-191
6	Starter Assembly Cap Screw (4) .....	ST700-2574	23	Gear Shaft Retaining Washer (2) .....	ST700-100
7	Cap Screw Washer (4) .....	SS800-26	◆ 24	Rear Gear Frame Bearing .....	TA-22
	Motor Housing Assembly .....	ST700-A40	25	Front Bearing Spacer .....	ST700-90
8	Motor Housing .....	ST700-40	26	Intermediate Pinion	
10	Housing Plug (2) .....	CE110-29		for Models ST750GBDP03R31, ST750GBDP03L32, ST799GBDP03R31 and ST799GBDP03L32 .....	SS800B-17
11	Housing Plug Inlet Boss .....	R0H-377		for Models ST750GCDP03R25, ST750GCDP03L26, ST799GCDP03R25 and ST799GCDP03L26 .....	SS825C-17
*	Nameplate .....	ST700-301		for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-17
*	Nameplate Screw (4) .....	R4K-302	27	Intermediate Pinion Retaining Screw .....	SS800-732
◆ 12	Motor Assembly		28	Gear Case	
	for Models ST750GBDP03R31, ST750GCDP03R25 and ST750GDDP09R51 .....	ST750R-A53		for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-37
	for Models ST750GBDP03L32, ST750GCDP03L26 and ST750GDDP09L52 .....	ST750L-A53		for all other models .....	SS800-37
	for Models ST799GBDP03R31, ST799GCDP03R25 and ST799GDDP09R51 .....	ST799R-A53	29	Drive Gear	
	for Models ST799GBDP03L32, ST799GCDP03L26 and ST799GDDP09L52 ...	ST799L-A53		for Models ST750GBDP03R31, ST750GBDP03L32, ST799GBDP03R31 and ST799GBDP03L32 .....	SS815B-9
12A	Cylinder O-ring Seal (2) .....	ST700-67		for Models ST750GCDP03R25, ST750GCDP03L26, ST799GCDP03R25 and ST799GCDP03L26 .....	SS825C-9
12B	Housing O-ring Seal (2) .....	Y327-032		for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850D-9
	Intermediate Gear Case Assembly .....	ST700-A37			
13	Intermediate Gear Case .....	ST700-37			
◆ 14	Rear Gear Case O-ring .....	Y327-163			
◆ 15	Front Gear Case O-ring .....	Y327-162			
◆ 16	Planet Gear Frame Shaft Seal .....	ST700-272			
◆ 16A	Spacer Ring .....	ST700-323			
◆ 17	Front Gear Frame Bearing .....	SS800-22			

\* Not illustrated.

◆ Indicates Tune-up Kit part.

**PRE-ENGAGED DRIVE (Continued)**

**PART NUMBER FOR ORDERING** →

**PART NUMBER FOR ORDERING** →

30	Front Drive Gear Bearing .....	SS800-278	◆ 47	Outer Bulkhead O-ring for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-152 SS800-152
◆ 31	Rear Drive Gear Bearing .....	SS800-359			
32	Drive Gear Bearing Retainer .....	SS800-361			
33	Drive Gear Shaft Bearing Retainer .....	SS800-632			
34	Drive Gear Screw .....	SS800-179			
35	Drive Gear Lock Washer .....	SS800-180	◆ 48	Inner Bulkhead O-ring for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51, ST799GDDP09L52 .....	SS850-151 SS800-151
36	Drive Gear Cup .....	SS800-177			
37	Drive Gear Screw O-ring .....	SS800-176			
38	Drive Housing Cap Screw (8) .....	SS800-744			
39	Drive Housing Cap Screw Lock Washer (8) .....	TE223A-415			
40	Drive Housing Kit for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-K300 SS825-K300		49 Clutch Spring Cup Retainer .....	SS800-366
	for all other models .....			50 Clutch Spring Cup .....	SS800-367
◆ 41	Drive Housing O-ring for B & C ratio .....	SS800-244		51 Clutch Spring .....	SS800-583
	for D ratio .....	SS850-244		52 Clutch Jaw Kit for Models ST750GBDP03R31, ST750GCDP03R25, ST750GDDP09R51, ST799GBDP03R31, ST799GCDP03R25 and ST799GDDP09R51 .....	SS800R-K587
42	Front Drive Shaft Bearing .....	SS850-363		for Models ST750GBDP03L32, ST750GCDP03L26, ST750GDDP09L52, ST799GBDP03L32, ST799GCDP03L26 and ST799GDDP09L52 .....	SS800L-K587
43	Drive Housing Seal .....	SS800-271			
44	Drive Housing Vent Plug .....	P250-546			
◆ 45	Bulkhead Retainer for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-181 SS800-181		53 Large Drive Shaft Bearing Retainer for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-107 SS800-107
	for all other models .....				
46	Bulkhead Kit for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-K150 SS800-K150			
	for all other models .....				

**MAINTENANCE SECTION**

- ◆ Indicates Tune-up Kit part.
- ◆ Indicates Tune-up Kit part.

**PRE-ENGAGED DRIVE (Continued)**

**PART NUMBER FOR ORDERING** →

**PART NUMBER FOR ORDERING** →

54	Piston Kit for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850K-703 SS800K-703	◆ 60	Seat (for all "B" and "C" ratio Models only) .....	SS800-191
◆ 55	Piston O-ring for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-337 SS800-337	61	Drive Pinion Retaining Screw for Models ST750GBDP03R31, ST750GCDP03R25, ST799GBDP03R31 and ST799GCDP03R25 .....	SS800R-394
57	Drive Shaft Kit for Models ST750GBDP03R31, ST750GCDP03R25, ST799GBDP03R31 and ST799GCDP03R25 .....	SS800R-K8		for Models ST750GBDP03L32 ST750GCDP03L26, ST799GBDP03L32 and ST799GCDP03L26 .....	SS800L-394
	for Models ST750GDDP09R51 and ST799GDDP09R51 .....	SS850R-K8		for ST750GDDP09R51 and ST799GDDP09R51 .....	SS850R-394
	for ST750GDDP09L52 and ST799GDDP09L52 .....	SS850L-K8	62	Drive Pinion Washer for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-725 SS800-725
58	Rear Drive Shaft Bearing (includes bearing and retainer) for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 .....	SS850-K399 SS800-K399	63	Drive Pinion for ST750GBDP03R31 and ST799GBDP03R31. ....	SS815R-13-31
	for all other models .....	SS850-700 SS800-700		for ST750GBDP03L32 and ST799GBDP03L32 .....	SS815L-13-32
59	Piston Return Spring for Models ST750GDDP09R51, ST750GDDP09L52 and ST799GDDP09R51 .....	SS850-700 SS800-700		for ST750GCDP03R25 and ST799GCDP03R25. ....	SS825R-13-25
	for all other models .....			for ST750GCDP03L26 and ST799GCDP03L26 .....	SS825L-13-26
				for ST750GDDP09R51 and ST799GDDP09L52. ....	SS850R-13-51
				for ST750GDDP09L52 and ST799GDDP09L52. ....	SS850L-13-52

◆ Indicates Tune-up Kit part.

**PRE-ENGAGED DRIVE (Continued)**

**PART NUMBER FOR ORDERING** →

← **PART NUMBER FOR ORDERING**

64	Pinion Spring Sleeve for Models ST750GDDP09R51, ST750GDDP09L52, ST799GDDP09R51 and ST799GDDP09L52 . . . . .	SS850-335	*	Flange Mounting Hardware Kit (includes O-ring, Mounting Bolts and Lock Washers) . . . . .	ST750-K167
	for all other models . . . . .	SS800-335	*	Planet Gear Kit (includes illustrated parts 14, 19 [3], 20 [54], 21 [6] and 22 [3]) . . . . .	ST700-K10
65	Pinion Spring for Models ST750GBDP03R31, ST750GCDP03R25, ST799GBDP03R31 and ST799GCDP03R25 . . . . .	SS800R-419	*	Tune-up Kit (includes illustrated parts 14, 15, 16, 16A, 17, 19, 20, 21, 22, 24 and 66A) . . . . .	ST700-TK1
	for Models ST750GBDP03L32, ST750GCDP03L26, ST799GBDP03L32 and ST799GCDP03L26 . . . . .	SS800L-419	*	Tune-up Kit (for ST750 models with right hand rotation) includes illustrated parts 12, 14, 16, 16A, 17, 19, 20, 21, 22, 24 and 66A . . . . .	ST750R-TK2
	for ST750GDDP09R51 and ST799GDDP09L52 . . . . .	SS850R-419	*	Tune-up Kit (for ST799 models with left hand rotation) includes illustrated parts 12, 14, 16, 16A, 17, 19, 20, 21, 22, 24 and 66A . . . . .	ST750L-TK3
	for ST750GDDP09L52 and ST799GDDP09L52 . . . . .	SS850L-419	*	Tune-up Kit (for ST799 models with right hand rotation) includes 12, 14, 16, 16A, 17, 19, 20, 21, 22, 24 and 66A . . . . .	ST799R-TK4
66	Inlet Flange Kit (includes Inlet Flange, O-ring, Mounting Bolts and Lock Washers) . . . . .	ST700-K166	*	Tune-up Kit (for ST799 models with left hand rotation) includes 12, 14, 16, 16A, 17, 19, 20, 21, 22, 24 and 66A . . . . .	ST799R-TK5
67	Drive Housing Kit . . . . .	ST700-K300	*	Tune-up Kit (for Pre-engaged drive models) includes illustrated parts 31, 41, 45, 47, 48, 55 and 60 . . . . .	ST700P-TK7
68	Flange . . . . .	ST700-212A	*	Tune-up Kit (for D ratio models) includes illustrated parts 41, 45, 47, 48 and 55 . . . . .	ST700D-TK8
69	Ring . . . . .	ST700-694Y			
70	Bearing . . . . .	ST700-693			
71	Spring . . . . .	SS800-700LP			
72	Cap Screw (9) . . . . .	SS800-179			
73	Drive Housing . . . . .	04331328			
74	Flange . . . . .	04331310			

\* Not illustrated.

## MAINTENANCE SECTION


### ST700K-350 Exhaust Kit

(Available at extra cost)

**PART NUMBER FOR ORDERING**

	Exhaust Kit . . . . .	ST700K-350
101	Directional Housing Exhaust Cover . . . . .	ST700-350
102	Cap Screw (6) . . . . .	ST700-703
103	Lock Washer (6) . . . . .	845-58
104	Exhaust Adapter . . . . .	ST700-351
105	Exhaust Adapter Seal . . . . .	ST700-103
106	Exhaust Cover Seal . . . . .	SS800-67
107	Weld Sleeve . . . . .	ST700-352
*	Plug . . . . .	ROH-377

\* Not illustrated.



## INSTALLATION

### NOTICE

To aid in installation of ST700K-350 Exhaust Kit, refer to Drawings TPA1272-2 and TPA1273-2 in this manual.

### ⚠ WARNING

**Always turn off the air or gas supply and disconnect the air or gas supply hose before installing, removing or adjusting any accessory on this starter or before performing any maintenance on this starter.**

1. Using an 8mm hex-head wrench, remove Starter Assembly Cap Screws (6) and Cap Screw Washers (7).
2. Pull the Housing Exhaust Cover (1) from the Motor Housing (8). To dislodge the Housing Exhaust Cover, rotate it until it clears the Motor Housing. Using a plastic hammer, tap the ears alternately until the Housing Exhaust Cover can be removed from the Motor Housing.

### NOTICE

**If Exhaust Cover Seal (106) was removed or damaged, replace it with a new Seal.**

3. Coat the Exhaust Cover Seal with O-ring lubricant and install in the groove in the Directional Housing Exhaust Cover (101).
4. Install Directional Housing Exhaust Cover on the rear of the Motor Housing in the desired orientation and using a plastic hammer, tap the Directional Housing Exhaust Cover until it seats.
5. Secure the Directional Housing Exhaust Cover on the rear of the Motor Housing using the Starter Assembly Cap Screws and Cap Screw Washers. Using an 8mm hex-head wrench, tighten each Cap Screw a little at a time to a final torque of 55 ft-lb (74.5 Nm) in 20 ft-lb (27 Nm) increments.
6. Lubricate Exhaust Adapter Seal (105) with O-ring lubricant and install in groove in Exhaust Adapter (104).
7. Install Exhaust Adapter **with Exhaust Adapter Seal down** on Directional Housing Exhaust Cover. Align holes and secure Adapter with Cap Screws (102) and Lock Washers (103). Tighten each Cap Screw a little at a time to a final torque of 48 ft-lb (65 Nm torque) in 20 ft-lb (27 Nm) increments.



## MAINTENANCE SECTION

### ⚠ WARNING

Always wear eye protection when operating or performing any maintenance on this starter. Always turn off the air or gas supply and disconnect the air or gas supply hose before installing, removing or adjusting any accessory on this starter or before performing any maintenance on this starter.

### LUBRICATION

Each time a Series ST700 Starter is disassembled for maintenance or repair, lubricate the starter as follows:

#### For Models with Inertia Drive

### NOTICE

On models with inertia drive, do not lubricate the threaded area of the Drive Shaft as it could collect dirt and foreign material which will prevent efficient operation.

#### For Models with Pre-Engaged Drive

1. Lubricate the inside diameter of the Drive Shaft (57) with Ingersoll-Rand No. 130 Grease.
2. Lubricate the Pinion end of the Drive Shaft with Ingersoll-Rand No. 11 Grease.
3. Wipe a thin film of Ingersoll-Rand No. 130 Grease in the bore of the Drive Housing (40).
4. Roll the Piston Return Spring (59) in Ingersoll-Rand No. 130 Grease.
5. Coat the outside of the Piston (54) with Ingersoll-Rand No. 130 Grease.

#### For All Models

1. Lubricate all O-rings with O-ring lubricant.
2. Lubricate the Front Drive Gear (29) with 8 oz. (240 ml) of Ingersoll-Rand No. 130 Grease.
3. Coat the Front Bearing Spacer (25) with gear lube before installing.
4. Add 175 ml (approximately 1/3 pint) of Dexron®\*\* II Automatic Transmission Fluid through the side plug hole in the Motor Housing (8).

### DISASSEMBLY

#### General Information


1. Do not disassemble the Starter any further than necessary to replace worn or damaged parts.
2. When grasping a part in a vise, always use leather-covered or copper-covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members.

\*\* Registered trademark of Exxon Corp.

3. Do not remove any part which is a press fit in or on a subassembly unless the removal of that part is necessary for replacement or repairs.
4. Always have a complete set of seals and O-rings on hand before starting any overhaul of a Series ST700 Turbine Starter. Never reuse old seals or gaskets.
5. Always mask adjacent parts on the Housing Exhaust Cover (1), Motor Housing (8), Intermediate Gear Case (13), Gear Case (28) and Drive Housing (38) so these members can be located in the same relative position when the Starter is reassembled.
6. Never wash the Inertia Drive in a solvent.
7. Do not press any needle bearing from a part unless you have a new needle bearing on hand for installation. Needle bearings are always damaged during the removal process.

#### Disassembly of the Housing Exhaust Cover, Motor Assembly, and Motor Housing


1. If replacing the Motor Assembly (12), remove both Housing Plugs (10) and drain the oil from the gearing before beginning disassembly of the Starter. Inspect the Magnetic Housing Plugs (10) for metal particles. Very fine metal particles are normal. Remove particles and reinstall plugs. Large particles or chips are an indication of a problem. Disassemble Gear Case (28) and inspect.
2. Using an 8 mm hex-head wrench, unscrew and remove the Starter Assembly Cap Screws (6) and Washers (7).
3. Pull the Housing Exhaust Cover (1) from the Motor Housing (8). To dislodge the Housing Exhaust Cover, rotate it until the ears clear the Motor Housing. Using a plastic hammer, tap the ears alternately until the Housing Exhaust Cover can be removed from the Motor Housing. Refer to Dwg. TPD1159.



(Dwg. TPD1159)


## MAINTENANCE SECTION

- Remove the Deflector Retaining Screw (5), Deflector Retaining Spring (4) and the Splash Deflector (3) from the Housing Exhaust Cover. Refer to Dwg. TPD1160.




(Dwg. TPD1160)

- Tap the Motor Housing with a plastic hammer to dislodge it from the Intermediate Gear Case (13). Refer to Dwg. TPD1162.




(Dwg. TPD1162)

- Grasp the rear of the Motor Assembly (12) and pull it from the rear of the Motor Housing. If the Motor Assembly is difficult to remove, lightly push the motor pinion which is on the front of the Motor Assembly toward the exhaust side of the Motor Housing in order to free the Motor Assembly. Refer to Dwg. TPD1161.



(Dwg. TPD1161)

- Tap the Intermediate Gear Case with a plastic hammer to dislodge it from the Gear Case (28). Refer to Dwg. TPD1164.



(Dwg. TPD1164)


- Position the Intermediate Gear Case on a bench in a copper-faced vise so that the Intermediate Pinion (26) is secured in the jaws of the vise. Tighten the vise only enough to hold the Intermediate Pinion securely.
- Loosen the Intermediate Pinion Retaining Screw (27) 1-1/2 turns only. **Do not remove.**

### ⚠ WARNING

**If the Intermediate Gear Case is not supported on a bench and if the Intermediate Pinion Retaining Screw is completely removed, the Intermediate Gear Case and components could fall causing injury.**


Tap the Intermediate Pinion lightly to back the Planet Gear Frame Assembly out of the Intermediate Gear Case. Refer to Dwg. TPD1169.

## MAINTENANCE SECTION



**(Dwg. TPD1169)**

10. Remove the Intermediate Gear Case Assembly from the vise and remove the Intermediate Pinion. Remove the Rear Gear Case O-ring (14) and Front Gear Case O-ring (15) from the Intermediate Gear Case.
11. Remove the Planet Gear Frame Assembly from the Intermediate Gear Case. Using a sleeve that contacts the outer race of the Front Gear Frame Bearing (17), press the Planet Gear Frame Shaft Seal (16) and the Front Gear Frame Bearing (17) from the front end and out of the rear of the Intermediate Gear Case. Refer to Dwg. TPD1166.




**(Dwg. TPD1166-1)**

12. Using a bearing puller, remove the Rear Gear Frame Bearing (24) from the Planet Gear Frame (18) and remove the Gear Shaft Retaining Washer (23).
13. Remove the Planet Gear Shafts (22), Planet Gears (19), Planet Gear Bearings (20) and Bearing Spacers (21).

14. Using a bearing puller, remove the Front Bearing Spacer (25) and the Gear Shaft Retaining Washer (23) from the front of the Planet Gear Frame by pressing on the front of the Planet Gear Frame Shaft. Refer to Dwg. TPD1167.

### NOTICE

**Remove the Gear Shaft Retaining Washer only if the Washer or Front Bearing Spacer is damaged.**




**(Dwg. TPD1167)**

### Disassembly of the Drive Housing

#### Inertia Models:


1. Remove the eight Drive Housing Cap Screws (40) and Lock Washers (41).
2. Tap the Drive Housing (38) with a plastic hammer to help dislodge it from the Gear Case Cover (32). Remove the Drive Housing (38) from the Starter Drive (36). Refer to Dwg. TPD1168.



**(Dwg. TPD1168)**

## MAINTENANCE SECTION

- Place the Drive Housing in an arbor press, bearing end up. Using a pressing bar remove the Drive Housing Bearing (39) the Drive Housing.
- Using a screwdriver, displace the locking spring and remove the screw holding the Starter Drive (36) to the Drive Gear Shaft.
- Slide the Starter Drive off the Drive Gear Shaft.
- Remove the two Drive Gear Keys (37) from the Drive Gear Shaft. Refer to Dwg. TPD1171.



(Dwg. TPD1171)

- Remove the Gear Case Cover from the Gear Case.
- Remove the Drive Housing O-ring (35) and the Gear Case Cover Seal (33) from the Gear Case Cover.
- Pull the Drive Gear (30) out of the Gear Case.
- Remove the Rear Drive Gear Bearing (31) and the Front Drive Gear Bearing (30) from the Drive Gear.

### Pre-Engaged Models:

- Grasp the Drive Pinion (63) in a copper-faced vise with the Starter supported on the workbench.
- Remove the Drive Pinion Retaining Screw (61).

### NOTICE

**Models ending in R25, R31 and R51 have a left-hand thread. Models ending in L26, L32 and L52 have a right-hand thread.**

- Remove the Starter from the vise.
- Remove the Drive Pinion Washer (62) and the Drive Pinion.
- Slide the Pinion Spring Sleeve (64) and the Pinion Spring (65) off the Drive Shaft.
- Using an impact wrench with a 5/16" (8 mm) x 8" (203 mm) long hex inserted into the end of the Drive Shaft, unscrew the Drive Gear Screw (34).

- Unscrew and remove the Drive Housing Cap Screws (38) and Lock Washers (39).
- Tap the Drive Housing (40) with a plastic hammer to help dislodge it from the Gear Case (28).

### WARNING

**Failure to follow this procedure could result in injury to personnel.**

- Place the Drive Housing in an arbor press, piston end up. Apply a load to the Piston (54) using the arbor press to compress the Piston Return Spring (59) before removing the Bulkhead Retainer (45). **Do not use compressed air to load the Piston.**
- Using a screwdriver, remove the Bulkhead Retainer. Use off the arbor press.

### CAUTION

**Make sure the tension of the spring pushes the Bulkhead out of the Drive Housing before removing the Drive Housing from the arbor press.**

- Remove the Bulkhead (46) from the Piston.
- Remove the Outer Bulkhead Ring (47) and the Inner Bulkhead Ring (48).
- Slide the Drive Shaft (57) from the Drive Housing.
- Pull the Piston Return Spring (59) off the Drive Shaft.

### NOTICE

**Do not remove the Front Drive Shaft Bearing (42) or the Drive Housing Seal (43) unless replacement is necessary and new parts are available. The Bearing and/or the Seal will always be damaged when removed from the Drive Housing.**

- Remove the Piston Ring (55) from the Piston.
- Insert a large screwdriver blade through the Piston Seal (56) so that it rests on top of the Clutch Spring Cup (50). Pry the Seal out of the Piston.

### NOTICE

**This operation will damage the Piston Seal. Therefore, a replacement Piston Seal must be on hand.**


- Press the Clutch Spring Cup (50) down and remove the Clutch Spring Cup Retainer (49).
- Remove the Clutch Spring Cup and Clutch Spring (51).
- Remove the two Clutch Jaws (52).
- Remove the Front Drive Gear Bearing (30), Drive Gear Cup (46), Drive Gear Lock Washer (35), Drive Gear Screw Ring (37) and Drive Gear Screw (34).
- Using a screwdriver, remove the large Drive Shaft Bearing Retainer (53).

## MAINTENANCE SECTION

22. Press the Rear Drive Shaft Bearing and Drive Shaft (57) out of the Piston. If the Rear Drive Shaft Bearing needs to be replaced, proceed as follows:
  - a. Using a small chisel, cut and remove the small drive shaft bearing retained in the Drive Shaft.

### NOTICE

- b. Press the Rear Drive Shaft Bearing (58) off the Drive Shaft.
23. Place the Gear Case (28) on a workbench.
24. Using retaining ring pliers and working through the access holes in the gear web, remove the Drive Gear Bearing Retainer (32). Refer to Dwg. TPD1170.



(Dwg. TPD1170)

25. Pull the Drive Gear (29) out of the Gear Case.

### NOTICE

**Do not disassemble the Drive Gear and Clutch parts of Series ST700 Turbine-Powered Starters. If the Drive Shaft is defective, install a new or factory-rebuilt unit.**

26. Using retaining ring pliers, remove the Drive Gear Shaft Bearing Retainer (33).
27. Remove the Rear Drive Gear Bearing (31) from the Drive Gear.


## ASSEMBLY

### General Instructions

1. Always press on the **inner** ring of a ball-type bearing when installing the bearing on a shaft.
2. Always press on the **outer** ring of a ball-type bearing when pressing the bearing into a bearing recess.

3. Whenever grasping a starter or part in a vise, always use leather-covered or copper-covered vise jaws. Take extra care with threaded parts or housings.
4. Except for bearings, always clean every part and wipe every part with a thin film of oil before installation.
5. Check every bearing for roughness. If an open bearing must be cleaned, wash it thoroughly in a suitable cleaning solution and dry with a clean cloth. **Sealed or shielded bearings should never be cleaned.** Work grease thoroughly into every open bearing before installation.
6. Apply a film of O-ring lubricant to all O-rings before final assembly.
7. Unless otherwise noted, always press on the **stamped end** of a needle bearing when installing the needle bearing in a recess. Use a bearing inserting tool similar to the one shown in Dwg. TPD786.

### Needle Bearing Inserting Tool



(Dwg. TPD786)

### Assembly of the Gear Case and Drive Housing

#### Inertia Drive Models:

### NOTICE


**On models with Inertia Drive, do not lubricate threaded area of the Drive Shaft as it could collect dirt and foreign material which will hinder efficient operation.**

#### Gear Case

1. Install the Rear Drive Gear Bearing (31) and Front Drive Gear Bearing (30) onto the Drive Gear (29).


## MAINTENANCE SECTION

2. Install the two Drive Gear Keys (37) into the drive gear shaft. Refer to Dwg. TPD1171.



(Dwg. TPD1171)

3. Slide the Rear Drive Gear Bearing into the Gear Case.
4. Lubricate the Drive Gear with approximately 8 oz. (240 ml) of Ingersoll-Rand No. 130 Grease.
5. Press the Drive Gear Shaft Seal (34) down into the Gear Case Cover (32) lip facing upward.
6. Install the Gear Case Cover O-ring (33) onto the Gear Case Cover.
7. Install the Gear Case Cover into the Gear Case.
8. Slide the Starter Drive (36) onto the drive gear shaft and tighten the Starter drive locating ring and screw securely.
9. Press the Drive Housing Bearing (39) into the Drive Housing (38) and lubricate with Ingersoll-Rand No. 130 Grease. See Dwg. TPD786.
10. Install the Drive Housing O-ring (35) onto the Drive Housing.
11. Install the Drive Housing onto the Gear Case, aligning the punches.
12. Install the eight Drive Housing Cap Screws (40) and Drive Housing Cap Screw Lock Washers (41). Tighten to 28 ft-lb (38 Nm) torque. Refer to Dwg. TPD1168.




(Dwg. TPD1168)

## Assembly of the Gear Case and Drive Housing

### Pre-Engaged Models:

#### Gear Case

1. Place the Drive Gear Bearing Retainer over the rear end of the Drive Gear.
2. Using an arbor press, press the Rear Drive Gear Bearing (31) onto the rear end of the Drive Gear.
3. Using a plastic hammer, seat the Rear Drive Gear Bearing into the Gear Case by tapping the opposite end of the Drive Gear.
4. Using retaining ring pliers, install the Drive Gear Shaft Bearing Retainer (33).
5. Using retaining ring pliers and working through the access holes in the gear web, install the Drive Gear Bearing Retainer. Refer to Dwg. TPD1170.



(Dwg. TPD1170)

6. Lubricate the Drive Gear with approximately 8 oz. (240 ml) of Ingersoll-Rand No. 130 Grease.
7. Press the Rear Drive Shaft Bearing (58) onto the Drive Shaft.
8. Slide the small bearing retainer convex side first, onto the Drive Shaft. Press it into position in accordance with the instructions packaged with the new Retainer.
9. Assemble the Drive Gear Screw (34), Drive Gear Lock Washer (35), Drive Gear Cup (36) and Drive Gear Screw O-ring (37).
10. Grasp the Drive Shaft (57) in a vise, external splined end down. Place assembled Drive Shaft Screw Unit into the Drive Shaft, screwhead down. Lubricate the inside diameter of the Drive Shaft with Ingersoll-Rand No. 130 Grease.

## MAINTENANCE SECTION

11. Slide the Drive Gear Bearing (30) into the Drive Shaft.
12. Lubricate with Ingersoll-Rand No. 130 Grease and install the Driving Clutch Jaw teeth facing up and Driven Clutch Jaw teeth facing down into the Drive Shaft.
13. Insert the Clutch Spring (51) into the Drive Shaft.
14. Insert the Clutch Spring Cup (50) into the Drive Shaft.
15. Press the inserted parts into the Drive Shaft, and install the Clutch Spring Cup Retainer (49).

### NOTICE

**If it is necessary to replace the Drive Housing (40) and drive components, make sure that the Piston Seal (part number SS800-272) has been removed from the rear of the new Piston (54). The Piston Seal must be removed to prevent pressure build-up which will cause movement of the Planet Gear Frame Shaft Seal (16). If this condition occurs, the Piston cannot retract and the Drive Pinion (63) will remain in engagement with the flywheel, causing damage to the Starter drive train and/or Starter motor. To remove the Piston Seal, insert a screwdriver inside the lip of the Seal and pry it loose from the Piston.**

16. Install the Piston (54) onto the Drive Shaft until the Rear Drive Shaft Bearing seats into the Piston.
17. Using a thin flat blade screwdriver to assist in this operation, coil the Large Drive Shaft Bearing Retainer (53) into the groove of the Piston to retain the outer race of the Drive Shaft Bearing.
18. Using O-ring lubricant, lubricate the Piston O-ring (55) and install it in the groove of the Piston.
19. Position the Drive Housing in an arbor press, pinion-end down and install the Drive Housing Seal (43) into the Drive Housing. Using a pressing sleeve of the proper size, press the Seal into the Drive Housing so that the lip of the seal faces away from the Drive Pinion.
20. Using a sleeve that contacts the outer race of the Front Drive Shaft Bearing (4), press the Bearing into the Drive Housing until it seats. For "B" and "C" ratio models only, drop the Piston Return Spring Seat (60) on top of the Front Drive Shaft Bearing. (See illustration on page 18.)
21. Slide the Piston Return Spring (59) onto the Drive Shaft and snap it into the front of the Piston so that it is against the Large Drive Shaft Bearing Retainer (53).
22. Lubricate and insert the assembled Drive Shaft into the Drive Housing.
23. Using O-ring lubricant, lubricate and install the Outer Bulkhead O-ring (47) and the Inner Bulkhead O-ring (48) on the Bulkhead (45).
24. Slide the Bulkhead onto the Piston.

25. With the Drive Housing in the arbor press, press down on the rear face of the Piston.

### NOTICE

**Feel the underside of the Drive Housing to make sure the Drive Shaft passes through the Bearing.**

26. Using a screwdriver, install the Bulkhead Retainer (45).

### ▲ WARNING

**Make sure the Bulkhead Retainer is properly seated in the Motor Housing groove before easing off the arbor press. Failure to do so will allow improperly retained parts to separate when removed from the arbor press resulting in injury to personnel.**

27. Remove the Drive Housing from the arbor press.
28. Using O-ring lubricant, lubricate and install the Drive Housing O-ring (41) in the groove of the Drive Housing.
29. Position the assembled Gear Case on a workbench. The assembled unit must be upright to accept the Drive Housing.
30. Carefully position the assembled Drive Housing (40) onto the Gear Case so as not to damage the Piston Seal. Align the punch marks of the Gear Case and Drive Housing.
31. Install the Drive Housing Cap Screw Lock Washers (39) and the Drive Housing Cap Screws (38) and tighten to 28 ft-lb (38 Nm) torque.
32. Using an impact wrench with a 5/16" (8 mm) x 8" (203 mm) long hex inserted into the end of Drive Shaft, tighten the Drive Gear Screw (34) to 57 ft-lb (77.3 Nm) torque.
33. Lubricate using Ingersoll-Rand No. 11 Grease and slide the Pinion Spring (65) and the Pinion Spring Sleeve (64) over the Pinion end of the Drive Shaft.
34. Lubricate the Pinion end of the Drive Shaft with Ingersoll-Rand No. 11 Grease and install the Drive Pinion (63).
35. Grasp the Drive Pinion in a leather-covered or copper-covered vise with the starter supported on a workbench.
36. Place the Drive Pinion Washer (62) onto Drive Pinion Retaining Screw (61).

### NOTICE

**Models ending in R25, R31 and R51 have a left-hand thread; models ending in L26, L32 and L52 have a right-hand thread. Install the Drive Pinion Retaining Screw into the end of the Drive Shaft and tighten it to 80 ft-lb (108.5 Nm) torque for models with "B" and "C" gear ratios and to 125 ft-lb (169.5 Nm) torque for models with "D", gear ratio.**


## MAINTENANCE SECTION

### Assembly of the Intermediate Gear Case, Motor Housing, Motor Assembly and Housing Exhaust Cover

1. Using a bearing pressing tool of the proper size, press the Front Gear Frame Bearing (17) into the rear of the Intermediate Gear Case (13). Place Spacer Ring (16A) on Bearing.
2. Using a sleeve which contacts the outer ring of the seal, press the Planet Gear Frame Shaft Seal (16) into the rear of the Intermediate Gear Case over the Front Gear Frame Bearing. Refer to Dwg. TPD1172-1.

#### NOTICE

**Make sure the flat side of the Seal is installed against the Bearing.**



(Dwg. TPD1172-1)

3. Install the Rear Gear Case O-ring (14) in the groove at the rear of the Intermediate Gear Case and the Front Gear Case O-ring (15) in the groove at the front of the Intermediate Gear Case. Coat both O-rings with O-ring lubricant.
4. Install one Gear Shaft Retaining Washer (23) on the front of the Planet Gear Frame (18). Press the Front Bearing Spacer (25) on the front shaft of the Planet Gear Frame to hold the Gear Shaft Retaining Washer snugly in position.

#### NOTICE

**Coat the Front Bearing Spacer with Gear Lube before installing it. Be careful not to gouge or scratch the Front Bearing Spacer during installation as this could result in leakage between the Planet Gear Frame and Gear Case.**


5. Place Planet Gear Frame on a bench, shaft side down. Place the Planet Gear Bearing (20) inside of Planet Gear (19). Place Bearing Spacers (21) on top and bottom of Bearing and Gear. Slide the components into the slots in the side of the Planet Gear Frame. Align holes in Spacers and Bearing with holes in Planet Gear

Frame and insert Planet Gear Shaft (22), integral keyed end down, through the Spacers and Bearing so that the larger portion of the keyed end of the Shaft contacts the Planet Gear Shaft Retaining Washer. Repeat the procedure for the two remaining Planet Gears and Components.

#### NOTICE


**Do not move or turn over the Planet Gear Frame until steps 6 and 7 have been completed. Movement of the Planet Gear Frame Assembly could dislodge assembled components, making it necessary to repeat Step 5.**

6. Install the other Planet Gear Shaft Retaining Washer over the shaft at the rear of the Planet Gear
7. Using the proper size bearing inserting tool, press the Rear Gear Frame Bearing (24) on the shaft at the rear of the Planet Gear Frame. Refer to Dwg. TPD1167.



(Dwg. TPD1167)

8. Slide the Planet Gear Frame Assembly, coupling end first, into the rear of the Intermediate Gear Case (13), making sure that the Planet Gears mesh with the ring gear. Use care so as to not damage the seal. Refer to Dwg. TPD1173.




(Dwg. TPD1173)



## MAINTENANCE SECTION

9. Install the Intermediate Pinion (26) making sure that the notches at the rear of the Pinion align with the notches and tangs in the shaft of the Planet Gear Frame.
10. Clean the threads of the Intermediate Pinion Retaining Screw (27) and apply 2–3 drops of PermaBond HM118®\*\*\* to the threads approximately 3 mm from the end of the Screw. Install Screw and tighten enough to hold assembly together.
11. For final tightening, position the Intermediate Gear Case so the Intermediate Pinion is secured in the jaws of a leather-covered or copper-faced vise. Tighten the Intermediate Pinion Retaining Screw to 90 ft-lb (122 Nm) torque. Refer to Dwg. TPD1204.



(Dwg. TPD1204)


12. Remove the Intermediate Gear Case from the vise and set it on a bench.

### NOTICE

**The Intermediate Gear Case will work in only one orientation.**

Align the punch marks on the Intermediate Gear Case and Gear Case and using a plastic hammer, tap the Intermediate Gear Case until it seats in the rear of the Gear Case. Make sure the Intermediate Pinion meshes with Drive Gear. Refer to Dwg. TPD1165.

\*\*\* Registered trademark of PermaBond Corp.




(Dwg. TPD1165)

13. Before installing the Motor Assembly, coat the O-rings on the Motor Assembly and the inside of the Cylinder with O-ring lubricant. Install the Motor Assembly through the rear of the Motor Housing with the geared end of the rotor toward the front. Refer to Dwg. TPD1161.

### NOTICE


**Turn the Intermediate Pinion so that the gear on the rotor meshes with the Planet Gears. Make sure that the rear of the Motor Assembly is installed flush with the rear of the Cylinder.**



(Dwg. TPD1161)


## MAINTENANCE SECTION

14. Align the punch marks on the Motor Housing with the punch marks on the Intermediate Gear Case and using a plastic hammer, tap the Motor Housing until it seats on the rear of the Intermediate Gear Case. Refer to Dwg. TPD1163.



(Dwg. TPD1163)

15. Coat the Exhaust Cover Seal (2) with O-ring lubricant and install in the groove on the Housing Exhaust Cover.
16. Align the punch marks on the Housing Exhaust Cover with the punch marks on the Motor Housing and using a plastic hammer, tap the Housing Exhaust Cover until it seats.
17. Install the Housing Exhaust Cover on the rear of the Motor Housing using the Starter Assembly Cap Screws (6) and Cap Screw Washers (7). Use an 8 mm hex-head wrench to tighten each a little at a time to a final torque of 45 to 50 ft-lb (61 to 68 Nm). Refer to Dwg. TPD1183.




(Dwg. TPD1183)

### NOTICE

18. When assembling the exhaust cover to the starter, add 15 ml of Dextron®\*\*\*II Automatic Transmission Fluid through the pipe plug hole in the Exhaust Cover.
19. Install the Splash Deflector (3), Deflector Retaining Spring (4) and Deflector Retaining Screw (5) in the rear of the Housing Exhaust Cover. Refer to Dwg. TPD1160.

### NOTICE

**Coat the threads of the Deflector Retaining Screw with Ingersoll-Rand SMB-441 Sealant.**



(Dwg. TPD1160)

### NOTICE

**Use Ingersoll-Rand SMB-441 Pipe Sealant on all plugs.**

20. Install the **bottom** Housing Plug (10) and the Housing Plug Inlet Boss (11). Put the Starter on its side with the side plug hole upward. Add 175 ml (approximately 1/3 pint) of Dextron® II Automatic Transmission Fluid through the side plug hole in the Motor Housing (8).

### CAUTION

**Do not overfill.**

Install the side Housing Plug (10) and tighten all plugs to 5 to 10 ft-lb (6.8 to 13.6 Nm) torque.

\*\*\* Registered trademark of Exxon Corp.

## MAINTENANCE SECTION

### – TEST AND INSPECTION PROCEDURE –

1. **Clutch Ratcheting:** Turn the Drive Shaft Pinion (63) by hand in the direction of Starter rotation. The clutch should ratchet smoothly with a slight clicking action.
2. **Motor and Gearing Freeness:** Turn the Drive Shaft Pinion (63) opposite the direction of Starter rotation. The Drive Shaft Pinion should turn by hand.

#### NOTICE

**Inadvertent application of air pressure to the “OUT” port will result in Drive malfunction (Pinion will fail to retract). If this condition occurs, loosen Drive Housing Cap Screws (38) to vent Gear Case (21). Also, loosen Housing Plugs (10) and (11) to vent Motor.**

3. **Pinion Engagement:** Apply 50 psig (3.4 bar/345 kPa) pressure to the engagement “IN” Port. Drive Shaft Pinion (63) should move outward and air or gas should escape from the “Out” Port. Plug the “Out” Port and apply 150 psig (10.3 bar/1034 kPa) pressure to the “IN” Port. Check and make sure no air or gas is escaping. Measure the dimension from the face of the Drive Shaft Pinion (63) to the face of the mounting flange. It should be 2–23/32” (69.0 + 2.0 mm) for models with “B” and “C” ratio gearing and 8–3/4” (222 + 2.0 mm) for models with “D” ratio gearing. Remove the pressure from the “IN” Port. Measure the distance from the face of the Drive Shaft Pinion to the face of the mounting flange. It should be 1–25/32” (45.0 + 2.0 mm) for models with “B” and “C” ratio gearing and 7–3/32” (180 + 2.0 mm) for models with “D” ratio gearing.
4. **Motor Action:** Secure Starter in a vise and apply 90 psig (6.2 bar/620 kPa) pressure using a 3/8” (9 mm) supply line to the inlet of the motor. Starter should run smoothly.
5. **Motor Seals:** Plug the exhaust and slowly apply 20 psig (1.38 bar/138 kPa) pressure to the inlet of the motor. Immerse the Starter for 30 seconds in a nonflammable, bubble-producing liquid. If the Starter is properly sealed, no bubbles will appear.
6. **Gear Case Seals:** Plug the exhaust and slowly apply 20 psig (1.38 bar/138 kPa) pressure to the inlet of the motor. Immerse the Starter for 30 seconds in a nonflammable, bubble-producing liquid. There should be no leakage in the housing joints in the Gear Case area or in the shaft seal in the Intermediate Gear System. If the Starter is properly sealed, no bubbles will appear.
7. **Confirm Motor Rotation:** Remove Housing Plug (10). Use a 1/4” hex drive to rotate the motor to verify proper motor adjustment. Intermediate Gearing output should rotate opposite the required Starter

rotation while observing from the pinion side. Replace Housing Plug.

8. **Orientation:** Drive Housing must be assembled to customer orientation or per engineering drawing. If orientation is not specified by customer, standard orientation will be supplied. Check dimension prints on pages 7, 8, and 9.
9. **Confirm Drive Rotation:** Apply low pressure to motor and observe rotation. Drive Pinion (63) must rotate in the direction stamped on the nameplate. Chamfer on pinion teeth should be on trailing edge of gear tooth.
10. **Bendix Drive Function–Inertia Models Only:** Install Starter on testing fixture. Apply low pressure air to motor. Bendix must engage according to specified rotation.
11. **Drive Housing Function–Pre–Engaged Models Only:** Apply 120 psig (8.27 bar/8.27 kPa) to “IN” port of Drive Housing (40). Cycle five times. Air should exhaust through “OUT” port during each cycle.
12. **Free Speed (All Models):** Install the Starter on a testing fixture with proper containment system. Apply 90 psig (6.2 bar/ 620 kPa) to motor inlet. Free speed specifications should be as follows:

	MAXIMUM	MINIMUM
“B” ratio	4800 rpm	4500 rpm
“C” ratio	4130 rpm	3880 rpm
“D” ratio	3100 rpm	2870 rpm
13. **Exhaust Deflector Operation:** Install Starter on testing fixture. Apply low air pressure to motor and observe. Deflector must return to its normal position after operation of the Starter.
14. **Concentricity and Squareness of Shaft to Housing “D” Ratio Only:** Assemble indicator on shaft. Indicate pilot diameter. Check squareness of face at mounting surface. Pilot diameter must be concentric within .008 max. T.I.R. Mounting face must be square with shaft within .004 T.I.R. max.
15. **Drive Housing Leakage–Pre–Engaged Models Only:** Plug Drive Housing (40) “OUT” port and apply 50 psig (3.45 bar/345 kPa) to “IN” port to extend Drive Shaft (57). There should be no leakage.
16. **Test Pinion Engagement–Pre–Engaged Models Only:** Plug “OUT” port in Drive Housing (40). Apply 50 psig (3.45 bar/345 kPa) as needed. In its normal position, the distance from the mounting flange to the end of the Drive Shaft (57) should be 1–3/4”. In its extended position, the distance from the mounting flange to the end of the Drive Shaft should be 2–7/8”. While the Drive Shaft is extended, push Drive Pinion (63) back on helical splined shaft. Rear face of Drive Pinion must move back .47” ± .035”.

## MAINTENANCE SECTION

### TROUBLESHOOTING GUIDE

Trouble	Probable Cause	Solution
Motor will not run	No air supply	Check for blockage or damage to air supply lines or tank.
	Damaged Motor Assembly	Inspect Motor Assembly and power train and repair or replace if necessary.
	Foreign material in Motor and/or piping	Remove Motor Assembly and/or piping and remove blockage.
	Blocked exhaust system	Remove Housing Exhaust Cover and check for blockage.
	Defective Control Valve or Relay Valve	Replace Control Valve or Relay Valve.
Loss of power	Low air pressure to Starter	Check air supply.
	Restricted air supply line	Check for blockage or damage to air lines.
	Relay Valve malfunctioning	Clean or replace lines or Relay Valve. Lube Relay Valve.
	Exhaust flow restricted	Check for blocked or damaged piping. Clean or replace piping. Check for dirt or foreign material and clean or remove. Check for ice build-up. Melt ice and reduce moisture build-up to Starter.
	Damaged Motor Assembly	Replace Motor Assembly.

#### For Models with Inertia Drive:

Drive will not engage	Foreign material in Starter Drive	Remove obstruction.
	Damaged or worn Drive parts	Check Drive components and replace if necessary.

#### For Models with Pre-Engaged Drive:

Drive will not engage	No pressure to Drive Housing port	Check air supply.
	Internal Drive Housing ports blocked	Remove blockage.
	Fluid in drive unit components	Remove fluid.
	Damaged or worn Piston Assembly, O-rings or seals	Replace damaged or worn parts.
	O-rings and seals dry	Re-lube O-rings and seals.
Motor runs, Pinion engages, but does not rotate flywheel	Damaged or broken drive train	Disassemble drive train and replace worn or damaged parts.
Excessive butt engagement	Damaged Drive Pinion or flywheel	Inspect Drive Pinion and flywheel and replace if necessary.
	Damaged Starter Drive or components	Inspect Drive components and replace worn or damaged parts.
	Low air pressure	Check air supply.
	Wrong Drive Pinion	Replace with proper Drive Pinion.

## MAINTENANCE SECTION

### TROUBLESHOOTING GUIDE (Continued)

Oil blowing out of exhaust	Oil in air supply line	Inspect air line and remove source of oil.
	Splash Deflector Retaining Screw or pipe plug missing.	Install Splash Deflector Retaining Screw or pipe plug.
	Worn or damaged rotor seals or static O-rings	Replace static seals on outside of Motor or send Motor to Ingersoll-Rand to be rebuilt.
Oil leaking from Gear Case	Worn or damaged O-rings	Replace O-rings.
	Loose joints	Make sure that joints fit properly and that Starter Assembly Cap Screws are tightened to 60 ft-lb (81 Nm). Make sure that all seals and O-rings fit and seal properly at their perimeters. If they do not, replace with new seals and O-rings.
	Excessive high-speed operation	Operate according to recommendations.
	High number of start cycles	Replace worn components.
	Loose or leaking Pipe Plugs	Tighten or replace Pipe plugs using Ingeroll-Rand SMB-441 Pipe Sealant.
	Splash Deflector Retaining Screw or pipe plug missing	Tighten Splash Deflector Retaining Screw or replace pipe plug.
	Air or gas leakage	Loose joints
Excessive high-speed operation		Operate according to recommendations.
High number of start cycles		Replace worn components.
Loose or leaking Pipe Plugs		Tighten or replace pipe plugs.
Splash Deflector Retaining Screw loose or pipe plug missing		Tighten Splash Deflector Retaining Screw or replace pipe plug.

#### NOTICE

**SAVE THESE INSTRUCTIONS. DO NOT DESTROY.**

# INDEX

	<b>Page</b>
<b>A</b>	
Assembly of Starter .....	29–34
<b>B</b>	
Barring over the Engine .....	6
Bulkhead .....	28, 31
Clutch .....	28, 31
<b>D</b>	
Dimensions of Starter .....	7–9
Disassembly of Starter .....	25–29
Drive Gear .....	28–31
Drive Housing .....	27–28, 30–31
Drive Shaft .....	28, 30, 31
<b>E</b>	
Exhaust Kit	
Parts List and Drawing .....	24
Installation .....	24
<b>G</b>	
Gas operation .....	1
<b>H</b>	
Housing Exhaust Cover .....	25, 34
<b>I</b>	
Illustrations	
Inertia Drive .....	15, 16
Pre-Engaged Drive .....	15, 18
Installation of Starter .....	4–6
Intermediate Gear Case .....	26, 27, 33, 34
Intermediate Pinion .....	26, 27, 33
<b>L</b>	
Lubrication	
Gearing .....	25, 29–34
Motor .....	25, 34
<b>M</b>	
Motor Assembly .....	25, 33
Motor Housing .....	25, 33, 34
Mounting the Starter .....	5
<b>O</b>	
Orientation of Starter .....	4
<b>P</b>	
Parts Listing .....	17–18, 20–23
Piping Diagrams .....	10–13
Piston .....	28–29, 31
Planet Gear Frame Assembly .....	32
<b>S</b>	
Splash Deflector .....	26, 34
<b>T</b>	
Testing the Starter .....	35
Troubleshooting .....	36, 37

## **NOTES**

