

**INSTRUCTION MANUAL
For Jackhamers**

**Instruktionshåndbog
for Jackhamers**

**HANDLEIDING
voor boorhamers**

**MANUEL D'INSTRUCTIONS
Pour les marteaux-perforateurs**

**BETRIEBSANLEITUNG
für Bohrhämmer der Jackhamer™**

**ΟΔΗΓΟΣ ΧΡΗΣΕΩΣ
Για Περιστροφικές Αερόσφυρες**

**MANUALE DI ISTRUZIONI
per i Martelli perforatori Jackhamer™**


**INSTRUKSJONSHÅNDBOK For
Håndholdte bormaskiner**

**MANUAL DE INSTRUÇÕES
Para Martelos de Perfuração**

**MANUAL DE INSTRUCCIONES
MARTILLOS ROMPEDORES**

**INSTRUKTIONSBOK för
handhållna bergbormaskiner**

INGERSOLL-RAND®



Read this instruction manual before
operating this equipment.

Designed and Built by Ingersoll-Rand Company
Roanoke, Va. 24019-5198 U.S.A.



**Certified ISO-9001 (ANSI/ASQC Q91)
Certification No. QSR-80**



INSTRUCTION MANUAL

FOR

Jackhamers

INGERSOLL-RAND®

Designed and Built by Ingersoll-Rand Company
Roanoke, Va. 24019-5198 U.S.A.



Certified ISO-9001 (ANSI/ASQC Q91)
Certification No. QSR-80

Refer All Communications To The Nearest Address Listed On The Back Cover.

Warranty

Ingersoll-Rand, through its distributor, warrants that each item of equipment manufactured by it and delivered hereunder to the initial user to be free of defects in material and workmanship for a period of three (3) months from initial operation or six (6) months from the date of shipment to the initial user, whichever first occurs.

With respect to the following types of equipment, the warranty period enumerated will apply in lieu of the foregoing warranty period.

- A. Aftercoolers, Drill Mountings and Klemm Rotary Heads – The earlier of six (6) months from initial operation or nine (9) months from date of shipment to the initial user.
- B. Portable Compressors, Portable Generator Sets (GENSET), Portable Light Towers and Abrasive Blasting Equipment. The earlier of twelve (12) months from shipment to, or the accumulation of 2,000 hours of service by, the initial user.
- C. All Compressor Air Ends, GENSET Generators and Paving Breakers – The earlier of twenty-four (24) months from shipment to, or the accumulation of 4,000 hours of service by, the initial user. For Air Ends, the warranty against defects will include replacement of the complete Air End, provided the original Air End is returned assembled and unopened.
- D. Pavers, Milling Machines, Pedestrian Compactors (including baseplates, upright and walk behinds) and Rotary Drills – The earlier of (6) months from shipment to, or the accumulation of 1,000 hours of service by, the initial user.
- E. Jackhammers, Forklifts and Self-Propelled Compactors – The earlier of twelve (12) months from shipment to, or the accumulation of 1,000 hours of service by, the initial user.
- F. Downhole Drills – In lieu of the repair or replacement of defective parts Ingersoll-Rand may elect to

issue full or partial credit toward the purchase of a new part. The extent of credit issued will be determined by pro rating against the normal service life of the part in question.

- G. Spare Parts (excluding downhole drills) – Three (3) months from date of shipment.

Ingersoll-Rand will provide a new part or repaired part, at its election, in place of any part which is found upon its inspection to be defective in material and workmanship during the period prescribed above. Such part will be repaired or replaced without charge to the initial user during normal working hours at the place of business of an Ingersoll-Rand distributor authorized to sell the type equipment involved or other establishment authorized by Ingersoll-Rand. User must present proof of purchase and date at the time of exercising warranty.

This warranty does not apply to failures occurring as a result of abuse, misuse, negligent repairs, corrosion, erosion and normal wear and tear, alterations or modification made to the product without express written consent of Ingersoll-Rand; or failure to follow the recommended operating practices and maintenance procedures as provided in the product's operating and maintenance publications.

Accessories or equipment furnished by Ingersoll-Rand, but manufactured by others, including, but not limited to, engines, tires, batteries, engine electrical equipment, hydraulic transmissions, carriers, shall carry whatever warranty the manufacturers have conveyed to Ingersoll-Rand and which can be passed on to the initial user.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES (EXCEPT OF TITLE), EXPRESSED OR IMPLIED, AND THERE ARE NO WARRANTIES OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE.

Limitation of Liability

THE REMEDIES OF THE USER SET FORTH UNDER PROVISIONS OF WARRANTY OUTLINED ABOVE ARE EXCLUSIVE AND THE TOTAL LIABILITY OF INGERSOLL-RAND OR ITS DISTRIBUTORS WITH RESPECT TO THIS SALE OR THE EQUIPMENT AND SERVICE FURNISHED HEREUNDER, IN CONNECTION WITH THE PERFORMANCE OR BREACH THEREOF, OR FROM THE SALE, DELIVERY, INSTALLATION, REPAIR OR TECHNICAL DIRECTION COVERED BY OR FURNISHED UNDER THIS SALE. WHETHER BASED ON CONTRACT, WARRANTY, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE SHALL NOT EXCEED THE PURCHASE PRICE OF THE UNIT OF EQUIPMENT UPON WHICH SUCH LIABILITY IS BASED.

INGERSOLL-RAND, ITS SUPPLIER(S) AND ITS DISTRIBUTORS SHALL IN NO EVENT BE LIABLE TO THE USER, ANY SUCCESSORS IN INTEREST OR ANY BENE-

FICIARY OR ASSIGNEE RELATING TO THIS SALE FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, SPECIAL OR PUNITIVE DAMAGES ARISING OUT OF THIS SALE OR ANY BREACH THEREOF, OR ANY DEFECTS IN, OR FAILURE OF, OR MALFUNCTION OF THE EQUIPMENT UNDER THIS SALE WHETHER BASED UPON LOSS OF USE, LOST PROFITS OR REVENUE, INTEREST, LOST GOODWILL, WORK STOPPAGE, IMPAIRMENT OF OTHER GOODS, LOSS BY REASON OF SHUTDOWN OR NON-OPERATION, INCREASED EXPENSES OF OPERATION OF THE EQUIPMENT, COST OF PURCHASE OF REPLACEMENT POWER OR CLAIMS OF USERS OR CUSTOMERS OF THE USER FOR SERVICE INTERRUPTION WHETHER OR NOT SUCH LOSS OR DAMAGE IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE.

Title

Section



Read this instruction manual before operating this equipment.

INTRODUCTION 1

- Foreword
- Introduction
- Reference Material

SAFETY 2

- Introduction
- Safety Alert Symbol and Signal Words
- Safety First
- Safety Precautions

DESCRIPTION 3

- Description (JX35/JX35S)
- Description (JH40)
- Introduction
- Optional Equipment (JX35/JX35S)
- Optional Equipment (JH40)
- Standard Equipment

INSTALLATION AND OPERATION 4

- Air Requirements
 - Air Hose and Fittings
- Before Operation
- Bit Care
- Controls
- Drilling the Hole

(Continued)

Table of Contents (Con't.)

Title	Section
INSTALLATION AND OPERATION (CON'T.)	4
Cleaning the Hole	
Collaring the Hole	
Drill Steel Care	
Stuck Drill Steel	
Introduction	
Lubrication	
Lubricating Oil Specifications	
Methods of Lubrication	
Operation	
Operational Tips	
Water Requirements	
LUBRICATION SPECIFICATIONS	5
SPECIFICATIONS FOR JX35 & JX35S	6
Jackhammer Specifications	
Vibration and Noise Data	
SPECIFICATIONS FOR JH40	6.1
Jackhammer Specifications	
Vibration and Noise Data	

Alphabetical Index

<u>Title</u>	<u>Page No.</u>
Foreword	1
Introduction	1
Reference Material	1

1. FOREWORD.

The contents of this manual are considered to be proprietary and confidential to Ingersoll-Rand® and should not be reproduced for distribution without the prior written consent of Ingersoll-Rand® Company.

Nothing contained in this document is intended to extend any promise, warranty or representation, expressed or implied, regarding the products described herein. Any such warranties or other terms and conditions of sale of products shall be in accordance with Ingersoll-Rand's standard terms and conditions of sale for such products, which are available upon request.

Ingersoll-Rand® Company reserves the right to make changes or add improvements to products without notice and without incurring any obligation to make such changes or add such improvements to products sold previously.

All equipment, regardless of how well built, requires a certain amount of attention. The purpose of this publication is to acquaint an operator with the function and operation of the components to obtain maximum performance and trouble free service from the jackhammer.

Before using the jackhammer, these instructions should be carefully read to obtain a thorough knowledge of the duties to be performed. Take pride in the jackhammer, keep it clean; and in good mechanical condition.

2. INTRODUCTION.

This instruction manual contains information on safety, installation, operation, description, and specifications for the Jackhammer Family.

3. REFERENCE MATERIAL.

The reference materials required to operate and/or maintain the jackhammer are listed in Table 1.

Table 1. Reference Material

Manual No.	Title of Manual
PL6113	Parts Lists For "PROMAXX™" Jackhammer Models JX35 & JX35S.
PS-5350.84	Parts List For Jackhammer Model JH40.

NOTICE

SAVE THESE INSTRUCTIONS. DO NOT DESTROY.

NOTICE

All information, illustrations, and specifications in this manual are based on the latest information available at the time of publication.

Product improvement is a continuing goal at Ingersoll-Rand®. Design and specifications are subject to change without notice or obligation.

The use of repair parts other than those included within the Ingersoll-Rand® approved parts list may create hazardous conditions over which Ingersoll-Rand® Company has no control. Therefore Ingersoll-Rand® Company cannot be held responsible for equipment in which non-approved repair parts are installed.

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Alphabetical Index

<u>Title</u>	<u>Page No.</u>
Introduction	1
Safety Alert Symbol and Signal Words	1
Safety First	1
Safety Precautions	2

1. INTRODUCTION.

This section contains important safety information for the Jackhamer Family.

▲ DANGER

DANGER IS USED TO INDICATE THE PRESENCE OF A HAZARD WHICH WILL CAUSE SEVERE PERSONAL INJURY OR DEATH IF THE WARNING IS IGNORED.

2. SAFETY FIRST.

SAFETY FIRST is the primary concern for the protection of both, personnel and the jackhamer during any phase of operation. All personnel must thoroughly understand all safety precautions before operating or doing any work on the jackhamer.

▲ WARNING

WARNING IS USED TO INDICATE THE PRESENCE OF A HAZARD WHICH CAN CAUSE SEVERE INJURY OR DEATH IF THE WARNING IS IGNORED.

3. SAFETY ALERT SYMBOL AND SIGNAL WORDS.

▲ – This is the Safety Alert Symbol. When you see this symbol in this instruction manual, be alert to the presence of a hazard.

▲ CAUTION

CAUTION IS USED TO INDICATE THE PRESENCE OF A HAZARD WHICH WILL OR CAN CAUSE PERSONAL INJURY, OR PROPERTY DAMAGE IF THE WARNING IS IGNORED.

NOTICE

Notice is used to notify people of installation, operation, or maintenance information which is important but not hazard related.

All personnel must understand the **DANGER, WARNING, CAUTION,** and **NOTICE** used throughout the text of this instruction manual. The **DANGER, WARNING, CAUTION,** and **NOTICE** are defined as follows:


By understanding what **DANGER, WARNING, CAUTION,** and **NOTICE** mean; and using good judgment and common sense; all


personnel can avoid injuring themselves and/or damaging the jackhammer.


4. SAFETY PRECAUTIONS.


The Safety Precautions listed are intended to make all personnel aware of the hazards


while working on or near a jackhammer. All personnel must use common sense and a good working practice while operating and maintaining the jackhammer. The safety precautions listed are of a general nature and cannot cover every possible situation:


	⚠ WARNING
	Do not start the jackhammer while it is lying on the ground.


	⚠ WARNING
	Keep your hands off the throttle lever until it is time to start jackhammer operation.


	⚠ CAUTION
	Always wear gloves when operating this tool.


	⚠ WARNING
	Keep legs and feet clear of the jackhammer tool to prevent injury if the tool breaks.


	⚠ WARNING
	Always wear safety shoes when operating this tool.


	⚠ WARNING
	Do not ride the jackhammer with one leg over the handle.


	⚠ CAUTION
	Always wear nose mask when operating this tool.


	⚠ WARNING
	Operate at 90-100 psig (6.2-6.9 bar) Maximum air pressure.


	⚠ WARNING
	Always wear approved hard hat when operating this tool.


	⚠ WARNING
	Always turn off the air supply and bleed and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool.


	⚠ CAUTION
	Always wear eye protection when operating this tool.


	⚠ WARNING
	Do not operate the jackhammer without a tool locked in the fronthead. Hold the tool firmly against the work.


	⚠ CAUTION
	Always wear hearing protection when operating this tool.


	⚠ WARNING
	Know what is underneath the material you are about to break. Be alert for any buried water, gas, sewer, telephone, or electric lines.

	⚠ WARNING
	Never rest the jackhammer on your foot.

	⚠ WARNING
	Do not use damaged, frayed or deteriorated air hose and fittings.

	⚠ WARNING
	Always keep both hands on the handles while operating the jackhammer.

	⚠ WARNING
	Keep body stance balanced and firm. Do not overreach when operating this tool.

	⚠ WARNING
	Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.

Alphabetical Index

<u>Title</u>	<u>Page No.</u>
Description (JX35/JX35S)	1
Description (JH40)	1
Introduction	1
Optional Equipment (JX35/JX35S)	1
Optional Equipment (JH40)	2
Standard Equipment	1

1. INTRODUCTION.

This section provides a description of the standard and optional equipment for the Jackhamer Family.

2. DESCRIPTION. (JX35/JX35S)

The jackhamer is a hand-held, lightweight, pneumatic powered rock drill with a ratchet-less rotation assembly and a reliable air distributor which replaces the traditional valving system. The jackhamer is designed for dry or wet drilling, and can easily be converted using the available wet option kit. (Refer to the parts list for the part number of available kits.)

The jackhamer is capable of drilling 1-1/4 to 1-1/2 in. (32 to 38mm) diameter holes up to 10 Ft. (3m) deep in medium to hard rock. It is particularly suitable for construction work, medium industrial maintenance work, and for general utility work in quarries and mines.

The standard jackhamer with an exhaust deflector is a JX35. The standard jackhamer with a muffler assembly is a JX35S.

3. DESCRIPTION. (JH40)

The jackhamer is a hand-held, medium-weight, muffled, pneumatic powered rock drill

with automatic rifle bar rotation, and exceptional hole cleaning ability. It is designed for air blowing or wet drilling; incorporates control of "hole blowing" in the throttle lever for one-lever, simplified control; and is equipped with a closed-center, T-Handle for general ground level work.

The jackhamer is capable of drilling 2 in. (50.8mm) diameter holes up to 18 ft. (5.5m) deep in medium to hard rock. It is particularly suitable for construction work, medium industrial maintenance work, and for general utility work in quarries and mines.

4. STANDARD EQUIPMENT.

Each jackhamer is a complete unit ready to be put into service with proper lubrication.

Refer to Section 6 for fronthead chuck sizes.

5. OPTIONAL EQUIPMENT. (JX35/JX35S)

The jackhamer can also be furnished with the following options:

- a. **Chucks** – Refer to Section 6.
- b. **Wet Option** – Used for dustless, wet drilling where minimum air consumption is required.

c. **Muffler Assembly** – Used to reduce jackhammer noise without hendering performance.

d. **Flex Handle** – This handle is used in place of the standard handle to reduce the amount of vibration that the operator encounters.

e. **Open Center Grip Handle** – This handle is mounted to the backhead end of the jackhammer and allows for ease of trans-

portation as well as an optional operator handle.

6. OPTIONAL EQUIPMENT. (JH40)

a. **Chucks** – Refer to Section 6.1.

b. **Beavertail Type Steel Holder** – Used in place of the standard yoke type steel holder. This holder is designed for foot operation.

c. **Wet Option** – Used for dustless, wet drilling where minimum air consumption is required.

Alphabetical Index

<u>Title</u>	<u>Page No.</u>
Air Requirements	1
Air Hose and Fittings	1
Before Operation	2
Bit Care	6
Controls (JX35/JX35S)	3
Controls (JH40)	3
Drilling the Hole	4
Cleaning the Hole	5
Collaring the Hole	5
Drill Steel Care	5
Stuck Drill Steel	5
Introduction	1
Lubrication	6
Lubricating Oil Specifications	7
Methods of Lubrication	6
Operation	3
Operational Tips	4
Water Requirements	2

1. INTRODUCTION.

This section provides installation and operation requirements for the Jackhamer Family.

2. AIR REQUIREMENTS.

An air compressor of sufficient capacity is needed to provide the necessary volume of air at the most efficient operating pressure to ensure effective and economical operation of the jackhamer. (Refer to Section 6 for specifications.)

The air requirements represent air pressures at the jackhamer inlet and not at the compressor. There is always a certain amount of pressure drop between the compressor and the jackhamer; only the pressure and volume at the tool is effective in doing work. If the hose

is relatively short and in good condition, the pressure drop between the compressor (or air receiver) and the jackhamer should not exceed 15 percent of the initial pressure.

Low or inadequate air pressure at the jackhamer is costly and wasteful, and an insufficient volume of air will not allow it to operate efficiently.

3. AIR HOSE AND FITTINGS.

Quality hose designed especially for rock drill service should be used. It should be constructed with an outer covering that resists abrasive wear, an oil-resistant inner tube and should be able to withstand the heat of the compressed air. It should have a working

pressure safety factor of at least 4 to 1 in relation to burst.

The hose fittings should be kept as tight as possible and should be in good condition. Elimination of leakage involves making the air system tight and then keeping it tight. Air losses through bad connections and worn hose can often reach 10 to 20 percent of the total air compressed. Refer to Section 6 for the size of air hose required.

4. WATER REQUIREMENTS.

The water pressure for wet style machines should be maintained at 10 psi (.69 bar) less than the air pressure. If water pressure exceeds air pressure, water will be forced into the machine and will carry away the lubricant. The water pressure should never fall below 40 psi (2.8 bar).

5. BEFORE OPERATION.

- a. Determine the method of lubrication to be used. Refer to Paragraph 16.
- b. Blow out the main air supply hose to get rid of moisture, rubber particles, and dirt.
- c. When using new air hose, blow lubricated air through the hose to completely coat the inside with oil. This may take 10 to 15 minutes.

▲WARNING

COMPRESSED AIR IS DANGEROUS. WHEN BLOWING OUT AN AIR HOSE, HOLD IT FIRMLY, AND POINT IT AWAY FROM PERSONNEL AND EQUIPMENT. NEVER BLOW YOUR CLOTHES FREE OF DUST WITH COMPRESSED AIR.

- d. An air line filter can be installed in the main air supply line to keep dirt from enter-

ing the jackhammer. Air line filters are an accessory item and must be specially ordered.

- e. Before connecting the air hose to the air connection, pour 2 to 3 oz. (.06 to .09 L) of rock drill oil into the inlet.
- f. Connect the leader hose to the air connection on the jackhammer.

▲WARNING

BE SURE ALL HOSE CONNECTIONS ARE TIGHT. A LOOSE HOSE NOT ONLY CAUSES LEAKS, BUT CAN COME COMPLETELY OFF THE JACKHAMER, WHIP AROUND, AND INJURE PERSONNEL IN THE AREA. ATTACH SAFETY CABLES TO ALL HOSES TO PREVENT INJURY IF A HOSE IS ACCIDENTALLY BROKEN.

- g. Open the latch by pushing the lever down.
- h. Insert the shank end of the drill steel in the fronthead, and swing the latch up to lock the tool in the jackhammer. Refer to Section 6 for the correct jackhammer shank size.

▲CAUTION

MAKE SURE THE TOOL IS THE CORRECT SIZE FOR THE FRONTHEAD: 7/8 OR 1 IN. HEX. (22 OR 25 MM HEX.) DEPENDING ON THE CHUCK. DON'T USE A JACKHAMER TOOL THAT IS WORN; IT WON'T DO AN EFFECTIVE JOB AND WILL CAUSE UNNECESSARY WEAR TO THE JACKHAMER.

- i. Check the drill steel. The drill steel center hole should be open, and shanks should be flat and square – not chipped or

rounded off. Be sure the shank of the drill steel is the proper length.

j. Be certain bits are properly ground. Dull bits are hard on the jackhammer and on the operator.

6. CONTROLS. (JX35/JX35S)

The jackhammer is controlled by a valve with a variable setting lever. The jackhammer also has an added blow air lever for secondary blow air to the drill steel, independent of the cycle or the main throttle. This blow air lever allows an extra 40 to 50 scfm (1.13 to 1.42 m³/min.) of blow air.

7. CONTROLS. (JH40)

The jackhammer is controlled by moving the lever as shown in Figure 1.




Figure 1. Operating Lever Postions

8. OPERATION.

▲ DANGER

KNOW WHAT IS UNDERNEATH THE MATERIAL YOU ARE ABOUT TO DRILL. BE ALERT FOR ANY EXISTING WATER, GAS, ELECTRICITY, SEWER, OR TELEPHONE LINES.

ALWAYS KEEP BOTH HANDS ON THE HANDLE WHILE OPERATING THE JACKHAMER.

THE OPERATOR MUST KEEP HIS LEGS AND FEET CLEAR OF THE DRILL STEEL TO PREVENT INJURY IF THE TOOL BREAKS. WHEN A TOOL BREAKS, THE JACKHAMER (WITH A PIECE OF BROKEN TOOL PROJECTING FROM THE FRONTHEAD) WILL SUDDENLY DROP TO THE GROUND.

THE OPERATOR WILL BE SERIOUSLY INJURED IF THE TOOL BREAKS WHILE HE IS RIDING THE JACKHAMER WITH ONE LEG OVER THE HANDLE.

▲ CAUTION

DO NOT OPERATE THE JACKHAMER WITHOUT A DRILL STEEL SHANK IN THE FRONTHEAD CHUCK. HOLD THE TOOL FIRMLY AGAINST THE WORK.

RIDING THE JACKHAMER HANDLE CREATES EXCESSIVE PRESSURE ON ONE SIDE OF THE JACKHAMER, THROWING IT OUT OF ALIGNMENT AND CAUSING UNNECESSARY WEAR ON INTERNAL PARTS.

NOTICE

Improper lubrication will prevent proper indexing of the rotation and ultimately reduce the rotation speed. Prolonged usage of the jackhammer without proper lubrication will cause damage to the unit. Refer to Paragraph 16 **"LUBRICATION"** for proper recommendations.

- a. Immediately after starting the jackhammer, check for the presence of oil mist at the exhaust port and on the drill steel shank. This is the only assurance that oil is traveling all the way through the jackhammer. When checking the jackhammer for proper lubrication, always put the tool against the work.
- b. Heating is not unusual in a new jackhammer and it should be checked carefully during the first few hours of operation. In most cases, heating will be localized around the piston stem bearing at the front end of the cylinder. Test this area frequently with the hand. As long as the hand can be held on the part comfortably, it is safe to continue drilling. When the heat is great enough to cause discomfort, stop the jackhammer and let it cool. Since lack of oil can cause excessive heating, check again to see that the steel shank is oily.
- c. If exhaust freeze-up occurs, add anti-freeze lubricant directly through the air inlet connection. Use "KILFROST" anti-freeze lubricant or equivalent.

9. OPERATIONAL TIPS.

For maximum operating efficiency, observe the following suggestions:

- a. Never strike the jackhammer housing with a blunt object. The housing may be broken or damaged.
- b. Never attempt major maintenance of the jackhammer on the job; take it to a repair shop.
- c. Never drag the jackhammer along the ground; the air ports in the exhaust may fill with dirt.
- d. Always blow out the air supply hose before connecting it to the jackhammer to remove any dirt inside the hose.
- e. Always be sure the jackhammer is well lubricated. Adjust the air line lubricator so that the drill steel shank always shows an oil film. There should be a fine mist of oil coming out of the exhaust port.
- f. Always keep rock drill oil in a sealed container so that it doesn't get contaminated with dust or dirt.
- g. Do not operate the jackhammer when the tool is not against the work.
- h. In extremely cold weather, keep drill steel tools wrapped in burlap or cloth until just before you use them. At 0°F (-17.8°C) a hardened steel tool loses about 80% of its normal shock resistance.
- i. Always keep plastic caps or plugs in all ports when the jackhammer is not in service.

10. DRILLING THE HOLE.

- a. Hold the jackhammer with both hands, spread feet apart, and apply a firm steady pressure.
- b. The correct amount of pressure for maximum drilling efficiency can be gained only through experience, but generally the correct pressure is usually recognizable by the rhythmic sound of the exhaust and the free rotation of the drill steel.

- c. Insufficient pressure will cause the jackhammer to bounce and may crack carbide inserts.
- d. Too much pressure will slow down the jackhammer and may result in stuck drill steel.
- e. Keep the jackhammer, drill steel and hole aligned at all times.

11. COLLARING THE HOLE.

- a. When starting the hole, hold the jackhammer firmly against the work and use a steel short enough so that the jackhammer can be handled comfortably.
- b. Open the throttle gradually and drill at half throttle or less.
- c. Make sure the bit is through the overburden and about 2 in. (51mm) deep in the rock before using full throttle.
- d. The jackhammer should be kept at right angles to the work, until the hole is collared, then repositioned for angled drilling.

12. CLEANING THE HOLE.

Always keep the hole clean and free of cuttings by blowing the hole frequently or using plenty of water with wet machines. The bit must work on fresh rock. If the bit churns in its own cuttings, drilling speed is reduced, and the possibility of the drill steel becoming stuck is increased.

▲ CAUTION

WHEN THE DRILL STEEL IS NOT PENETRATING THE ROCK FREELY, SEVERE LOADS BUILD UP ON THE CLUTCH ASSEMBLY CAUSING OVERHEATING. THIS LEADS TO MAJOR DAMAGE OF THESE PARTS AND EARLY BREAKDOWN.

13. STUCK DRILL STEEL.

When drilling moist formations there is often a tendency for cuttings to pack in the hole immediately behind the bit, forming a “mud collar”. Through action of the rotating bit, wet cuttings pack solidly against the wall of the holes; and can cause a stuck drill steel.

a. To remove a stuck drill steel:

1. Remove the jackhammer from the stuck drill steel and make an attempt to loosen the steel with a wrench.
2. Do not try to pull a stuck drill steel with the jackhammer for more than a few minutes. Heavy thrust loads can damage front end parts.

b. To prevent a stuck drill steel:

1. Blow the hole often.
2. Keep the jackhammer working against fresh rock.
3. Raise the bit from the bottom of the hole, and blow the hole clean before removing drill steel and bit.

14. DRILL STEEL CARE.

a. It is very important that the threads of the drill steel be properly lubricated and cared for at all times. Steels having stripped threads, cracks, or severe galling must not be used. Also, care should be taken while drilling not to bend steel or gall threads due to misuse.

b. Bent steel produces unnecessary stresses and accelerates wear on front-head components. Bent steel and severe thread galling can be avoided if the following steps are taken:

1. Be sure that the steel is bottomed in the bit.
2. All the threads must be in good condition and well lubricated.

3. Always drill with a sharp bit. Dull bits cause excessive pounding and unnecessary stresses on all threads and jackhammer parts.

4. Never approach the rock with the jackhammer running. Position carefully and collar the hole at reduced throttle. Once the bit is collared in rock, full throttle may be applied.

5. Always keep the jackhammer against the work. Insufficient feed pressure will cause the bit to become loose on the steel and will damage the threads and cause inserts to tear loose.

6. Always maintain alignment between the jackhammer and hole.

7. Never retract the jackhammer at full throttle. Use half throttle.

15. BIT CARE.

For long bit life, the instructions as listed in Paragraph 14 covering "Drill Steel Care" must also be applied to the bit. In addition, the following steps must be taken:

- a. Never allow the bit to become plugged with loose cuttings. Blow the hole continuously.
- b. Never force or broach the bit into a hole.
- c. Remove the bit from the steel with a bit wrench. Never strike the bit with a hammer.
- d. Never run a dull bit.

16. LUBRICATION.

17. METHODS OF LUBRICATION.

Proper lubrication is the most important single factor responsible for the service life of the pneumatic jackhammer. A jackhammer can be severely damaged during the first few minutes of operation if it is not properly lubricated.

The lubrication method depends on the actual operating conditions and customer preference.

a. **For JX35/JX35S** – The jackhammer is equipped with an integral lubricator which holds approximately 15cc of lubricant. The lubricator injects lubricant into the piston stem bearing area. Injection volumes will vary depending on the duty cycle of the jackhammer. Typically, the consumption rate is approximately 1cc per 10 – 15 minutes of operation. For more continuous drilling operation an inline lubricator is recommended.

b. For intermittent operation with an air supply hose no longer than 50 ft. (15 m), a compressor-mounted lubricator may be used.

c. For continuous operation during an eight hour shift, an Ingersoll-Rand® air line lubricator, or other constant-feed air line lubricator, should be installed in the air-supply line about 11.5 ft. (3.5 m) from the jackhammer. The lubricator should have a capacity of least 1 U.S. pint (0.47 liters). To adjust an air line lubricator initially:

1. Turn the lubricator needle valve clockwise until it is completely closed, and then turn the valve counter-clockwise about 3/4 of a turn off its seat.

2. Almost immediately after starting the jackhammer, check for presence of oil at the exhaust ports and on the drill steel shank. When checking the jackhammer for proper lubrication, always put the tool against the work.

3. Fine-tune the lubricator needle valve to provide a light film of oil on the jackhammer tool and a fine oil mist coming from the exhaust ports. If there is blue smoke coming from the exhaust port or oil running down the tool, the jackhammer

is getting too much oil. Adjust the lubricator for proper rate of feed.

d. Regardless of the method of lubrication, the lubricating oil reservoir must be filled with the correct grade of rock drill oil as frequently as is necessary to prevent any possibility of the jackhammer running dry.

e. Every effort must be made to avoid oil contamination from dirt or other impurities. Oil should be kept in covered containers and stored in an area that is relatively dust free.

f. Before filling the air line lubricator, the area around the filler plug should be wiped clean.

18. LUBRICATING OIL SPECIFICATIONS.

Ingersoll–Rand® offers a complete line of rock drill oil formulated to provide maximum performance in all types of rock drill equipment. These oils exceed the oil specifications listed in Section 5, Table 1.

⚠ CAUTION

NEVER ALLOW THE LUBRICATOR TO BECOME EMPTY AS THE PARTS WILL BE DAMAGED IF THE JACKHAMER IS OPERATED WITHOUT LUBRICATION.

Use Section 5, Table 2 for selecting the correct viscosity grade to meet your requirements and Section 5, Table 3 for selecting the correct rock drill oil part number.

**LUBRICATION
SPECIFICATIONS**

Table 1. Rock Drill Oil Specifications

Characteristic	Test Procedure	Below 20°F (-7°C)	20°F to 90°F (-7°C to 32°C)	Above 90°F (32°C)
Viscosity:				
SUS at 100°F (38°C)	ASTM-D2161	175 min.	450 min.	750 min.
SUS at 210°F (99°C)	ASTM-D2161	46 min.	65 min.	85 min.
cST at 104°F (40°C)	ASTM-D445	37 min.	105 min.	160 min.
cST at 212°F (100°C)	ASTM-D445	6 min.	11 min.	16 min.
Pour Point, °F (°C) max.	ASTM-D97	-10°F (-23°C)	-10°F (-23°C)	0°F (-18°C)
Flash Point, °F (°C) min.	ASTM-D92	370°F (188°C)	400°F (204°C)	450°F (232°C)
Viscosity Index, min.	ASTM-D2270	90	90	90
Steam Emulsion No. min.	ASTM-1935-65	1200	1200	1200
Consistency	Stringy	Stringy	Stringy
Falex Load Test lbs (kg) [min]	ASTM-D2670	2000 lbs (907 kg)	2000 lbs (907 kg)	2000 lbs (907 kg)
Timken E.P. Test lbs (kg) [min]	ASTM-D2782	30 lbs (14 kg)	30 lbs (14 kg)	30 lbs (14 kg)

Table 2. Selection Chart

Typical Operating Conditions	20°F to 90°F (-7°C to 32°C)	Above 90°F (32°C)
90-100 psi (6.2 to 6.9 bar)	Light	Medium

Table 3. Ingersoll-Rand Rock Drill Oil Part Numbers

Grade	1 Gallon (3.8 Liter)	5 Gallon (18.9 Liter)	55 Gallon (208 Liter)
Light	51378701	51378727	51378743
Medium	51378693	51378719	51378735

Alphabetical Index

<u>Title</u>	<u>Page No.</u>
Jackhamer Specifications	1
Vibration and Noise Data	1

1. VIBRATION AND NOISE DATA.

NOTICE

In compliance with **EC Directive 84/537/EEC on Noise** at the workplace, the following data is supplied:

The following are average sound power (Lw) levels:

JX35	113 dB(A)
JX35S	110 dB(A)

NOTICE

In compliance with **Weighted RMS Acceleration ISO 8662, Part 5 on Vibration**, the following data is supplied:

JX35/JX35S	30.2 m/s ²
------------	-----------------------

2. JACKHAMER SPECIFICATIONS.

a. Net Weight (less tool):

JX35	32 lbs	14.5 kg
JX35S	34 lbs	15.4 kg

b. Shipping Weight (less tool):

JX35	39 lbs	17.7 kg
JX35S	41 lbs	18.6 kg

c. Overall Length (less tool):

22 in.	559 mm
--------	--------

d. Bore of Cylinder:

2.38 in.	60.3 mm
----------	---------

e. Working Stroke:

1.50 in.	38 mm
----------	-------

f. Blows Per Minute:

2400 bpm

g. Recommended Air Supply:

90 -100 psi (6.2 - 6.9 bar) at jackhamer inlet.

h. Air Inlet Size:

3/4 NPT

i. Water Inlet Size:

3/4 NPT

j. Size Air Hose Recommended:

3/4 in.	19 mm
---------	-------

k. Air Consumption @ 90 psi (6.2 bar):

75 ft ³ /min	2.12 m ³ /min
-------------------------	--------------------------

I. Size of Standard Chuck:

7/8 in. Hex. x 4-1/4 in. long
(22mm Hex. x 108mm long)

m. Size of Optional Chuck:

7/8 in. Hex. x 3-1/4 in. long
(22mm Hex. x 83mm long)
1 in. Hex. x 4-1/4 in. long
(25mm Hex. x 108mm long)

Alphabetical Index

<u>Title</u>	<u>Page No.</u>
Jackhamer Specifications	1
Vibration and Noise Data	1

1. VIBRATION AND NOISE DATA.

NOTICE

In compliance with **EC Directive 84/537/EEC on Noise** at the workplace, the following data is supplied:

The following are average sound power (Lw) levels:

112 dB(A)

NOTICE

In compliance with **Weighted RMS Acceleration ISO 8662, Part 5 on Vibration**, the following data is supplied:

18.2 m/s²

2. JACKHAMER SPECIFICATIONS.

a. **Net Weight (less tool):**

(Yoke Style) 58 lbs 26.3 kg

(Beavertail Style) 61 lbs 27.7 kg

b. **Shipping Weight (less tool):**

(Yoke Style) 60 lbs 27.2 kg

(Beavertail Style) 63 lbs 28.6 kg

c. **Overall Length (less tool):**

22-1/2 in. 572 mm

d. **Bore of Cylinder:**

2-1/2 in. 63.5 mm

e. **Working Stroke:**

2-5/8 in. 66.7 mm

f. **Standard Rotation:**

180 RPM

g. **Recommended Air Supply:**

90 -100 psi (6.2 - 6.9 bar) at inlet

h. **Air Inlet Size:**

3/4 NPT

i. **Water Inlet Size:**

3/4 NPT

j. **Size Air Hose Recommended:**

3/4 in. 19 mm

k. **Air Consumption @ 90 psi (6.2 bar):**

Blower Style 120 ft³/min 3.40 m³/min

Wet Style 105 ft³/min 2.97 m³/min

I. Size of Standard Chuck:

1 in. Hex. x 4-1/4 in. long
(25.4 mm Hex. x 108 mm long)

m. Size of Optional Chucks:

7/8 in. Hex. x 4-1/4 in. long
(22 mm Hex. x 108 mm long)
7/8 in. Hex. x 3-1/4 in. long
(22 mm Hex. x 83 mm long)

Worldwide Ingersoll-Rand sales offices

U.S.A.

U.S. C&M OFFICES

Bethlehem, PA 18017-2293
1495 Valley Center Pkwy.
215/882-8800

Boston, MA 02125
33 Locust Street
617/288-8988

Casper, WY 82601
3273 N. I-25 Frontage Road
307/237-4259

Denver, CO 80207
5805 East 39th Ave.
303/399-1580

East Hanover, NJ 07936
98 Route #10
201/887-1212

Elkridge, MD 21227
5681 Main Street
410/796-3200

Gray, TN 37615
Suncrest Drive
615/477-3114

Houston, TX 77001
2210 McAllister
713/681-9221

Knoxville, TN 37922 (C&M)
112 Glenleigh Court
Suite #1
615/966-8800

Knoxville, TN 37912 (IRES)
4726 Clinton Hwy.
615/525-0404

Milwaukee, WI 53225
12311 West Silver Springs Dr.
414/461-7810

Nashville, TN 37229
310 S. Second St.
615/254-1811

New Castle, DE 19702
91 Christiana Road
302/324-9040

New Cumberland, PA 17070
Exit 15 on Rt. 83
4 miles south of Harrisburg
717/938-1441

New England
300 Turnpike Rd. -Route 9
Southboro, MA 01772
508/481-1350

Philadelphia
Route 309
Montgomeryville, PA 18936
215/655-9990

Phoenix, AZ 85007
820 N. 17th Ave.
602/258-6493

Pico Rivera, CA 90660
6211 Paramount Blvd.
310/946-3801

Portland, OR 97214
240 South East Clay Street
503/232-0151

Sacramento, CA 95836
1851 Bell Avenue
916/641-1994

San Leandro, CA 94577
1944 Marina Blvd.
510/357-9131

Scranton, PA 18505
605 Davis St.
717/346-3885

Seattle, WA 98168
11222 E. Marginal Way, S.
206/762-7400

U.S. C&M FACTORIES ROCK DRILLS

Rotary blasthole deephole, monitoring rigs

Ingersoll-Rand Co.
Rotary Drill Division
2100 N. First St.
Garland, TX 75040
214/495-8181

Downhole Drills and Bits; Pneumatic and Hydraulic Crawler Drills; Anchor Drills; Breakers and Jackhammers™

Ingersoll-Rand Co.
Rock Drill Division
7500 Shadwell Drive
Roanoke, VA 24019-5198
703/362-3321

COMPACTORS, PAVING MILLERS, ASPHALT PAVERS AND FORKLIFTS

Ingersoll-Rand Co.
Road Machinery Division
Ingersoll Drive
Shippensburg, PA 17257
717/532-9181

UNDERGROUND EQUIPMENT

Roadheaders; drill jumbos, diesel- powered production and utility equip- ment (scoops, haul dumps, etc.)

Contact Rock Drill Division
Roanoke, VA

Split Set rock stabilizers

Simmons-Rand Co.
Split Set Division
Suite 300
100 Thanet Circle
Princeton, NJ 08540-3662
609/921-8688

AIR COMPRESSORS

Portable compressors, Generator Sets and Light Plants

Ingersoll-Rand Co.
Portable Compressor Division
P.O. Box 868
501 Sanford Ave.
Mocksville, NC 27028
704/634-3561

Small Compressor Plant
Ingersoll-Rand Co.
101 Industrial Drive
Campbellsville, KY 42718
502/465-3511

Centrifugal compressors (Centac)

Ingersoll-Rand Co.
Centrifugal Compressor Division
Route 45
Mayfield, KY 42066
502/247-8640

Reciprocating and rotary-screw compressors

Ingersoll-Rand Co.
Air Compressor Group
P.O. Box 1600
800A Beaty St.
Davidson, NC 28036
704/892-7100

PUMPS

Engineered centrifugal pumps

Ingersoll-Rand Co.
P.O. Box 486
Phillipsburg, NJ 08865
201/859-7000

Reciprocating pumps and standard centrifugal pumps

Ingersoll-Rand Co.
P.O. Box 656
Allentown, PA 18105
215/433-6411

Vertical turbine pumps

Ingersoll-Rand Co.
Vertical Turbine Pump Division
Hastings, NE 68901
402/463-1306

TOOLS, WINCHES

Ingersoll-Rand Co.
Power Tool Division
P.O. Box 1776
Liberty Corner, NJ 07938
201/647-6000

LIQUID/SOLID SEPARATORS

Ingersoll-Rand Co.
Impco Division
150 Burke St.
Nashua, NH 03061
603/882-2711

CANADA

Surface and underground equipment Tools and industrial equipment

Ingersoll-Rand Canada Inc.
2360 Millrace Court
Mississauga, Ontario L5N1W2
(1)416/858-8480

Ingersoll-Rand Canada, Inc.
2250 Hymus Blvd
Dorval, Quebec H9P1J9
(1) 514/683-9157

MEXICO

All equipment

Ingersoll-Rand, S.A. de C.V.
Boulevard Centro
Industrial #11
Fracc. Industrial
Puente de Vigas
Tlalnepantla,
54090 Edo. de Mexico
Mexico
52 (5) 390-40-21
52 (5) 390-24-11

SOUTH AMERICA

USA, Miami, Florida
1 (305) 599-0500

Chile - Santiago
56 (2) 41-198

Colombia - Bogota
57 (1) 219-1406/1460

Venezuela - Caracas
58 (2) 239-9369

EUROPE

Austria - Vienna
43 (222) 83-05-250

Belgium - Brussels
32 (02) 216-99-95

France - Trappes
33 (3) 050-61-10

Germany - Ratingen
49 (2102) 48090

*Italy - Milano
39 (02) 950561

Netherlands - Zoeterwoude
31 (071) 452200

Norway - Oslo
47 (02) 39-15-26

Spain - Madrid
34 (9) 1-671-07-00

Sweden - Spanga
46 (08) 750-59-20

United Kingdom - London
44 (01) 584-5070

*Also for Bulgaria, Czechoslovakia,
Hungary, Poland, Rumania, USSR,
Yugoslavia.

AFRICA-MIDDLE EAST

Egypt - Cairo
(02)341-5190

South Africa - Alrode
27 (011) 864-3930

ASIA-PACIFIC

Australia - Melbourne
61-(3) 794-1611

Hong Kong
852 (5) 270183

India - Bombay
91 (22) 4936765

Japan - Tokyo
81 (3) 403-08417

Korea - Seoul
82 (2) 776-2541

New Zealand - Auckland
64 (9) 885096

Philippines - Manila
63 (2) 89-85-06/08

Singapore
(65) 8611555