




## OPERATION AND MAINTENANCE MANUAL FOR MODELS PDA075, PDA125, PDA200 AND PDA30 AIR-OPERATED DIAPHRAGM PUMPS

### NOTICE

The PDA Series of Diaphragm pumps are designed as suction and submersible pumps. They are especially recommended for those applications involving the pumping of either suspended particulate (wet or dry), heavily sedimented or viscous solutions, or those solutions containing solids up to the individual capacity of the pump.

Ingersoll-Rand is not responsible for customer modification of pumps for applications on which Ingersoll-Rand was not consulted.



### ⚠ WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.  
READ THIS MANUAL BEFORE OPERATING PUMP.**

**IT IS THE RESPONSIBILITY OF THE EMPLOYER TO PLACE THE INFORMATION  
IN THIS MANUAL INTO THE HANDS OF THE OPERATOR.**

**FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.**

#### PLACING PUMPS IN SERVICE

- Always operate, inspect and maintain this pump in accordance with American Standards Institute Safety Code for Portable Air Tools (ANSI B186.1)
- For safety, top performance, and maximum durability of parts, operate this pump up to 110 psig (7.58 bar/758 kPa) maximum air pressure. Do not exceed 125 psig (8.61 bar/861 kPa) air pressure. Always use the proper size air hose, suction hose, and discharge hose as shown in Table 1.
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this pump, or before performing any maintenance on this pump.
- Do not use damaged, frayed or deteriorated air hoses and fittings.
- Be sure all hoses and fittings are the correct size and are tightly secured. See Dwg. TPD905-1 for a typical piping arrangement.

- Always use clean, dry air at 90 psig maximum air pressure. Dust, corrosive fumes and/or excessive moisture can ruin the motor of an air pump.
- Do not lubricate pumps with flammable or volatile liquids such as kerosene, diesel or jet fuel.
- Do not remove any labels. Replace any damaged label.
- This pump is not designed for working in explosive atmospheres.
- This pump is not insulated against electric shock.

#### USING THE PUMP

- Always wear eye protection when operating or performing maintenance on this pump.
- Always wear hearing protection when operating this pump.
- Use accessories recommended by Ingersoll-Rand.
- Do not start or operate this pump unless it is submerged.

### NOTICE

The use of other than genuine Ingersoll-Rand replacement parts may result in safety hazards, decreased pump performance, and increased maintenance, and may invalidate all warranties.

Repairs should be made only by authorized trained personnel. Consult your nearest Ingersoll-Rand Authorized Servicenter.

Refer All Communications to the Nearest  
Ingersoll-Rand Office or Distributor.

© Ingersoll-Rand Company 1996

Printed in U.S.A.

**INGERSOLL-RAND®**  
**PROFESSIONAL TOOLS**

# WARNING LABEL IDENTIFICATION



FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

	<b>WARNING</b> Always wear eye protection when operating or performing maintenance on this pump.
--	---

	<b>WARNING</b> Always wear hearing protection when operating this pump.
--	--

	<b>WARNING</b> Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this pump, or before performing any maintenance on this pump.
--	---

	<b>WARNING</b> Do not use damaged, frayed or deteriorated air hoses and fittings.
--	--

	<b>WARNING</b> Operate at 90 psig (6.2 bar/620 kPa) Maximum air pressure.
--	--

<b>International Warning Label:</b> Order Part No. _____	

## PLACING PUMP IN SERVICE

### LUBRICATION



**Ingersoll-Rand No. 10**

Always use an air line lubricator with these pumps. We recommend the following Portable Air Line Lubricator:

**Models PDA075 and PDA125:**  
**International - No. 8LUB16C**

**Models PDA200 and PDA300:**  
**International - No. 16LUB16C**

### INSTALLATION


All Models PDA075, and Models PDA125 and PDA200 with Teflon Diaphragms are furnished with a foot mounting inlet. Models PDA125 and PDA200 with Neoprene Diaphragms and all Models PDA300 are furnished with a screened inlet. For permanent installation, pumps with a foot mounting should be bolted to a mounting pad. All pumps should be attached to permanently installed piping by means of a flexible coupling to reduce pipe vibration. If the pump is used permanently submerged, remove the check valve and attach a hose to the air exhaust to pipe the exhaust above the level of the liquid being pumped.



**Submerge the pumps only in non-corrosive materials.**

If a suction hose is used, make certain that it is at least as large as specified in Table 1. If highly viscous materials are being pumped, the suction hose should be larger than specified. Make certain that all fittings and connections, particularly on the suction side of the pump are air tight. Loose connections will result in the reduction or loss of the suction capability of the pump.

These pumps will handle solids up to and including the sizes shown in Table 1. If a suction hose is used and there is any possibility of solids larger than those indicated, be certain to use a screen of the proper size on the end of the suction hose.



# PLACING PUMP IN SERVICE

**Hose and Solid Size**

Series	Air Inlet	Air Hose Size		Suction Size		Discharge Size		Solids Size	
		in.	mm	in.	mm	in.	mm	in.	mm
PDA075	1/4	1/4	6	1	25	3/4	19	1/8	3.1
PDA125	3/8	1/2	13	1-1/2	38	1-1/4	32	3/16	4.7
PDA200	1/2	1/2	13	2	51	2	51	1/4	6.3
PDA300	1/2	3/4	19	3	76	3	76	3/8	9.5

**Table 1**

## OPERATION

The discharge rate of the pump can be controlled by one of two methods:

1. The preferred method is to limit the volume and/or pressure of the air supply to the pump by means of a pressure regulator or a gate valve installed at the air inlet of the pump.
2. When it is necessary to control the discharge rate at a remote location, install a valve in the discharge line. When the pump discharge is throttled down so that the discharge pressure equals the air supply pressure, the pump will stall out. No bypass or pressure relief is needed, and there will be no damage to the pump. The discharge rate of the pump can be determined by counting the number of strokes per minute, a stroke being 1/2 cycle or 1 air exhaust. The volume per stroke of each pump is shown in Table 2.

Volume per Stroke	
Pump	gallons/liter
PDA075	0.10/0.37
PDA125	0.31/1.17
PDA200	0.77/2.91
PDA300	1.38/5.22

**Table 2**

When the pump is used for moving thick materials, check the stroke rate to make certain that the pump is not operating at a rate faster than the material is capable of flowing. If the pump is operating at a speed too fast for the available flow, reduce the volume of air to the pump until the stroke rate corresponds to the discharge volume.

If the material being pumped is capable of solidifying or packing, always flush the pump after the pumping operation. The pump can be turned upside down and all liquid will be drained out.

## APPLICATION

Few fluids are moved from one location to another without passing through a pump. Although these Diaphragm Pumps are primarily for the construction industry, there are going to be many applications – perhaps a derailed tank car – that involve fluids other than water. Because of this, it is extremely important that we understand the nature of certain chemicals and their effects on the materials used in these pumps.

To begin with, the major housing parts on these pumps are made of aluminum and are subject to corrosion by highly acidic and alkaline solutions. Use these pumps only within a pH factor range of pH6 – pH8.

**WARNING**

**Halogenated solvents can, under certain conditions, corrode aluminum or galvanized parts. If the wet parts of a pressurized fluid system contain aluminum or galvanized parts, this corrosive action could cause an explosion.**

Manufacturers typically add inhibitors to halogenated solvents. There is no known inhibitor that will prevent the corrosion reaction under all conditions. Do not use these pumps for pumping these materials. Typical examples of halogenated hydrocarbons (HHC) include, but are not limited to, the following:

- |                             |                                   |
|-----------------------------|-----------------------------------|
| <b>Trichlorethane</b>       | <b>Trichlorethylene</b>           |
| <b>Methylene Chloride</b>   | <b>Methyl Chloride</b>            |
| <b>Carbon Tetrachloride</b> | <b>Chloroform Dichlorethylene</b> |

When pumping volatile liquids, such as gasoline or naphtha, special considerations must be given to the amount of suction lift and the size of the suction line used.

**WARNING**

**The suction lift, whether actual vertical lift or pipe line friction, must be kept as low as possible and should never exceed 12 feet (3.6 m). Pumping rates should not exceed 20 gallons per minute.**

## **PLACING PUMP IN SERVICE**

When pumping any of the liquids shown in Table 3, always use a pump equipped with Viton or Teflon diaphragms, ball valves, and ball valve seats.

<b>Ketones and Aldehydes</b>	<b>Acetates</b>	<b>Aromatic Hydrocarbons</b>
1. Ethyl methyl ketone 2. Methylacetone 3. Acetone 4. Formaldehyde	1. Ethyl acetate 2. Isopropyl acetate 3. Amyl acetate 4. Butyl acetate	1. Benzene 2. Toloul (toluene) 3. Xylene (xyol) 4. Benzol 5. Hexane 6. Cyclohexane 7. Naphthalene

**Table 3**

### **HOW TO ORDER A DIAPHRAGM PUMP**

#### **NEOPRENE DIAPHRAGM with FOOT MOUNTING BASE**

<b>Model</b>	<b>Weight lb. (kg)</b>	<b>Pipe Tap (in.)</b>		<b>Suction Lift</b>		<b>Maximum Size Solids in. (mm)</b>
		<b>Discharge NPT (BSP)</b>	<b>Inlet NPT (BSP)</b>	<b>Dry ft. (m)</b>	<b>Wet ft. (m)</b>	
PDA075A1F	22 (9.9)	3/4 (-)	3/4 (-)	18 (5.5)	25 (7.6)	1/8 (3)
PDA075A3F	22 (9.9)	- (3/4)	- (3/4)	18 (5.5)	25 (7.6)	1/8 (3)

#### **TEFLON DIAPHRAGM with FOOT MOUNTING BASE**

PDA075T1F	22 (9.9)	3/4 (-)	3/4 (-)	12 (3.7)	25 (7.6)	1/8 (3)
PDA075T3F	22 (9.9)	- (3/4)	- (3/4)	12 (3.7)	25 (7.6)	1/8 (3)
PDA125T1F	35 (15.9)	1-1/4 (-)	1-1/2 (-)	12 (3.7)	25 (7.6)	3/16 (5)
PDA125T3F	35 (15.9)	- (1-1/4)	- (1-1/2)	12 (3.7)	25 (7.6)	3/16 (5)
PDA200T1F	72 (32.6)	2 (-)	2 (-)	13 (4.0)	20 (6.1)	1/4 (6)
PDA200T3F	72 (32.6)	- (2)	- (2)	13 (4.0)	20 (6.1)	1/4 (6)

#### **NEOPRENE DIAPHRAGM with SCREEN BASE**

PDA125A1S	35 (15.9)	1-1/4 (-)	1-1/2 (-)	22 (6.7)	27 (8.2)	3/16 (5)
PDA125A3S	35 (15.9)	- (1-1/4)	- (1-1/2)	22 (6.7)	27 (8.2)	3/16 (5)
PDA200A1S	72 (32.6)	2 (-)	2 (-)	20 (6.1)	25 (7.6)	1/4 (6)
PDA200A3S	72 (32.6)	- (2)	- (2)	20 (6.1)	25 (7.6)	1/4 (6)
PDA300A1S	120 (54.4)	3 (-)	3 (-)	20 (6.1)	25 (7.6)	3/8 (9.5)
PDA300A3S	120 (54.4)	- (3)	- (3)	20 (6.1)	25 (7.6)	3/8 (9.5)

#### **VITON DIAPHRAGM with SCREEN BASE**


PDA300V1S	120 (54.4)	3 (-)	3 (-)	20 (6.1)	25 (7.6)	3/8 (9.5)
PDA300V3S	120 (54.4)	- (3)	- (3)	20 (6.1)	25 (7.6)	3/8 (9.5)

# MANUEL D'EXPLOITATION ET D'ENTRETIEN POMPES À MEMBRANES PNEUMATIQUES MODÈLES PDA075, PDA125, PDA200 ET PDA300

## NOTE

La série PDA de pompes à membranes est une famille de pompe d'épuisement et submersibles. Elles sont particulièrement recommandées pour les applications nécessitant le pompage de particules en suspension (humides ou sèches), les solutions à forte teneur en sédiments ou visqueuses, ou les solutions contenant des matières solides jusqu'à la capacité individuelle de la pompe.

Ingersoll-Rand ne peut être tenu responsable de la modification des pompes par le client pour les adapter à des applications qui n'ont pas été approuvées par Ingersoll-Rand.



## ⚠ ATTENTION

**D'IMPORTANTES INFORMATIONS DE SÉCURITÉ SONT JOINTES.  
LIRE CE MANUEL AVANT D'UTILISER LA POMPE.  
L'EMPLOYEUR EST TENU DE COMMUNIQUER LES INFORMATIONS  
DE CE MANUEL AUX EMPLOYÉS UTILISANT CET OUTIL.**

**LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES.**

### MISE EN SERVICE DES POMPES

- Toujours exploiter, inspecter et entretenir cet outil conformément au Code de sécurité des outils pneumatiques portatifs de l'American National Standards Institute (ANSI B186.1).
- Pour des raisons de sécurité, et pour obtenir les performances et la durabilité maximales des pièces, cette pompe doit être alimentée avec de l'air comprimé à une pression maximum de 7,58 bar (758 kPa). Ne pas dépasser une pression d'air supérieure à 8,61 bar (861 kPa). Utiliser toujours un flexible d'air comprimé, un flexible d'aspiration et un flexible de refoulement aux dimensions correctes indiquées dans le Tableau 1.
- Couper toujours l'alimentation d'air comprimé et débrancher le flexible d'alimentation avant d'installer, déposer ou ajuster toute accessoire sur cette pompe, ou d'entreprendre une opération d'entretien quelconque sur la pompe.
- Ne pas utiliser des flexibles ou des raccords endommagés, effilochés ou détériorés.
- S'assurer que tous les flexibles et les raccords sont correctement dimensionnés et bien serrés. Voir Plan TPD905-1 pour un exemple type d'agencement des tuyauteries.

- Utiliser toujours de l'air sec et propre à une pression maximum de 6,2 bar. La poussière, les fumées corrosives et/ou une humidité excessive peuvent endommager le moteur d'une pompe pneumatique.
- Ne jamais lubrifier les pompes avec des liquides inflammables ou volatils tels que le kérosène, le gasol ou le carburant d'aviation.
- Ne retirer aucune étiquette. Remplacer toute étiquette endommagée.
- Cette pompe n'est pas conçue pour fonctionner dans des atmosphères explosives.
- Cette pompe n'est pas isolée contre les chocs électriques.

### UTILISATION DE LA POMPE

- Porter toujours des lunettes de protection pendant l'utilisation et l'entretien de cette pompe.
- Porter toujours une protection acoustique pendant l'utilisation de cette pompe.
- Utiliser les accessoires recommandés par Ingersoll-Rand.
- Ne pas exploiter cette pompe lorsqu'elle n'est pas submergée.

## NOTE

L'utilisation de rechanges autres que les pièces d'origine Ingersoll-Rand peut causer des risques d'insécurité, réduire les performances de la pompe et augmenter l'entretien, et peut annuler toutes les garanties.

Les réparations ne doivent être effectuées que par des réparateurs qualifiés autorisés. Consultez votre Centre de Service Ingersoll-Rand le plus proche.

Adressez toutes vos communications au Bureau Ingersoll-Rand ou distributeur le plus proche.

© Ingersoll-Rand Company 1996







Imprimé aux É.U.

**INGERSOLL-RAND®**  
**PROFESSIONAL TOOLS**

## SIGNIFICATION DES ETIQUETTES D'AVERTISSEMENT

### ATTENTION

LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES



## MISE EN SERVICE DES POMPES

### LUBRIFICATION



Ingersoll-Rand No. 10

Utiliser toujours un lubrificateur avec ces pompes. Nous recommandons le lubrificateur d'air comprimé portable suivant :

**Pour les modèles PDA075 et PDA125:**  
International - No. 8LUB16C

**Pour les modèles PDA200 et PDA300:**  
International - No. 16LUB16C

### INSTALLATION


Tous les Modèles PDA075, PDA125 et PDA200 fournis dotés de membranes en Téflon sont fournis avec un orifice d'admission monté dans le pied de la pompe. Les modèles PDA125 et PDA200 dotés d'une membrane en néoprène et les Modèles PDA300 sont fournis avec un orifice d'admission à crépine. Pour les installations permanentes, les pompes dotées d'un pied doivent être boulonnées sur une embase de montage. Toutes les pompes doivent être connectées à des tuyauteries fixes par l'intermédiaire d'un accouplement flexible pour réduire la vibration des tuyauteries. Si la pompe est utilisée de façon permanente en position submergée, déposer le clapet anti-retour et connecter un flexible sur le raccord d'échappement d'air pour acheminer l'échappement au-dessus du niveau liquide à pomper.

### AVERTISSEMENT

**La pompe ne doit être submergée que dans des liquides non corrosifs.**

Lorsqu'un flexible d'aspiration est employé, vérifiez que son diamètre est au moins égal à celui spécifié dans le Tableau 1. Pour le pompage de matériaux très visqueux, le diamètre du flexible d'aspiration doit être supérieur à celui spécifié. S'assurer que les raccords et connexions, en particulier sur le côté aspiration de la pompe, sont étanches à l'air. Des connexions libres conduiraient à une réduction ou une perte de la capacité d'aspiration de la pompe.

Ces pompes sont capables de pomper des matières solides jusqu'aux dimensions indiquées dans le Tableau 1. Lorsqu'un flexible d'aspiration est employé et si des solides de dimension supérieure à celle spécifiée risquent d'être pompés, installer une crépine de taille correcte à l'extrémité du flexible d'aspiration.



(Plan TPD905-1)

# MISE EN SERVICE DES POMPES

## Dimensions des flexibles et des solides

Série	Admission d'air	flexible		aspiration		refoulement		solides	
		pouces.	mm	pouces.	mm	pouces.	mm	pouces.	mm
PDA075	1/4	1/4	6	1	25	3/4	19	1/8	3,1
PDA125	3/8	1/2	13	1-1/2	38	1-1/4	32	3/16	4,7
PDA200	1/2	1/2	13	2	51	2	51	1/4	6,3
PDA300	1/2	3/4	19	3	76	3	76	3/8	9,5

Tableau 1

## FONCTIONNEMENT

Le débit de refoulement de la pompe peut être contrôlé de deux façons différentes :

1. La méthode préférée est de limiter le volume et/ou la pression de l'alimentation d'air comprimé de la pompe au moyen d'un régulateur de pression ou d'un robinet-vanne monté sur l'admission d'air de la pompe.
2. Lorsque le débit de refoulement doit être contrôlé à un endroit éloigné de la pompe, monter une vanne sur le circuit de refoulement. Lorsque le refoulement de la pompe est réduit jusqu'à ce que la pression de refoulement soit égale à la pression d'air comprimé, la pompe calera. Il n'est pas nécessaire de prévoir un bypass ou une soupape de sûreté, et la pompe ne risque pas d'être endommagée. Le débit de refoulement de la pompe peut être déterminé en comptant le nombre de courses par minutes, une course étant égale à 1/2 cycle ou 1 échappement d'air. Le volume par course de chaque pompe est indiqué dans le Tableau 2.

Volume par course	
Pompe	gallons/litres
PDA075	0,10/0,37
PDA125	0,31/1,17
PDA200	0,77/2,91
PDA300	1,38/5,22

Tableau 2

Lorsque la pompe est utilisée pour le transfert de matériaux épais, vérifier la cadence des courses de la pompe pour s'assurer que la pompe ne fonctionne pas à un débit plus rapide que celui possible pour l'écoulement du matériau. Si la vitesse de la pompe est trop rapide pour le matériau pompé, réduire le volume d'air d'alimentation de la pompe jusqu'à ce que la cadence de la pompe corresponde au volume de refoulement.

Si le matériau à pomper risque de se solidifier ou de se compacter, rincer la pompe après chaque pompage. La pompe peut être retournée pour vidanger tout le liquide qu'elle contient.

## APPLICATION

Peu de fluides sont déplacés d'un endroit à un autre sans l'aide d'une pompe. Bien que ces pompes à membranes soient destinées principalement à l'industrie du bâtiment, elles peuvent être utilisées dans de nombreuses applications mettant en cause des fluides autres que de l'eau, comme par exemple, lors du déraillement d'un wagon-citerne. Par conséquent, il est important de bien comprendre la nature de certains produits chimiques et leurs effets sur les matériaux employés dans la construction de ces pompes.

Pour commencer, les pièces principales du corps de ces pompes sont fabriquées en aluminium et sont sujettes à corrosion en présence de solutions acides ou alcalines. Ces pompes ne peuvent donc être utilisées que dans une plage de fluides ayant un pH compris entre 6 et 8.

### ATTENTION

**Les solvants halogénés peuvent, dans certaines conditions, attaquer les pièces en aluminium ou galvanisées. Si les parties humides d'un circuit de fluide pressurisé contiennent des pièces en aluminium ou galvanisées, cette action corrosive pourrait causer une explosion.**

Les fabricants ajoutent normalement des inhibiteurs dans les solvants halogénés. Aucun inhibiteur connu n'empêchera la corrosion dans toutes les conditions. Ne jamais utiliser ces pompes avec ces matériaux. Parmi les hydrocarbures halogénés (HHC) on trouve à titre d'exemple seulement:

**Trichloroéthane                      Trichloréthylène**  
**Chlorure de méthane              Chlorure de méthyle**  
**Tétrachlorure de carbone      Bichloréthylène de chloroforme**

Des considérations spéciales doivent être prises pour le pompage de liquides volatiles, tels que l'essence ou le naphtha, au niveau de la hauteur d'aspiration et du diamètre des tuyaux d'aspiration.

### ATTENTION

**La pression d'aspiration, que ce soit la hauteur verticale réelle ou le frottement dans la tuyauterie, doit être maintenue aussi basse que possible et ne doit en aucun cas dépasser 3,6 m. Les débits de pompage ne devraient pas dépasser 90 litres/mn.**

## **MISE EN SERVICE DES POMPES**

Pour le pompage des liquides indiqués dans le Tableau 3, utiliser toujours une pompe équipée de membranes, de vannes sphériques et de sièges de vanne en Viton ou en Téflon.

<b>Cétones et Aldéhydes</b>	<b>Acétates</b>	<b>Hydrocarbures aromatiques</b>
1. Cétone éthyle méthyle 2. Méthylacétone 3. Acétone 4. Formaldéhyde	1. Acétate d'éthyle 2. Acétate isopropylique 3. Acétate d'amyle 4. Acétate butylique	1. Benzène 2. Toluène 3. Xylène 4. Benzol 5. Hexane 6. Cyclohexane 7. Naphtalène

**Tableau 3**




# MANUAL DE FUNCIONAMIENTO Y MANTENIMIENTO BOMBAS NEUMÁTICAS DE DIAFRAGMA MODELOS PDA075, PDA125, PDA200 Y PDA300

## NOTA

Las bombas de diafragma de la serie PDA están diseñadas como bombas de aspiración y sumergibles. Se recomiendan especialmente para aquellas aplicaciones que incluyan el bombeo de partículas en suspensión (seco o mojado), soluciones muy sedimentadas o viscosas, o aquellas soluciones que contengan sólidos hasta la capacidad individual de la bomba.

Ingersoll-Rand no aceptará responsabilidad alguna por las modificaciones de las bombas efectuadas por el cliente para aplicaciones que no hayan sido consultadas con Ingersoll-Rand.



## ⚠ AVISO

**SE ADJUNTA INFORMACIÓN IMPORTANTE DE SEGURIDAD.  
LEA ESTE MANUAL ANTES DE USAR LA BOMBA**

**ES RESPONSABILIDAD DE LA EMPRESA ASEGURARSE DE QUE EL OPERARIO ESTÉ  
AL TANTO DE LA INFORMACIÓN QUE CONTIENE ESTE MANUAL.  
EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRÍA OCASIONAR LESIONES.**

### PARA PONER LA BOMBA EN SERVICIO

- Utilice, examine y mantenga siempre esta herramienta conforme al código de seguridad para herramientas neumáticas portátiles de la American National Standards Institute (ANSI B186.1).
- Utilice, inspeccione y mantenga esta bomba siempre de acuerdo con todas las normativas locales y nacionales que se apliquen a las bombas neumáticas de operación manual o que se sujeten con la mano.
- Para mayor seguridad, óptimo rendimiento y larga vida útil de las piezas, utilice esta bomba hasta una presión de aire de 110 psig (7,58 bar/758 kPa). La presión de aire no debe exceder los 125 psig (8,61 bar/861 kPa). Las mangueras de aire, de aspiración y de descarga deben ser del tamaño apropiado como se indica en el cuadro 1.
- Corte siempre el suministro de aire y desconecte la manguera de suministro de aire antes de instalar, desmontar o ajustar un accesorio de la bomba, o antes de realizar trabajos de mantenimiento de la misma.
- No utilice mangueras de aire y racores dañados, desgastados ni deteriorados.
- Asegúrese de que todos los racores y mangueras sean del tamaño correcto y estén bien apretados. El Esq. TPD905-1 muestra una disposición característica de las tuberías.

- Use siempre aire limpio y seco a una presión máxima de 90 psig (6,2 bar/620 kPa). El polvo, los gases corrosivos y el exceso de humedad pueden estropear el motor de una bomba neumática.
- No lubrique la bomba con líquidos inflamables o volátiles tales como queroseno, diesel o combustible para motores a reacción.
- No saque ninguna etiqueta. Sustituya toda etiqueta dañada.
- Esta bomba no ha sido diseñada para trabajar en ambientes explosivos.
- Esta bomba no está aislada contra descargas eléctricas.

### UTILIZACIÓN DE LA BOMBA

- Lleve siempre protección ocular al utilizar la bomba o realizar trabajos de mantenimiento en la misma.
- Lleve siempre protección para los oídos al utilizar esta bomba.
- Utilice únicamente los accesorios recomendados por Ingersoll-Rand.
- No arranque ni utilice la bomba si no está sumergida.

## NOTA

El uso de piezas de recambio que no sean las auténticas piezas Ingersoll-Rand puede poner en peligro la seguridad, reducir el rendimiento de la bomba y aumentar los cuidados de mantenimiento necesarios, así como invalidar toda garantía.

Las reparaciones sólo se deben encomendar a personal debidamente cualificado y autorizado. Consulte con el centro de servicio autorizado Ingersoll-Rand más próximo.

Toda comunicación se deberá dirigir a la oficina o al distribuidor Ingersoll-Rand más próximo.

© Ingersoll-Rand Company 1996




Impreso en EE. UU.

**INGERSOLL-RAND®**  
**PROFESSIONAL TOOLS**

## ETIQUETAS DE AVISO

**AVISO**

EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRÍA OCASIONAR LESIONES.



## PARA PONER LA BOMBA EN SERVICIO

### LUBRICACIÓN




Ingersoll-Rand N°. 10

Utilice siempre un lubricador de aire comprimido con esta bomba. Recomendamos el siguiente lubricador portátil de aire comprimido:

Para los modelos PDA075 y PDA125:  
Internacional - N°. 8LUB16C

Para los modelos PDA200 y PDA300:  
Internacional - N°. 16LUB16C



### INSTALACIÓN

Todos los modelos PDA075, así como los modelos PDA125 y PDA200 con diafragma de teflón, llevan una admisión con pedestal. Los modelos PDA125 y PDA200 con diafragma de neopreno y todos los modelos PDA300 llevan un tamiz de admisión. Para las instalaciones permanentes, las bombas con pedestal deben fijarse a una placa de montaje. Todas las bombas deben conectarse a un sistema de tuberías permanente por medio de un acoplamiento flexible para reducir la vibración de las tuberías. Si la bomba se usa permanentemente sumergida, saque la válvula antirretorno y conecte una manguera al escape para llevar el aire de escape más arriba del nivel del líquido que se bombea.

### PRECAUCIÓN

Sumerja las bombas solamente en materiales no corrosivos.

Si utiliza una manguera de aspiración, asegúrese de que el diámetro de la misma no sea inferior al que se especifica en el cuadro 1. Si se está bombeando material muy viscoso, la manguera de aspiración debe ser más grande de lo especificado. Asegúrese de que todos los racores y conexiones sean herméticos, sobre todo los que están en el lado de aspiración de la bomba. Las conexiones flojas reducirán o anularán la capacidad de aspiración de la bomba.

Estas bombas manejan sólidos hasta los tamaños indicados en el cuadro 1. Si se utiliza una manguera de aspiración y existe la posibilidad de que haya sólidos mayores de los indicados, asegúrese de utilizar un tamiz del tamaño apropiado en el extremo de la manguera de aspiración.

## PARA PONER LA BOMBA EN SERVICIO

**Tamaños de manguera y de sólidos**

Serie	Admisión de aire	Tamaño manguera de aire		Tamaño manguera aspiración		Tamaño manguera descarga		Tamaño de sólidos	
		pulg.	mm	pulg.	mm	pulg.	mm	pulg.	mm
PDA075	1/4	1/4	6	1	25	3/4	19	1/8	3,1
PDA125	3/8	1/2	13	1-1/2	38	1-1/4	32	3/16	4,7
PDA200	1/2	1/2	13	2	51	2	51	1/4	6,3
PDA300	1/2	3/4	19	3	76	3	76	3/8	9,5

**Cuadro 1**

### MANEJO

El caudal de descarga de la bomba puede regularse por uno de dos métodos:

1. El método preferido es el de limitar el volumen y/o la presión del aire suministrado a la bomba por medio de un regulador de presión o una válvula de corredera instalada en la admisión de aire de la bomba.
2. Cuando sea necesario regular el caudal de descarga desde una posición alejada, instale una válvula en la tubería de descarga. Cuando se disminuya la descarga de bomba y la presión de descarga iguale la presión del aire suministrado, la bomba se calará. No se necesita ninguna derivación ni descarga de presión, ni se dañará la bomba.

El caudal de descarga de la bomba puede determinarse contando el número de carreras por minuto: una carrera representa 1/2 ciclo o 1 escape de aire. El volumen por carrera de cada bomba se muestra en el cuadro 2.

Volumen por carrera	
Bomba	Galones/litros
PDA075	0,10/0,37
PDA125	0,31/1,17
PDA200	0,77/2,91
PDA300	1,38/5,22

**Cuadro 2**

Cuando se utiliza la bomba para trasladar materiales espesos, compruebe el ritmo de bombeo para asegurarse de que no esté funcionando a una velocidad superior a la velocidad a la que puede fluir el material. Si la bomba funciona a demasiada velocidad para el grado de fluidez del material, reduzca el volumen de aire que pasa a la bomba hasta que el ritmo de bombeo corresponda al caudal de descarga.

Si el material bombeado puede solidificarse o incrustarse, limpie siempre la bomba una vez terminada la operación de bombeo. La bomba puede ponerse boca abajo para drenar todo el líquido.

### USO

Son pocos los líquidos que se desplazan de un lugar a otro sin intervención de una bomba. Si bien estas bombas de diafragma están encaminadas principalmente para el ramo de la construcción, habrá otras muchas aplicaciones –como puede ser el descarrilamiento de un coche cisterna– que implican líquidos que no sean del agua. Por ello es muy importante comprender la naturaleza de ciertos productos químicos y sus efectos sobre los materiales que se emplean en estas bombas.

Para empezar, las piezas principales de la carcasa de estas bombas son de aluminio y están sujetas a la corrosión, resultado de soluciones muy ácidas o alcalinas. Estas bombas sólo se deben utilizar dentro de la gama de factores pH de pH6 a pH8.



**AVISO**

**En ciertas circunstancias los disolventes halogenados pueden corroer el aluminio o las piezas galvanizadas. Si las piezas mojadas de un sistema de líquido bajo presión contienen aluminio o piezas galvanizadas, esta acción corrosiva puede causar una explosión.**

Los fabricantes suelen añadir inhibidores a los solventes halogenados. No hay ningún inhibidor conocido que pueda evitar la acción corrosiva en todas las condiciones. No utilice estas bombas para bombear estas materias. Los ejemplos típicos de hidrocarburos halogenados (HHC) incluyen pero no se limitan a lo siguiente:

- |                         |                              |
|-------------------------|------------------------------|
| Tricloroetano           | Tricloroetileno              |
| Cloruro de metileno     | Cloruro de metilo            |
| Tetracloruro de carbono | Dicloroetileno de cloroformo |

Al bombear líquidos volátiles tales como gasolina o nafta, deberá tener bien en cuenta la altura de elevación y el tamaño de la tubería de aspiración que se utiliza.



**AVISO**

**La altura de elevación, se trata de la elevación vertical o de la fricción de la tubería, debe mantenerse en la mínima posible y no debe nunca exceder los 3,6 m. El caudal de bombeo no debe exceder los 20 galones por minuto.**

## **PARA PONER LA BOMBA EN SERVICIO**

Al bombear alguno de los líquidos indicados en el cuadro 3, utilice siempre una bomba equipada con diafragma, válvula de bola y asiento de válvula de bola de Teflón o Vitón.

<b>Cetonas y aldehidos</b>	<b>Acetatos</b>	<b>Hidrocarburos aromáticos</b>
1. Cetona etilmetílica 2. Acetona metílica 3. Acetona 4. Formaldehido	1. Acetato etílico 2. Acetato isopropílico 3. Acetato amílico 4. Acetato butílico	1. Benceno 2. Tolueno 3. Xileno 4. Benzol 5. Hexano 6. Ciclohexano 7. Naftaleno


**Cuadro 3**

# MANUAL DE FUNCIONAMENTO E MANUTENÇÃO BOMBAS DE DIAFRAGMA PNEUMÁTICAS MODELOS PDA075, PDA125, PDA200 E PDA300

## AVISO

As bombas de Diafragma Séries PDA são concebidas como sendo bombas de sucção submersíveis. Elas são especialmente recomendadas para estas aplicações envolvendo o bombeamento de particulado suspenso (a seco ou a húmido), pesadamente sedimentado ou soluções viscosas, ou aquelas soluções que contenham sólidos até a capacidade individual da bomba.

A Ingersoll-Rand não é responsável por modificações, feitas pelo cliente em ferramentas, nas quais a Ingersoll-Rand não tenha sido consultada.



## ⚠️ ADVERTÊNCIA

**INFORMAÇÃO DE SEGURANÇA IMPORTANTE EM ANEXO.  
LEIA ESTE MANUAL ANTES DE OPERAR A FERRAMENTA.**

**É DA RESPONSABILIDADE DO EMPREGADOR COLOCAR A INFORMAÇÃO  
DESTE MANUAL NAS MÃOS DO OPERADOR.**

**O NÃO CUMPRIMENTO DAS SEGUINTE ADVERTÊNCIAS PODE  
RESULTAR EM FERIMENTOS.**

### COLOCANDO AS BOMBAS EM FUNCIONAMENTO

- Sempre opere, inspecione e mantenha esta ferramenta de acordo com o Código de Segurança do Instituto Americano de Padrões Nacionais para Ferramentas Pneumáticas Portáteis (ANSI B186.1).
- Para segurança, máximo desempenho e máxima durabilidade das peças, opere esta bomba com uma pressão de ar máxima de 7,58 bar/758 kPa (110 psig). Não exceda a pressão de ar acima de 8,61 bar/861 kPa (125 psig). Use sempre o tamanho apropriado de mangueira de ar, mangueira de sucção e mangueira de descarga como mostrado na Tabela 1.
- Desligue sempre a alimentação de ar e desligue a mangueira de alimentação de ar antes de instalar, remover ou ajustar qualquer acessório nesta ferramenta, ou antes de executar qualquer serviço de manutenção nesta ferramenta.
- Não use mangueiras de ar ou adaptadores danificados, gastos ou deteriorados.
- Certifique-se de todas as mangueiras e adaptadores são do tamanho correcto e estão seguramente

apertados. Veja o Desenho TPD905-1 para a montagem normal da tubagem.

- Use sempre ar seco e limpo com uma pressão máxima de 90 psig. Pó, fumos corrosivos e/ou humidade excessiva podem arruinar o motor de uma bomba pneumática.
- Não lubrifique as bombas com líquidos inflamáveis ou voláteis tais como querosene, diesel ou combustível de jactos.
- Não remova nenhum rótulo. Substitua qualquer rótulo danificado.

### USANDO A FERRAMENTA

- Use sempre óculos de protecção quando estiver operando ou executando algum serviço de manutenção nesta bomba.
- Use sempre protecção contra ruído quando operar esta bomba.
- Use acessórios recomendados pela Ingersoll-Rand.
- Não ligue ou opere esta bomba a não ser que ela esteja submersa.
- Esta Bomba não foi concebida para trabalhos em atmosferas explosivas.
- Esta Bomba não está isolada contra choques eléctricos.

## AVISO

O uso de peças de substituição que não sejam genuinamente da Ingersoll-Rand podem resultar em riscos de segurança, diminuição do desempenho da ferramenta, aumento da necessidade de manutenção e pode invalidar todas as garantias.

As reparações devem ser feitas somente por pessoal treinado autorizado. Consulte o Centro de Serviços da Ingersoll-Rand mais próximo.

Envie Todos os Comunicados Para o Distribuidor ou Escritório da Ingersoll-Rand Mais Próximo.

© Ingersoll-Rand Company 1996





Impresso nos E.U.A.

**INGERSOLL-RAND®**  
**PROFESSIONAL TOOLS**

# IDENTIFICAÇÃO DO RÓTULO DE ADVERTÊNCIA

## ⚠ ADVERTÊNCIA

O NÃO CUMPRIMENTO DAS SEGUINTES ADVERTÊNCIAS PODE RESULTAR EM FERIMENTO.



## COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

### LUBRIFICAÇÃO




#### Ingersoll-Rand No. 10

Use sempre use um lubrificador de ar de linha com estas bombas. Nós recomendamos os seguintes Lubrificadores de Condução de Ar Portáteis:

**Para Modelos PDA075-EU e PDA125-EU:  
Para Internacional - No. 8LUB16C**

**Para Modelos PDA200-EU e PDA300-EU:  
Para Internacional - No. 16LUB16C**



(Desenho TPD905-1)

### INSTALAÇÃO

Todos os Modelos PDA075-EU, e Modelos PDA125-EU e PDA200-EU com Diafragmas de Teflon são fornecidos com uma entrada de montagem no pé de apoio. Modelos PDA125-EU e PDA200-EU com Diafragmas de Neoprene e todos os Modelos PDA300-EU são fornecidos com uma entrada vedada por uma tela. Para instalação permanente, as bombas com um pé de apoio para montar devem ser aparafusadas no painel de montagem. Todas as bombas devem ser acopladas a uma tubagem instalada permanentemente por meio de um acoplamento flexível para reduzir a vibração do tubo. Se a bomba for usada permanentemente submersa, remova a válvula de verificação e acople uma mangueira ao escape de ar para conectar com tubos o escape acima do nível do líquido a ser bombeado.

## ⚠ CUIDADO

**As bombas devem ser submersas somente em materiais não-corrosivos.**

Se a bomba de sucção for usada, certifique-se de que ela seja no mínimo como especificado na Tabela 1. Se materiais altamente viscosos estiverem sendo bombeados, a mangueira de sucção deve ser maior que o especificado. Esteja certo de que todos os adaptadores e conexões, particularmente aqueles no lado de sucção onde a bomba está apertada pneumaticamente. Conexões frouxas resultarão na redução ou perda de capacidade de sucção da bomba.

Estas bombas irão lidar com sólidos até e inclusive os tamanhos mostrados na Tabela 1. Se a mangueira de sucção for usada e houver qualquer possibilidade dos sólidos serem maiores do que aqueles indicados, certifique-se de que uma tela do tamanho apropriado seja usada na extremidade da mangueira de sucção.

# COLOCANDO A BOMBA EM FUNCIONAMENTO

## ESPECIFICAÇÕES

### Mangueira e Tamanho do Sólidos

Séries	Entrada de Ar	Tamanho da Mangueira de Ar		Tamanho da Mangueira de Sucção		Tamanho da Mangueira de Descarga		Tamanho dos Sólidos	
		mm	pol.	mm	pol.	mm	pol.	mm	pol.
PDA075-EU	1/4	6	1/4	25	1	19	3/4	3,1	1/8
PDA125-EU	3/8	13	1/2	38	1-1/2	32	1-1/4	4,7	3/16
PDA200-EU	1/2	13	1/2	51	2	51	2	6,3	1/4
PDA300-EU	1/2	19	3/4	76	3	76	3	9,5	3/8

Tablela 1

### OPERAÇÃO

A taxa de descarga da bomba pode ser controlada por um dos dois métodos:

1. O método preferido é limitar o volume e/ou a pressão de alimentação de ar para a bomba por meio de uma regulador de pressão ou uma válvula de vedação instalada na entrada de ar da bomba.
2. Quando for necessário controlar a taxa de descarga em um local remoto, instale uma válvula na linha de descarga. Quando a descarga da bomba for diminuída de modo que a pressão de descarga se iguale à pressão de alimentação de ar, a bomba irá engasgar. Nenhum desvio ou alívio de pressão é necessário, e não haverá dano algum à bomba.

A taxa de descarga da bomba pode ser determinada pelo número de impactos por minuto, um impacto sendo 1/2 ciclo ou um escape de ar. O volume de impacto de cada bomba é mostrado na Tabela 2.

### Volume por Impacto

Bomba	galões/litros
PDA075-EU	0,10/0,37
PDA125-EU	0,31/1,17
PDA200-EU	0,77/2,91
PDA300-EU	1,38/5,22

Tablela 2

Quando a bomba for usada para mover materiais espessos, verifique a taxa de impacto para se certificar de que a bomba não está operando em uma taxa mais rápida do que o material é capaz de fluir. Se a bomba estiver operando em velocidade rápida demais para o fluxo disponível, reduza o volume de ar para a bomba até que a taxa de impacto corresponda ao volume de descarga.

Se o material sendo bombeado for capaz de solidificar ou formar "pacotes", limpe sempre a bomba depois da operação da bomba. A bomba pode se virada de cabeça para baixo e todo o líquido será drenado.

### APLICAÇÃO

Poucos fluídos são movidos de um lugar para outro sem passar por uma bomba. Embora estas Bombas de Diafragma sejam primariamente para a indústria de construção, muitas aplicações estão sendo utilizadas – talvez um carro de tanque fora do trilho – que envolvem fluídos que não sejam a água. Por causa disto, é extremamente importante que nós compreendamos a natureza de certos materiais químicos e seus efeitos em materiais usados nestas bombas.

Para começar, a maioria das peças do corpo destas bombas é feita de alumínio e está sujeita a corrosão por soluções altamente ácidas ou alcalinas. Use estas bombas somente dentro de um intervalo de factor de pH de 6 a 8.

### ADVERTÊNCIA

**Solventes halogenados podem, sob certas condições, corroerem peças de alumínio ou galvanizadas. Se peças húmidas de sistema de fluido contiver alumínio ou peças galvanizadas, esta ação corrosiva pode causar explosão.**

Os fabricantes adicionam tipicamente solventes halogenados. Não há nenhum inibidor que irá prevenir a reação de corrosão sob todas as condições. Não use estas bombas para bombear estes materiais. Exemplos típicos de hidrocarbonos halogenados (HHC) incluem, mas não são limitados aos seguintes:

Tricloreto de Metileno	Tricloroetileno
Tetracloroeto de Carbono	Dicloroetileno de Clorofórmio

Ao bombear líquidos voláteis, tais como gasolina ou nafta, considerações especiais devem ser dadas à quantidade de levante de sucção e o tamanho da conduta de sucção utilizada.

### ADVERTÊNCIA

**O levante de sucção, quer seja um levante vertical real ou fricção de conduta de tubo, deve ser mantido tão baixo quanto possível e nunca deve exceder 3,6m (12 pés). Taxas de Bombeamento não devem exceder a 20 galões por minuto.**

## **COLOCANDO A BOMBA EM FUNCIONAMENTO**

Ao bombear qualquer destes líquidos mostrados na Tabela 3, use sempre uma bomba equipada com Diafragmas de Teflon ou Viton, válvulas de esferas e assentos de válvula de esferas.


<b>Acetonas e Aldeídos</b>	<b>Acetatos</b>	<b>Hidrocarbonos Aromáticos</b>
1. Etil metil acetona	1. Acetato Etilico	1. Benzeno
2. Metilacetona	2. Acetato Isopropílico	2. Toloul (Tolueno)
3. Acetona	3. Amyl acetato	3. Xileno (xylol)
4. Formolaldeído	4. Butil acetato	4. Benzol
		5. Hexano
		6. Ciclohexano
		7. Naftaleno

**Tablela 3**



# MAINTENANCE SECTION

## Series PDA075



(Dwg. TPB849)

# MAINTENANCE SECTION

PART NUMBER FOR ORDERING


PART NUMBER FOR ORDERING

1	Air Valve Body (includes piston) . . . . .	PDA075-LF80A	19	Outer Piston (2)	
2	Bottom Air Valve Cap . . . . .	PDA075-80S		for models with Neoprene	
3	Top Air Valve Cap (includes			Diaphragm . . . . .	PDA075-B81B
	guide) . . . . .	PDA075-80RS		for models with Teflon	
4	Valve Cap Retaining Ring (2) . . . . .	PDA075-80T		Diaphragm . . . . .	PDA075-T81B
5	Valve Cap O-ring (2) . . . . .	PDA075-2D	20	Water Chamber (2) . . . . .	PDA075-85
6	Air Valve Gasket . . . . .	PDA075-80B	21	Ball Valve (4)	
7	Center Block . . . . .	PDA075-80HA		Neoprene . . . . .	PDA075-91
8	Muffler Plate Gasket . . . . .	PDA075-80MG		Teflon . . . . .	PDA075-TF91
9	Muffler Plate . . . . .	PDA075-80M	22	Ball Valve Seat (4) . . . . .	PDA075-A90
10	Muffler . . . . .	PDA075-70C	23	Valve Seat O-ring (4)	
11	Air Valve Body Mounting			Neoprene . . . . .	PDA075-90B
	Screw (4)			Teflon . . . . .	PDA075-90T
	for models with Neoprene		24	Discharge Manifold	
	Diaphragm . . . . .	PDA075-80AS		with 3/4" National Pipe	
	for models with Teflon			Thread . . . . .	PDA075-86NPT
	Diaphragm . . . . .	PDA075-S80AS		with 3/4" British Standard	
12	Mounting Screw Nut (4) . . . . .	PDA075-S62C		Pipe . . . . .	PDA075-86BSP
13	Diaphragm Shaft		25	Inlet Manifold	
	for models with Neoprene			with 3/4" National Pipe	
	Diaphragm . . . . .	PDA075-81A		Thread . . . . .	PDA075-87NPT
	for models with Teflon			with 3/4" British Standard	
	Diaphragm . . . . .	PDA075-T81A		Pipe . . . . .	PDA075-87BSP
14	Diaphragm Shaft O-ring (4) . . . . .	PDA075-LF80JH	26	Manifold Bolt Assembly (consists	
15	Piston Shaft (2)			of Bolt, Washer and Nut) (4)	
	for models with Neoprene			for models with Neoprene	
	Diaphragm . . . . .	PDA075-81F		Diaphragm . . . . .	PDA075-84
	for models with Teflon			for models with Teflon	
	Diaphragm . . . . .	PDA075-81AN		Diaphragm . . . . .	PDA075-S84
16	Inner Piston (2)		*	Nameplate . . . . .	
	for models with Neoprene			for models ending in -EU . .	PDA200-EU-301
	Diaphragm . . . . .	PDA075-81C		for all other models . . . . .	PDA200-301
	For models with Teflon		*	Caution Label	
	Diaphragm . . . . .	PDA075-T81C		for models ending in -EU . .	EU-99
17	Diaphragm (2)			for all other models . . . . .	PDA075-33
	Neoprene . . . . .	PDA075-83			
	Teflon . . . . .	PDA075-TF83	*	Tune-up Kit (for models with	
18	Back-up Diaphragm (for models			Neoprene Diaphragms) (includes	
	with Teflon Diaphragm) (2) . . . . .	PDA075-TF83B		illustrated items 14[4], 17[2],	
				21[4] and 23[4]) . . . . .	PDA075-TK2

\* Not illustrated.

# MAINTENANCE SECTION

## Series PDA125



(Dwg. TPA1234)

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

1	Air Valve Body (includes piston) . . .	PDA125-LF60A	16	Diaphragm Shaft O-ring (7) . . . . .	PDA125-LF20J
2	Air Valve Screen . . . . .	PDA125-60E	17	Center Block Gasket (2) . . . . .	PDA125-60P
3	Reducer Bushing . . . . .	PDA125-60AP	18	Diaphragm Shaft Stud (2) for models with Neoprene Diaphragm . . . . .	PDA125-T21F
4	Bottom Air Valve Cap . . . . .	PDA125-60S		for models with Teflon Diaphragm . . . . .	PDA125-T61F
5	Top Air Valve Cap (includes guide) . .	PDA125-60R	19	Air Chamber (2) . . . . .	PDA125-62
6	Valve Cap Retaining Ring (2) . . . . .	PDA125-60T	20	Air Chamber Mounting Screw (3) . .	PDA125-63B
7	Valve Cap O-ring (2) . . . . .	PDA125-60U	21	Chamber Mounting Screw Nut (3) . .	PDA125-62C
8	Air Valve Gasket . . . . .	PDA125-P60B	22	Inner Piston (2) for models with Neoprene Diaphragm . . . . .	PDA125-61C
9	Air Valve Body Mounting Screw (4) . . . . .	PDA125-60AS		for models with Teflon Diaphragm . . . . .	PDA125-TB61C
10	Nipple . . . . .	PDA125-20F	23	Diaphragm (2) Neoprene . . . . .	PDA125-63
11	Check Ball . . . . .	PDA125-20M		Teflon . . . . .	PDA125-TF63
12	Check Body . . . . .	PDA125-20K8	24	Back-up Diaphragm (for models with Teflon Diaphragm) (2) . . . . .	PDA125-TF63B
13	Center Block . . . . .	PDA125-LF60H			
14	Center Block Bushing . . . . .	PDA125-60N			
15	Diaphragm Shaft for models with Neoprene Diaphragm . . . . .	PDA125-61A			
	for models with Teflon Diaphragm . . . . .	PDA125-T61A			

## MAINTENANCE SECTION

PART NUMBER FOR ORDERING


PART NUMBER FOR ORDERING

25	Outer Piston (2) for models with Neoprene Diaphragm . . . . .	PDA125-B61B	35	Manifold Clamp (consists of two halves (4) for models with Neoprene Diaphragm . . . . .	PDA125-69
	for models with Teflon Diaphragm . . . . .	PDA125-T61B		for models with Teflon Diaphragm . . . . .	PDA125-S69
26	Water Chamber (2) . . . . .	PDA125-65	36	Manifold Clamp Bolt (8) for models with Neoprene Diaphragm . . . . .	PDA125-69B
27	Ball Valve (4) Neoprene . . . . .	PDA125-71		for models with Teflon Diaphragm . . . . .	PDA125-S69B
	Teflon . . . . .	PDA125-TF71	37	Manifold Clamp Nut (8) for models with Neoprene Diaphragm . . . . .	PDA125-62C
28	Ball Valve Seat (4) for models with Neoprene Diaphragm . . . . .	PDA125-70		for models with Teflon Diaphragm . . . . .	PDA125-S62C
	for models with Teflon Diaphragm . . . . .	PDA125-A70	38	Manifold Housing Screen (for models with Neoprene Diaphragm) .	PDA125-68
29	Valve Seat O-ring (for models with Teflon Diaphragm) (4) . . . . .	PDA125-70T	39	Housing Screen Mounting Screw (for models with Neoprene Diaphragm) (4) . . . . .	PDA125-68A
30	Water Chamber Clamp (consists of two halves) (2) for models with Neoprene Diaphragm . . . . .	PDA125-MP64	40	Screen Mounting Screw Washer (for models with Neoprene Diaphragm) (4) . . . . .	PDA125-68B
	for models with Teflon Diaphragm . . . . .	PDA125-MPS64	*	Nameplate for models ending in -EU . . . . .	PDA200-EU-301
31	Chamber Clamp Bolt (4) for models with Neoprene Diaphragm . . . . .	PDA125-64C		for all other models . . . . .	PDA200-301
	for models with Teflon Diaphragm . . . . .	PDA125-S64C	*	Caution Label for models ending in -EU . . . . .	EU-99
32	Chamber Clamp Nut (4) for models with Neoprene Diaphragm . . . . .	PDA125-64D		for all other models . . . . .	PDA075-33
	for models with Teflon Diaphragm . . . . .	PDA125-S39C	*	Tune-up Kit (for models with Neoprene Diaphragm) (includes illustrated parts 16[7], 23[2], 27[4], and 28[4]) . . . . .	PDA125-TK2
33	Discharge Manifold with 1-1/4" National Pipe Thread . . . . .	PDA125-66NPT			
	with 1-1/4" British Standard Pipe . . . . .	PDA125-66BSP			
34	Inlet Manifold with 1-1/2" National Pipe Thread . . . . .	PDA125-67NPT			
	with 1-1/2" British Standard Pipe . . . . .	PDA125-67BSP			

\* Not illustrated.

# Series PDA200

21



MAINTENANCE SECTION

(Dwg. TPA1235-1)

PART NUMBER FOR ORDERING 

PART NUMBER FOR ORDERING 

	Air Valve Assembly . . . . .	PDA200-LF20	23	Back-Up Diaphragm (for models with Teflon Diaphragm) (2) . . . . .	PDA200-TF24B
1	Air Valve Body (includes piston) . . . . .	PDA200-LF20A	24	Outer Piston (2) for models with Neoprene Diaphragm . .	PDA200-B21B
2	Air Valve Gasket . . . . .	PDA200-20B		for models with Teflon Diaphragm . . . .	PDA200-T21B
3	Center Block Assembly . . . . .	PDA200-P20H	25	Water Chamber (2) . . . . .	PDA200-35
4	Block Gasket (2) . . . . .	PDA200-20P	26	Ball Valve (4) Neoprene . . . . .	PDA200-41
5	Air Valve Body Mounting Screw (4) . . . . .	PDA200-20AS		Teflon . . . . .	PDA200-TF41
6	Air Valve Screen . . . . .	PDA200-20E	27	Ball Valve Seat (4) for models with Neoprene Diaphragm . .	PDA200-40
7	Reducer Bushing . . . . .	PDA200-20AP		for models with Teflon Diaphragm . . . .	PDA200-A40
8	Bottom Air Valve Cap . . . . .	PDA200-20S	28	Valve Seat O-ring (for models with Teflon Diaphragm) (4) . . . . .	PDA200-40T
9	Top Air Valve Cap (includes guide) . . . . .	PDA200-20R	29	Water Chamber Clamp (consists of two halves) (2) for models with Neoprene Diaphragm . .	PDA200-30
10	Valve Cap Retaining Ring (2) . . . . .	PDA200-520T		for models with Teflon Diaphragm . . . .	PDA200-S30
11	Valve Cap O-ring (2) . . . . .	PDA200-20U	30	Chamber Clamp Bolt (4) for models with Neoprene Diaphragm . .	PDA200-30C
15	Diaphragm Shaft for models with Neoprene Diaphragm . .	PDA200-21A		for models with Teflon Diaphragm . . . .	PDA200-S30C
	for models with Teflon Diaphragm . . . .	PDA200-T21A	31	Chamber Clamp Nut (4) for models with Neoprene Diaphragm . .	PDA200-30D
16	Diaphragm Shaft Stud (for models with Teflon Diaphragm) (2) . . . . .	PDA200-T21F		for models with Teflon Diaphragm . . . .	PDA200-S30D
17	Diaphragm Shaft O-ring (7) . . . . .	PDA200-LF20JH	32	Discharge Manifold with 2" National Pipe Thread . . . . .	PDA200-36NPT
18	Countersunk Air Chamber (2) . . . . .	PDA200-22B		with 2" British Standard Pipe . . . . .	PDA200-36BSP
19	Air Chamber Mounting Screw (3) . . . . .	PDA200-22C			
20	Air Chamber Mounting Nut (3) . . . . .	PDA200-22D			
21	Inner Piston (2) for models with Neoprene Diaphragm . .	PDA200-21B			
	for models with Teflon Diaphragm . . . .	PDA200-T21C			
22	Diaphragm (2) Neoprene . . . . .	PDA200-24			
	Teflon . . . . .	PDA200-TF24			

PART NUMBER FOR ORDERING 


PART NUMBER FOR ORDERING 

33	Inlet Manifold Housing with screened base for models having Neoprene Diaphragms with 2" National Pipe Thread ..... PDA200-37NPT with 2" British Standard Pipe ..... PDA200-37BSP with footed base for models having Teflon Diaphragms with 2" National Pipe Thread ..... PDA200-37FNPT with 2" British Standard Pipe ..... PDA200-37FBSP		38	Manifold Clamp Bolt (8) for models with Neoprene Diaphragm ... PDA200-39B for models with Teflon Diaphragm ..... PDA200-S39B	
34	Manifold Housing Screen (for models with Neoprene Diaphragm) ..... PDA200-38		39	Manifold Clamp Nut (8) for models with Neoprene Diaphragm ... PDA200-39C for models with Teflon Diaphragm ..... PDA200-S39C	
35	Housing Screen Mounting Screw (for models with Neoprene Diaphragm)(3) ..... PDA200-38A		*	Nameplate for models ending in -EU ..... PDA200-EU-301 for all other models ..... PDA200-301	
36	Suction Hook-Up Cover (for models with Neoprene Diaphragm) ..... PDA200-42		*	Caution Label for models ending in -EU ..... EU-99 for all other models ..... PDA075-33	
37	Manifold Clamp (consists of two halves)(4) for models with Neoprene Diaphragm .. PDA200-39 for models with Teflon Diaphragm .... PDA200-S39		*	Tune-up Kit (for models with Neoprene Diaphragms only)(includes illustrated items 17[7], 22[2], 26[4] and 27[4]) ..... PDA200-TK2	

\* Not illustrated.

# MAINTENANCE SECTION

## Series PDA300



(Dwg. TPA1236-1)

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

1	Air Valve Body (includes piston)	PDA300-LF1A	22	Outer Piston (2)	PDA300-B2B
2	Air Valve Cap (2)	PDA300-1R	23	Piston Assembly Bolt (12)	PDA300-2G
3	Valve Cap Retaining Ring (2)	PDA300-1T	24	Assembly Bolt Washer (12)	PDA300-68B
4	Valve Cap O-ring (2)	PDA300-1U	25	Water Chamber (2)	PDA300-50
5	Air Valve Gasket	PDA300-1B	26	Ball Valve (4)	
6	Air Valve Screen	PDA300-20E		for models with Neoprene	
7	Reducer Bushing	PDA300-20AP		Diaphragm	PDA300-55
8	Air Valve Body Mounting			for models with Viton	
	Screw (4)	PDA300-20AS		Diaphragm	PDA300-TF55
12	Center Block Assembly	PDA300-P1H	27	Ball Valve Seat (4)	
13	Center Block Gasket (2)	PDA300-1P		for models with Neoprene	
14	Diaphragm Shaft	PDA300-2A		Diaphragm	PDA300-56
15	Diaphragm Shaft O-ring (7)	PDA300-LF1JH		for models with Viton	
16	Countersunk Air Chamber (2)	PDA300-3B		Diaphragm	PDA300-VT56
17	Air Chamber Mounting Screw (4)	PDA300-3C	28	Water Chamber Clamp (consists of	
18	Air Chamber Mounting Nut (4)	PDA300-22D		two halves) (2)	PDA300-11
19	Inner Piston (2)	PDA300-2C	29	Chamber Clamp Bolt (4)	PDA300-11C
20	Inner Piston Back-up Washer (2)	PDA300-2E	30	Chamber Clamp Nut (4)	PDA300-11D
21	Diaphragm (2)				
	Neoprene	PDA300-5			
	Viton	PDA300-VT5			



## MAINTENANCE SECTION

**PART NUMBER FOR ORDERING** 

**PART NUMBER FOR ORDERING** 

31	Discharge Manifold with 3" National Pipe Thread . with 3" British Standard Pipe .	PDA300-51NPT PDA300-51BSP	38	Manifold Clamp Nut (8) . . . . .	PDA300-30D
32	Inlet Manifold Housing (for screened base) with 3" National Pipe Thread . with 3" British Standard Pipe .	PDA300-52NPT PDA300-52BSP	*	Nameplate for models ending in -EU . . . . for all other models . . . . .	PDA200-EU-301 PDA200-301
33	Inlet Manifold Housing Screen . . .	PDA300-53	*	Caution Label for models ending in -EU . . . . for all other models . . . . .	EU-99 PDA075-33
34	Housing Screen Mounting Screw (3) . . . . .	PDA300-38A	*	Tune-up Kit (for models with Neoprene Diaphragm) (includes illustrated items 15[7], 21[2], 26[4] and 27[4]) . . . . .	PDA300-TK2
35	Suction Hook-up Cover . . . . .	PDA300-57			
36	Manifold Clamp (consists of two halves) (4) . . . . .	PDA300-54			
37	Manifold Clamp Bolt (8) . . . . .	PDA300-54B			

\* Not illustrated.

## MAINTENANCE SECTION

### ⚠ WARNING


Always wear protective eyewear when operating or servicing one of these Pumps. If a diaphragm failure should occur, the material being pumped may be forced out the air exhaust.

### DISASSEMBLY OF SERIES PDA075

### ⚠ WARNING

Before attempting any maintenance or repair, shut off the air supply and disconnect the air supply hose at the Pump. Failure to do so could result in injury.

1. Disconnect all suction lines and discharge lines.
2. Stand the Pump upright on the workbench, with the discharge manifold nipple facing you.
3. Using a felt-tipped marking pen, draw an index line across the outer edge of the Water Chambers (20) and Center Block (7). Mark the left and right Water Chamber "L" and "R" respectively. These marks will help in alignment during assembly. Refer to Drawing TPD810-1.




(Dwg. TPD810-1)

4. Using a 9/16" wrench, unscrew the four manifold bolt nuts and remove the four Manifold Bolt Assemblies (26) that hold the Pump together.
5. Lift off the Discharge Manifold (24).
6. Remove the two discharge Ball Valves (21), Ball Valve Seats (22) and Valve Seat O-rings (23).
7. Grasp both Water Chambers and lift the entire midsection from the Inlet Manifold (25).
8. Pull the two Water Chambers away from the center assembly.
9. Remove the two intake Ball Valves, Ball Valve Seats and Valve Seat O-rings.
10. Set the center assembly on end on the workbench.

**For Pumps with a Neoprene Diaphragm**, using a wrench on the hex of the Outer Piston (19), unscrew the Outer Piston and remove the Diaphragm (17) and Inner Piston (16). Refer to drawing TPD811.


## MAINTENANCE SECTION

**For Pumps with a Teflon Diaphragm**, using a wrench on the hex of the Piston Shaft (15), unscrew the Shaft and remove the Outer Piston (19), Diaphragm (17), Back-Up Diaphragm (18) and Inner Piston (16). Refer to Drawing TPD811.



(Dwg. TPD811)

11. Turn the center assembly over and pull the remaining assembled Diaphragm along with the Diaphragm Shaft (13) away from the Center Block (7). Refer to Drawing TPD812-1.



(Dwg. TPD812-1)

12. Grip the Diaphragm Shaft in leather-covered vise jaws or clamp it between two wooden blocks with the Diaphragm upward.  
**For Pumps with a Neoprene Diaphragm**, using a wrench on the hex of the Outer Piston, unscrew the Outer Piston and remove the Diaphragm and Inner Piston.  
**For Pumps with a Teflon Diaphragm**, using a wrench on the hex of the Piston Shaft, unscrew the Shaft and remove the Outer Piston, Diaphragm, Back-Up Diaphragm and Inner Piston.
13. Using an O-ring pick, remove the four Diaphragm Shaft O-rings (14) from the grooves in the bushing in the Center Block.
14. Unscrew and remove the four Air Valve Mounting Screw Nuts (12) and pull the Muffler (10) and Muffler Plate (9) away from the Center Block. Remove the Muffler Plate Gasket (8).
15. Remove the four Air Valve Body Mounting Screws (11), Air Valve Body (1) and Air Valve Gasket (6) from the Center Block.

## MAINTENANCE SECTION


16. Inspect the air valve piston for wear and free movement in the bore in the Air Valve Body. The piston must move freely when the Air Valve Body is turned vertically end for end. The piston should have a dull anodized appearance, and be free of surface defects. If the anodized surface is worn through on the ported face, the piston is worn beyond tolerance and the entire assembled Air Valve must be replaced or returned to the factory for rebuilding.

### NOTICE

**New air valve pistons are not available as replacements for worn pistons. If the piston is worn beyond tolerance, the Air Valve Body is also worn beyond tolerance and installation of a new piston will result in erratic pump operation and excessive air consumption. A worn Air Valve Body can be rebuilt one time at the factory.**


### ASSEMBLY OF SERIES PDA075

1. Moisten four new Diaphragm Shaft O-rings (14) with O-ring lubricant, and install them in the grooves in the diaphragm shaft bushing. Note that there are six grooves in the bushing. Install the O-rings in grooves 1,3,4 and 6 starting from either end of the bushing. Refer to Drawing TPD813.



(Dwg. TPD813)

2. Using new Air Valve Cap O-rings (5), moisten them with O-ring lubricant and Install a new O-ring in each Air Valve Cap (2 and 3).
3. Install the Top Air Valve Cap with the guide pin in the Air Valve Body (1) as shown in Drawing TPD833. Do not replace the snap ring at this time.




(DWG. TPD833)

4. Slide the air valve piston into the bore of the Air Valve Body making certain to align the guide pin in the piston with the guide pin on the Top Air Valve Cap.


## MAINTENANCE SECTION

5. Look through the ports in the machined face of the Air Valve Body and see if the ports are aligned with the ports in the air valve piston. If the ports are not aligned, insert a drift pin in the hole in the bottom of the piston and rotate both the air valve piston and Top Air Valve Cap until the ports are aligned. Refer to Drawing TPD834.



(Dwg. TPD834)

6. Install the Bottom Air Valve Cap (2) and both Valve Cap Retaining Rings (4).
7. Align the Air Valve Gasket (6) against the Air Valve Body, and secure the Air Valve Body and piston against the Center Block (7) with the four Air Valve Body Mounting Screws (11). Position the Muffler Plate Gasket (8) and Muffler Plate (9) against the opposite side of the Center Block. Refer to Drawing TPD835. Secure the assembly with the four Mounting Screw Nuts (12) and install the Muffler (10).




**NOTE:** BE SURE THAT VALVE GASKET IS INSTALLED WITH HOLES IN GASKET ON TOP OF HOLES IN CENTER BLOCK.


(Dwg. TPD835)

## MAINTENANCE SECTION

8. Note that one side of each Diaphragm (17) is marked “This Side Out”. Install one Diaphragm and its associated parts on the Diaphragm Shaft (13) in the sequence and orientation shown in Drawing TPD814-1. Hand tighten the assembly.



**Assembly of Neoprene Diaphragm**



(Dwg. TPD814-1)

**Assembly of Teflon Diaphragm**


9. Set the assembled Diaphragm and Diaphragm Shaft on the workbench with the Diaphragm downward.
10. Wipe the Diaphragm Shaft with a thin film of Ingersoll-Rand No. 10 Oil.
11. Being careful not to damage the Diaphragm Shaft O-rings, slide the Center Block down over the Diaphragm Shaft.
12. Install the second Diaphragm and its associated parts in the sequence and orientation shown in drawing TPD814-1. Make certain that the side of the Diaphragm marked “This Side Out” faces away from the Diaphragm Shaft.
13. Using two wrenches, tighten both Outer Pistons or Piston Shafts by simultaneously turning the wrenches in opposite directions.

### NOTICE

**Tighten the Outer Pistons or Piston Shafts to 20 ft-lb (27 Nm) torque.**


## MAINTENANCE SECTION

14. Install the Ball Valve (21), Ball Valve Seat (22) and Valve Seat O-ring (23) in the lower boss of each Water Chamber (20). Tap the Valve Seat with a mallet to firmly seat the parts. Refer to Drawing TPD816.



(Dwg. TPD816)

15. Push the right side Diaphragm Shaft into the Center Block to fully extend the Diaphragm on the left side. Make certain the outer bead of the Diaphragm is inside the groove in the center block face at the outer edge of the largest part of the Center Block. Refer to Drawing TPD818-1.




(Dwg. TPD818-1)

16. Position the left Water Chamber on the workbench surface with the diaphragm end upward.
17. Place the assembled Center Block, fully extended Diaphragm first, onto the left Water Chamber. Make certain the marks on the Center Block align with the marks on the Water Chamber.
18. While holding the Center Block against the left Water Chamber, insert a pry bar under the right Diaphragm and pull the Diaphragm Shaft through the Center Block to fully extend the right Diaphragm.
19. After removing the pry bar, make certain the outer bead of the right Diaphragm is inside the groove in the center block face at the outer edge of the largest part of the Center Block.

## MAINTENANCE SECTION

20. Place the right Water Chamber on on the Center Block making certain that the marks on the Center Block align with the marks on the Water Chamber. Refer to Drawing TPD819-1.




(Dwg. TPD819-1)

21. Place the Inlet Manifold (25) on the workbench so that the inlet nipple is **facing away from you**.  
22. Carefully pick up the entire center assembly and place in on the Inlet Manifold so that the Muffler Plate (9) is **facing toward you**.

### NOTICE

**In order to facilitate final assembly of the Pump and to prevent leakage, make certain that the center assembly is aligned side-to-side and front-to-back on the Inlet Housing. This is very critical and must be done as exact as possible. Refer to Drawing TPD820-1.**




(Dwg. TPD820-1)

23. Install the Ball Valves. Ball Valve Seats and Valve Seat O-rings in the Discharge Manifold (24), and set the Discharge Manifold on the Pump with the discharge nipple facing you. Carefully align the Discharge Manifold on the Water Chambers and press down firmly.



## MAINTENANCE SECTION

24. Install the four Manifold Bolt Assemblies (26) on the Discharge Manifold. Thread the Nuts on two or three threads. Make no attempt to fit the Bolts into the Intake Manifold at this time. Refer to Drawing TPD821-1.




(Dwg. TPD821-1)

25. After all four Manifold Bolts have been installed, press down on the Discharge Manifold with one hand and, with the other hand, pull two of the Bolts on one side into their slots on the Intake Manifold, making certain both Bolts snap over their respective guide on the Water Chamber. Install the other two Manifold Bolts in the same manner.
26. Tighten the Manifold Bolt Nuts in a crisscross pattern, making certain to maintain the alignment between the Inlet Housing and Water Chambers, and the Discharge Manifold and Water Chambers. Refer to Drawing TPD822-1.

### NOTICE

**Tighten the Manifold Bolt Nuts to 15 ft-lb (20 Nm) torque.**



(Dwg. TPD822-1)

## MAINTENANCE SECTION


27. Test the Pump by connecting the air supply line and running it dry. You should have good suction at the inlet housing nipple, approximately 15 inches gauge for Pumps with Neoprene Diaphragms, and 10 inches gauge for Pumps with Teflon Diaphragms.

### DISASSEMBLY AND ASSEMBLY OF SERIES PDA125, PDA200 AND PDA300

#### **⚠ WARNING**

**Before attempting any maintenance or repair, shut off the air supply and disconnect the air supply hose at the Pump. Failure to do so could result in injury.**

Do not disassemble one of these Pumps any further than necessary to replace worn or damaged parts. To replace the Ball Valves and Ball Valve Seats, it is necessary to remove only the Discharge Manifold and Inlet Manifold. If you are going to replace the Diaphragms, replace the Diaphragm on one side of the Pump and then reassemble that side of the Pump before replacing the other Diaphragm.



(Dwg. TPD823-1)


#### **Replacement of the Ball Valves and Ball Valve Seats**

1. Loosen the Small Band Clamps that secure the Discharge Manifold to the Water Chambers, and lift off the Discharge Manifold.
2. Lift off the Ball Valves, and withdraw the Ball Valve Seat from each Water Chamber.
3. Install a new Ball Valve Seat in each Water Chamber, and set a new Ball Valve on each Seat.
4. Replace the Discharge Manifold and secure it with the Small Band Clamps.
5. Loosen the Small Band Clamps that secure the Water Chambers to the Inlet Manifold, and lift off the upper portion of the Pump.
6. Lift off the Ball Valves, and withdraw the Ball Valve Seats from the Inlet Manifold.
7. Install a new Ball Valve Seat in each side of the Inlet Manifold, and set a new Ball Valve on each Seat.
8. Set the top portion of the Pump back onto the Inlet Manifold and secure it with the Small Band Clamps.

## MAINTENANCE SECTION


### Replacement of the Diaphragms

1. Stand the Pump upright on the workbench, with the discharge manifold nipple facing you.
2. Using a felt-tipped marking pen, draw an index line across the outer edges of the Water Chambers and Air Chambers. Mark the left and right Chambers "L" and "R" respectively. These marks will help in alignment during assembly. Refer to Drawing TPD824.



(Dwg. TPD824)

3. Remove the two Small Band Clamps that attach the Discharge Manifold to the Water Chambers, and lift off the Discharge Manifold and the two Ball Valves.
4. Look down through the opening of both Water Chambers and see which chamber has the Diaphragm extended furthest toward the outer wall of the Water Chamber. This is the side which should be removed first since it will have the Diaphragm in its normal, unflexed position. Refer to Drawing TPD825-1.



(Dwg. TPD825-1)


5. Remove the Large Band Clamp that secures the Water Chamber to the Air Chamber, and the Small Band Clamp that secures the Water Chamber to the Inlet Manifold.
6. Pull the Water Chamber away from the Air Chamber and examine the exposed Diaphragm.
7. If the Diaphragm needs replacement, unscrew and remove the Outer Piston.

## MAINTENANCE SECTION

8. Install the new Diaphragm and its associated parts on the end of the Diaphragm Shaft in the sequence and orientation shown in the appropriate following drawings.


### CAUTION

For Series PDA300 models, the twelve Piston Assembly Bolts (23) must be tightened to 18 ft-lb (25 Nm) torque.



### Installation of Diaphragm of Series PDA125


(Dwg. TPD826-1)



### Installation of Diaphragm on Series PDA200

(Dwg. TPD827-1)

## MAINTENANCE SECTION




### Installation of Diaphragm on Series PDA300

(Dwg. TPD829-1)

9. Set the intake Ball Valve on the Ball Valve Seat in the Intake Manifold.
10. Place the Water Chamber on the Inlet Manifold and secure it with the Small Band Clamp.
11. Install the large Band Clamp that secures the Water Chamber to the Air Chamber.
12. Replace the second Diaphragm as described in Steps 3 through 11.
13. After both Diaphragms have been replaced, set the discharge Ball Valves on the Ball Valve Seat in each of the Water Chambers.
14. Replace the Discharge Manifold and secure it with the Small Band Clamps.

### Disassembly of Series PDA125, PDA200 and PDA300


1. Remove one Diaphragm as described in Steps 1 through 7 of the section **Replacement of the Diaphragms**.
2. Remove the large Band Clamp that secures the Air Chamber to the second Water Chamber, and pull the Water Chamber away.
3. Grasp the remaining Diaphragm, and pull the Diaphragm and Diaphragm Shaft from the Center Block Assembly. Refer to drawing TPD830-1.



(Dwg. TPD830-1)

## MAINTENANCE SECTION

4. Grasp the Diaphragm Shaft in leather-covered vise jaws or between two blocks of wood, and remove the second Diaphragm. Refer to Drawing TPD831.



(Dwg. TPD831)


5. If there is any question about the age or condition of the Diaphragm Shaft O-rings in the Center Block Bushing, remove the O-rings with an O-ring pick.
6. Remove the four Air Valve Body Mounting Screws that attach the Air Valve Body and piston to the Center Block Assembly.
7. The anodized aluminum air valve piston should move freely in the bronze bushing. If the Piston does not move freely, immerse the complete Air Valve and piston into a nonflammable, nontoxic solvent. This should remove any accumulation of oil and dirt.
8. Remove the snap ring from the top end of the Air Valve Body and apply a jet of air to the 3/16" hole in the opposite end of the Body. This will cause the piston to strike the Air Valve Cap and drive it from the Air Valve Body.

### WARNING

Make certain the Air Valve Cap and piston are expelled in a direction that will avoid injury. Directing the components into a corrugated pasteboard box or other cushioned area will minimize damage to the parts.

### NOTICE

New air valve pistons are not available as replacements for worn pistons. If there is more than .010" clearance between the piston and the bore of the Air Valve Body or if the anodize is worn from the back of the piston, the complete Air Valve Assembly should be returned to the factory for rebuilding. Refer to drawing TPD832-1.




(Dwg. TPD832-1)

9. Remove the snap ring and push the Air Valve Cap from the other end of the Air Valve Body.
10. Remove and discard the O-rings from both Air Valve Caps.
11. Remove the air inlet bushing and withdraw the Air Valve Screen.
12. Wash the Air Valve Screen in a good nontoxic, nonflammable solvent and remove all dirt and scale.

## MAINTENANCE SECTION


### Assembly of Series PDA125, PDA200 and PDA300

1. Replace the Air Valve Screen. If the Air Valve Screen is damaged in any respect, or could not be unclogged, install a new Air Valve Screen.
2. Using new Air Valve Cap O-rings, moisten them with O-ring lubricant and install a new O-ring in each Air Valve Cap.
3. Install the Top Air Valve Cap with the guide pin in the Air Valve Body as shown in Drawing TPD833. Do not replace the snap ring at this time.



(Dwg. TPD833)


4. Slide the air valve piston into the bore of the Air Valve Body making certain to align the guide pin hole in the piston with the guide pin on the Top Air Valve Cap.
5. Look through the ports in the machined face of the Air Valve Body and see if the ports are aligned with the ports in the air valve piston. If the ports are not aligned, insert a drift pin in the hole in the bottom of the piston and rotate both the air valve piston and Top Air Valve Cap until the ports are aligned. Refer to Drawing TPD834.




(Dwg. TPD834)

## MAINTENANCE SECTION

6. Install the Bottom Air Valve Cap and both Valve Cap Retaining Rings.
7. Align the Air Valve Gasket against the Air Valve Body, and secure the Air Valve Body and piston to the Center Block Assembly with the four Air Valve Body Mounting Screws and Mounting Screw Nuts. Refer to Drawing TPD835.



8. If the O-rings were removed from the Center Block Bushing, moisten new O-rings with O-ring lubricant and install them in grooves 1, 2, 4, 6, 8, 10 and 11, starting from either end of the Bushing. Refer to Drawing TPD836.



9. Grasp the Diaphragm Shaft in leather-covered vise jaws, or between two blocks of wood as shown in Drawing TPD831.
10. Install one Diaphragm on the end of the Diaphragm Shaft in the sequence and orientation shown in Drawing TPD826-1, TPD827-1 or TPD829-1.
11. Moisten the Diaphragm Shaft with Ingersoll-Rand No. 10 Oil, and insert it through the Center Block Bushing as shown in Drawing TPD830-1.
12. Remove the assembly from the vise. Turn the assembly over and push the Center Block downward to expose the unassembled end of the Diaphragm Shaft.
13. Install the second Diaphragm on the Diaphragm Shaft in the sequence and orientation shown in Drawing TPD826-1, TPD827-1 or TPD829-1.
14. Using two wrenches, tighten both Outer Pistons by simultaneously turning the wrenches in opposite directions.

### NOTICE

**Tighten the Outer Pistons of each pump to the following torques:**

For Series PDA125 .....	50 ft-lb (68 Nm) torque
For Series PDA200 .....	75 ft-lb (102 Nm) torque
For Series PDA300 .....	90 ft-lb (122 Nm) torque




## MAINTENANCE SECTION

15. With the Diaphragm in the full stroke position as shown in Drawing TPD837-1, pull the lip of the Diaphragm down into the groove in the Air Chamber.
16. While leaving the Diaphragm fully extended, install the Water Chamber to that side of the Pump, making certain to align the index mark on the Water Chamber with that on the Air Chamber. Secure it with a Large Band Clamp. Tap the Large Band Clamp with a soft mallet around the rim to assure positive and even seating.

### NOTICE


**Tighten the Large Band Clamp fasteners of each pump to the following torques:**

For Series PDA125 .....	5 ft-lb (7 Nm) torque
For Series PDA200 .....	20 ft-lb (27 Nm) torque
For Series PDA300 .....	55 ft-lb (75 Nm) torque



(Dwg. TPD837-1)


17. Turn the assembly over and using a claw-bar or similar lever, pull the Diaphragm Shaft through the bushing as far as possible. Refer to Drawing TPD838.



(Dwg. TPD838)

## MAINTENANCE SECTION

18. With the Diaphragm in the full stroke position as shown in drawing TPD837-1, pull the lip of the Diaphragm down into the groove in the Air Chamber.
19. Install the second Water Chamber, making certain the index mark on the Water Chamber is aligned with the index mark on the Air Chamber. Secure it with a Large Band Clamp. Tap the Large Band Clamp with a soft mallet around the rim to assure positive and even seating. Tighten the Large Band Clamp to the same torque as the previous Clamp.
20. If the Water Chambers have been installed correctly, the intake and discharge openings will be flat and parallel to each other. Place the assembly on a flat surface and check to make certain these members are properly aligned. Refer to Drawing TPD840.



(Dwg. TPD840)


21. Install a Ball Valve Seat in each side of the Inlet Manifold, and set a Ball Valve on each Seat.
22. Set the assembled portion of the Pump on the Inlet Manifold, and secure it with the Small Band Clamps.

### NOTICE

**Tighten the Manifold Clamp fasteners of each pump to the following torques:**

For Series PDA125 .....	50 in-lb (6 Nm) torque
For Series PDA200 .....	50 in-lb (6 Nm) torque
For Series PDA300 .....	100 in-lb (11 Nm) torque

23. Install a Ball Valve Seat in each Water Chamber and set a Ball Valve on each Seat.
24. Set the Discharge Manifold on the Water Chambers, and secure it with the Manifold Clamps. Tighten the Manifold Clamps to the same torque as the previous Clamps.
25. The Pump is now ready for use. Connect a 1/2" air supply line to the Pump and, using 90 psig of air, run the Pump dry. It should cycle approximately 150 times a minute.



**Cutaway View of Air Valve Assembly**

(Dwg. TPD841-1)

## **MAINTENANCE SECTION**

<b>TROUBLESHOOTING GUIDE</b>		
<b>Trouble</b>	<b>Probable Cause</b>	<b>Solution</b>
Pump will not run or runs slowly.	Clogged Air Valve Screen	Remove the Air Valve Screen and clean it in good nonflammable, nontoxic solvent.
	Sticky Air Valve	Flush the Air Valve Screen by inserting some solvent in the air inlet and operating the Pump for a few minutes. After the Air Valve is loosened up, lubricate it by putting some Ingersoll-Rand No. 10 Oil in the air inlet.
	Worn Air Valve	Check the Air Valve Piston for wear. If it is worn, return the entire Air Valve Assembly to the factory for rebuilding.
	Center Block O-rings are worn	Install new O-rings
Pump runs but there is little or no flow.	Pump is pumping faster than material can flow	Check the stroke rate of the Pump and slow it down if necessary, to handle dry materials.
	Sticking Ball Valves	If the material being pumped is not compatible with the Ball Valve and Seats, these members may swell. Replace the Ball Valves and Seats with those of the proper material.
	Loose suction connections	Make certain all suction connections are airtight. Tighten the Small Band Clamps that secure the Water Chambers to the Inlet Housing.
Pump Air Valve freezes.	Excessive moisture in the air	Install a dryer for the compressed air, or fill the Oil Reservoir with an anti-freeze such as Tanner-gas or Killfrost.
Air bubbles in pump discharge.	Ruptured Diaphragm	Install a new Diaphragm if necessary.
	Band Clamps are loose	Tighten the Band Clamps, especially those that secure the Water Chambers to the Intake Housing.
Fluid comes out air exhaust.	Ruptured Diaphragm	Install new Diaphragm if necessary.

### **NOTICE**

**SAVE THESE INSTRUCTIONS. DO NOT DESTROY.**