

SERIES 6F ANGLE WRENCHES

NONREVERSIBLE MODELS

6WTR3F
6WTQ3F

REVERSIBLE MODELS

6WRTR3F
6WRTQ3F

Always operate, inspect and maintain this tool in accordance with American National Standards Institute Safety Code for Portable Air Tools (ANSI B186.1) and any other applicable safety codes and regulations.

The delivered torque of this Angle Wrench can be effectively controlled by regulating the inlet air pressure between 50 psig (3.4 bar/340 kPa) and 85 psig (6.2 bar/620 kPa). Operating the Wrench at pressures outside this range will result in inefficient operation, and operating the Wrench on higher pressures will cause premature wear.

Operate this Wrench using 3/8" (10 mm) inside diameter air supply hose.

⚠ WARNING

Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool. Failure to do so could result in injury.

LUBRICATION

Adequate lubrication is imperative for maximum performance and durability of the gearing in these Tools.

Oil: Ingersoll-Rand No. 10 Lubricant.

Grease: Ingersoll-Rand No. 67 Lubricant.

The use of an air line lubricator is recommended. Where the lubricator cannot be permanently mounted, we recommend using an Ingersoll-Rand No. 8LUB12 Lubricator. For permanent installations, we recommend using an Ingersoll-Rand No. NFLRU-4 Filter-Lubricator-Regulator Unit. Adjust the lubricator so there is a slight oil mist in the exhaust.

If an air line lubricator is not used, inject 2 cc of the recommended oil into the air inlet before attaching the air hose and after each eight hours of operation.

After each 50 000 cycles, or one month of operation, inject 3 to 4 cc of the recommended grease into the Grease Fitting (57) in the Gear Case (56).


After each eight hours of operation, inject 1 to 2 cc of the recommended grease into the Grease Fitting (102) in the Angle Housing Assembly (101).

SHUTOFF VALVE ADJUSTMENT PROCEDURE

⚠ WARNING

Adjustment to the Shutoff Valve system is preset at the factory. Do not adjust any part of the Valve unless, after prolonged use of the Tool, the Tool shuts off prematurely or the Tool fails to shut off. Only if either of these conditions exists are you to adjust the Valve. Adjust the Valve according to the procedures below.

1.



(Dwg. TPD1071)

Figure 1

Turn the Regulator Adjustment Screw until the top of the Screw is approximately two threads below the face of the Regulator Body. Set the Bleed Adjustment Screw approximately four threads below the face of the Regulator Body.

Notice: The use of other than genuine Ingersoll-Rand replacement parts may result in decreased tool performance and increased maintenance, and may invalidate all warranties.


Refer All Communications to the Nearest
Ingersoll-Rand Office or Distributor.

© Ingersoll-Rand Company 1987

Printed in U.S.A.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

2.




(Dwg. TPD1074)

Figure 2

Cycle the tool on a test joint to test for shutoff.

3.




(Dwg. TPD1072)

Figure 3

a. If the tool fails to shut off, turn the Bleed Adjustment Screw clockwise a little at a time, until consistent shutoff occurs. If no shutoff occurs, reset the Bleed Adjustment Screw four turns under flush. (See Figure 3). Set the Regulator Adjustment Screw 1/4 turn deeper and repeat steps 2 and 3. (See Figure 1).

b. If tool shutoff occurs, turn the Bleed Adjustment Screw counterclockwise until the tool stalls on a test joint. When the tool stalls, rotate the Bleed Adjustment Screw clockwise, a little at a time, until consistent shutoff occurs. (See Figure 3).

4.




(Dwg. TPD1075)

Figure 4

Cycle the tool on a test joint to test for shutoff.

5.



(Dwg. TPD1073)


Figure 5

a. If the tool fails to shut off, turn the Regulator Adjustment Screw clockwise, a little at a time, until consistent shutoff occurs. (See Figure 5).

b. If tool shutoff occurs, turn the Regulator Adjustment Screw counterclockwise until the tool stalls on a test joint. When the tool stalls, rotate the Regulator Adjustment Screw clockwise 1/8 of turn at a time until consistent shutoff occurs. This adjustment provides maximum torque output at shutoff. (See Figure 5).

6. It is possible that the tool might shut off when the throttle is depressed. This condition is a premature shutoff and can be corrected by turning the Bleed Adjustment Screw counterclockwise a little at a time until the premature shutoff condition is corrected. (See Figure 3).

If the Bleed Adjustment Screw was used to correct a premature shutoff condition, retest the tool for shutoff at 55 and 90 psig. If necessary, repeat steps 2 through 5. (See Figures 2, 3, 4 and 5).



Power Unit

PART NUMBER FOR ORDERING


PART NUMBER FOR ORDERING

	Motor Housing Assembly				
	for 6WRT	6WRT-A40	36	Rear End Plate	
	for 6WT (except Model 6WTQ3F)	6WT-A40		for 6WRT	6WRT-12
	for 6WTQ3F	6WTF-A40		for 6WT	6WTF-12
1	Motor Housing		37	Rotor	
	for 6WRT	6WRT-B40		for Q ratio (12 teeth)	6WTQF-53
	for 6WT (except Model 6WTQ3F)	6WT-B40	• 38	for R ratio (9 teeth)	6WTRF-53
	for 6WTQ3F	6WTF-B40	39	Vane Packet (set of 5 Vanes)	6WT-42-5
2	Throttle Plunger Bushing	5RLK2C-91		Cylinder	
3	Reverse Valve Bushing Retainer (for 6WRT and 6WTQ3F)	6WRT-667		for 6WRT	6WRT-3
4	Throttle Lever	7L-273	40	for 6WT	6WT-3
5	Throttle Lever Pin	7L-120	41	Front End Plate	6WTF-11
	Throttle Plunger Assembly	6WT-A94	• 42	Cylinder Dowel	6WT-98
6	Throttle Plunger	6WT-94		Front Rotor Bearing	ROOH-97
• 7	Throttle Plunger Seal	8SL-259	43	Spindle Assembly	6LP-A8
8	Throttle Valve Seat	7RAK-303	44	Spindle	6LP-8
9	Throttle Valve Seat Support	7RAK-304	• 45	Seal Support	5RAK-5
10	Throttle Valve	7RAK-302	46	Seal	182A53-610
11	Throttle Valve Spring	7L-51	47	Spindle Planet Gear Assembly (3) (18 teeth)	6WTP-A10
12	Silencer Seal Ring	WWV100A1-43	48	Spindle Planet Gear Bearing (1 for each Gear)	WFS182-654
• 13	Exhaust Deflector Seal	RO0A2-103	50	Gear Retainer	6LL-81
14	Rear Muffler	6WT-A23		Gear Head	
• 15	Muffler Element	3RA-310		for Q ratio (marked Q)	6LQ-216
16	Inlet Bushing Spacer	7AH-65	51	for R ratio (marked R)	6LR-216
17	Inlet Bushing	7L-565		Gear Head Planet Gear Assembly (3)	
• 18	Air Strainer Screen	ROA2-61		for Q ratio (18 teeth)	6WTP-A10
19	Reverse Valve (for 6WRT)	6WRT-329	52	p for R ratio (20 teeth)	6WTK-A10
20	Lock Pin Retainer (for 6WRT)	7RL-56		Gear Head Planet Gear Bearing (1 for each Gear)	
21	Reverse Valve Lock Pin (for 6WRT)	SPA102R-668	55	for Q ratio	WFS182-654
22	Retainer Setscrew			for R ratio	7AJ-500
	for 6WRT	7RL-669	56	Gear Head Spacer	6LM-80
	for 6WTQ3F	R2J-561	57	Gear Case Assembly	6WTM-A37
23	Reverse Valve Spring (for 6WRT)	55RP-515	58	Gear Case	6WTM-B37
24	Shutoff Valve	6WT-172	59	Grease Fitting	D0F9-879
25	Shutoff Valve Stop	6WT-176	60	Grease Fitting Collar	6WT-880
26	Shutoff Valve Spring	6WT-171	61	Grease Shield	5R-701
	Regulator Body Assembly	6WT-A173	62	Grease Shield Retainer	6LL-343
27	Regulator Body	6WT-173	63	Spindle Bearing	R1L-24
28	Regulator Spring	6WT-180	• 64	Spindle Bearing Retainer	7L-28
29	Regulator Adjustment Screw	6WT-174	65	Muffler Element	6WT-311
30	Pressure Port Plug	5081T-266	• 66	Exhaust Deflector	6WT-23
31	Bleed Adjustment Screw	6WT-175		Exhaust Deflector Seal (2)	AG20-103
32	Regulator Body Seal	182A53-610	*	Deflector Retaining Ring	6WT-203
• 33	Rear End Plate Gasket	6WRT-739	*	Horizontal Hanger	6WS-366
• 34	Rear Rotor Bearing Retaining Nut	6WT-118	*	Vertical Hanger	7L-365
• 34A	Bearing Thrust Washer	6WTF-117	*	Grease Gun	RO00A2-228
35	Rear Rotor Bearing	DG20-22		Tune-up Kit (includes illustrated items 7, 8, 9, 10, 11, 12, 13, 14, 18, 32, 33, 34, 34A, 35, 38, 42, 45, 63 and 65 [2])	6WT-TK1

* Not illustrated.

• To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (•) for every four tools in service.

GEARING AND ANGLE ATTACHMENT



(Dwg. TPA1224)

PART NUMBER FOR ORDERING

		7L3D6
	Angle Attachment	7L3D6
101	Angle Housing Assembly	7L3A-B550
102	Grease Fitting	DOF9-879
103	Angle Housing Cap	8SA32-110
● 104	Upper Spindle Bearing	8SA32-603
● 105	Matched Bevel Gear Set	7L3A-A552
● 106	Bevel Pinion Bearing	182A53-606
107	Rear Thrust Bearing Seat	7L2A-682
● 108	Bearing Seat Retainer	1415A12-6
109	Front Thrust Bearing Seat	141A12-683
● 111	Bearing Spacer Retainer	182A53-685
112	Bevel Pinion Thrust Bearing	161A32-105
● 113	Lower Spindle Bearing	8SA-593
● 114	Bevel Gear Retainer	8SA32-578
115	Bevel Pinion Bearing Spacer	182A53-165
118	Socket Adapter Spindle Assembly (3/8" Square Drive)	8SA32-P507-3/8
*	Socket Retaining Spring	401-718
*	Socket Retaining Pin	5020-716
120	Spindle Bearing Cap	8SA32-531
121	Coupling Nut Retainer	5C1-29
122	Coupling Nut	7L-27
*	Lower Bearing Cap Wrench	8SA32-26
*	Bearing Inserting Tool	7L3A-950

* Not illustrated.

● To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (●) for every four tools in service.

