

03537818


Form P6934
Edition 7
September, 1999F
E
P

OPERATION AND MAINTENANCE MANUAL FOR SERIES TD, TX AND TXD GRINDERS

NOTICE

Series TD, TX and TXD Grinders are designed for close-quarter work in the metal fabricating industry, shipyards, pipe fabrication, die manufacturing and limited space applications. They are particularly good where conduits, pipes, ducts, etc. pass through bulkheads or frames. These small Grinders are very efficient for grinding weld bead and leaving a fine finish.

Ingersoll-Rand is not responsible for customer modification of tools for applications on which Ingersoll-Rand was not consulted.



WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.
READ THIS MANUAL BEFORE OPERATING TOOL.**

**IT IS THE RESPONSIBILITY OF THE EMPLOYER TO PLACE THE INFORMATION
IN THIS MANUAL INTO THE HANDS OF THE OPERATOR.**

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

PLACING TOOL IN SERVICE

- Always operate, inspect and maintain this tool in accordance with American National Standards Institute Safety Code for Portable Air Tools (ANSI B186.1).
- For safety, top performance, and maximum durability of parts, operate this tool at 90 psig (6.2 bar/620 kPa) maximum air pressure at the inlet with 3/8" (10 mm) inside diameter air supply hose.
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.
- Do not use damaged, frayed or deteriorated air hoses and fittings.
- Be sure all hoses and fittings are the correct size and are tightly secured. See Dwg. TPD905-1 for a typical piping arrangement.
- Always use clean, dry air at 90 psig maximum air pressure. Dust, corrosive fumes and/or excessive moisture can ruin the motor of an air tool.
- Do not lubricate tools with flammable or volatile liquids such as kerosene, diesel or jet fuel.
- Do not remove any labels. Replace any damaged label.

USING THE TOOL

- Always wear eye protection when operating or performing maintenance on this tool.
- Always wear hearing protection when operating this tool.
- Keep hands, loose clothing and long hair away from rotating end of tool.
- Anticipate and be alert for sudden changes in motion during start up and operation of any power tool.
- Keep body stance balanced and firm. Do not overreach when operating this tool. High reaction torques can occur at or below the recommended air pressure.
- Tool accessories may continue to rotate briefly after throttle is released.
- Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.
- Use accessories recommended by Ingersoll-Rand.
- This tool is not designed for working in explosive atmospheres.
- This tool is not insulated against electric shock.

NOTICE

The use of other than genuine Ingersoll-Rand replacement parts may result in safety hazards, decreased tool performance, and increased maintenance, and may invalidate all warranties.

Repairs should be made only by authorized trained personnel. Consult your nearest Ingersoll-Rand Authorized Servicenter.

Refer All Communications to the Nearest
Ingersoll-Rand Office or Distributor.

© Ingersoll-Rand Company 1999

Printed in U.S.A.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

WARNING LABEL IDENTIFICATION

! WARNING

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

	! WARNING		! WARNING		! WARNING
	Always wear eye protection when operating or performing maintenance on this tool.		Always wear hearing protection when operating this tool.		Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.
	! WARNING		! WARNING		! WARNING
	Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.		Do not carry the tool by the hose.		Do not use damaged, frayed or deteriorated air hoses and fittings.
	! WARNING		! WARNING		
	Keep body stance balanced and firm. Do not overreach when operating this tool.		Operate at 90 psig (6.2 bar/ 620 kPa) Maximum air pressure.		

GRINDER SPECIFIC WARNINGS

! WARNING

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

- Do not use this tool if actual free speed exceeds the nameplate rpm.
- Before mounting a wheel, after any tool repair or whenever a Grinder is issued for use, check free speed of Grinder with a tachometer to make certain its actual speed at 90 psig (6.2 bar/620 kPa) does not exceed rpm stamped or printed on the nameplate. Grinders in use on the job must be similarly checked at least once each shift.
- Always use the recommended Ingersoll-Rand Wheel Guard furnished with the Grinder.
- Do not use any grinding wheel, bur or other accessory having a maximum operating speed less than the free speed of the Grinder in which it is being used. Always conform to maximum rpm on grinding wheel blotters.
- Inspect all grinding wheels for chips or cracks prior to mounting. Do not use a wheel that is chipped or cracked or otherwise damaged. Do not use a wheel that has been soaked in water or any other liquid.
- Make certain grinding wheel properly fits the arbor. Do not use reducing bushings to adapt a wheel to any arbor unless such bushings are supplied by and recommended by the wheel manufacturer.
- After mounting a new wheel, hold the Grinder under a steel workbench or inside a casting and run it for at least 60 seconds. Make certain no one is within the operating plane of the grinding wheel. If a wheel is defective, improperly mounted or the wrong size and speed, this is the time it will usually fail.
- When starting with a cold wheel, apply it to the work slowly until the wheel gradually warms up. Make smooth contact with the work and avoid any bumping action or excessive pressure.
- Always replace a damaged, bent or severely worn wheel guard. Do not use a wheel guard that has been subjected to a wheel failure.
- Make certain wheel flanges are at least 1/3 the diameter of grinding wheel, free of nicks, burrs and sharp edges. Always use wheel flanges furnished by the manufacturer; never use a makeshift flange or a plain washer. Tighten Flange Nut securely.
- Guard opening must face away from operator. Bottom of wheel must not project beyond guard.
- Series TD120 Grinders have a free speed of 12,000 rpm; Series TD180, TX180 and TXD180 Grinders have a free speed of 18,000 rpm; Series TD200 and TX200 Grinders have a free speed of 25,000 rpm, when operated at 90 psig (6.2 bar/620 kPa) air pressure. Operation at higher air pressure will result in excessive speed.
- Always match collet size with accessory shank size.
- Always insert tool shank no less than 10 mm in the collet. Tighten Collet Nut securely to prevent accessory from working out during operation of the Grinder. Check tightness of Collet Nut before operating the Grinder. Pay particular attention to the fact that allowed speed of a mounted point is lowered when the length of the shaft is increased between end of collet and mounted point (overhang).

GRINDER SPECIFIC WARNINGS

WARNING: Incorrect combinations of grinding wheel, wheel guard and tool speed could result in injury.
Correct combinations are specified below:

Guard Part Number	Wheel Type	Wheel Diameter in. (mm)	Maximum Wheel Thickness in. (mm)	Maximum Speed rpm
LE2-931	1	3 (76)	1/2 (12.7)	20 500

PLACING TOOL IN SERVICE

LUBRICATION



Ingersoll-Rand No. 10 **Ingersoll-Rand No. 68**
Ingersoll-Rand No. 50




Always use an air line lubricator with these tools.
We recommend the following Filter-Lubricator-Regulator Unit:

For USA – No. C28-04-FKG0-28

After each two hours of operation, if an air line lubricator is not used, inject 1/2 to 1 cc of Ingersoll-Rand No. 10 Oil into the Air Inlet.

CAUTION

Do not mark any nonmetallic surface of this tool with customer identification codes. Such action could affect tool performance.




MOUNTING THE ROUTER ATTACHMENT

To mount a TD-RK4 or TD-RK6 Router Attachment to a TD200 or TD250 Grinder having a collet, proceed as follows:

1. Use the Collet Body Wrench to hold the Collet Body from turning and using the Collet Nut Wrench , unscrew and remove the Collet Nut Assembly from the Grinder. Remove the Collet .
2. Grasp the tool in copper-covered or leather-covered vise jaws with the spindle upward and using a 1-1/2" wrench, unscrew and remove the Clamp Nut . This is a **left-hand thread**, rotate the Nut **clockwise** to remove it.
3. Remove the Clamp Spacer and install the Router Attachment Clamp Spacer .
4. Thread the Clamp Nut onto the Housing and tighten the Nut between 20 and 25 ft-lb (27 and 34 Nm) torque. This is a **left-hand thread**, rotate the Nut **counterclockwise** to tighten it.
5. Insert the Collet into the Collet Body and loosely thread the Collet Nut onto the Collet Body. Insert a router bit into the Collet and tighten the Collet Nut.
6. Install the Nosepiece Adapter over the bit and collet assembly and thread it onto the Clamp Spacer. Tighten the Adapter between 2 and 3 ft-lb (2.7 and 4.0 Nm) torque. This is a **left-hand thread**, rotate the Adapter **counterclockwise** to tighten it.
7. Install the Adapter Lock Screw in the Adapter and tighten it between 12 and 18 in-lb (1.3 and 2.0 Nm) torque.
8. Thread the Lock Nut onto the Nosepiece Adapter.
9. Thread the Nosepiece Assembly onto the Adapter and then back the Lock Nut against the Assembly. Tighten the Lock Nut between 14 and 19 ft-lb (19.0 and 25.8 Nm) torque.
10. If a Trimmer Guide is used, thread the Guide into the Nosepiece Assembly and tighten the Guide between 3 and 4 ft-lb (4.1 and 5.4 Nm) torque.

PLACING TOOL IN SERVICE

TRIMMER GUIDE



Trimmer Guide Dimensions

(Dwg. TPD1208)

PART NUMBER FOR ORDERING	A	B	C	D	E
R120-128-2 (for 1/4" shank)	1-1/2	3/8	3/8	1/8	1/2-20NF
R120-128-7 (for 1/4" shank)	2-1/2	1/2	1/2	3/16	1/2-20NF
LG2-129-1 (for 3/8" shank)	2-1/2	1/2	5/8	1/8	5/8-18UNF

★ Note: Offset = 1/2 ("B" dimension minus trimmer bit diameter.)

The following equipment is available at an extra price and must be ordered separately:

1. Router Attachment Assembly

- for models using 1/4" diameter bits Part No. TD-RK4
- for models using 3/8" diameter bits Part No. TD-RK6

2. Trimmer Guide (for Router Attachments)

- for 1/4" shank Part No. R120-128-2
- for 1/4" shank Part No. R120-128-7
- for 3/8" shank Part No. LG2-129-1

NOTICE

All the models listed on Page 5 can be changed to front exhaust tools by reversing the Flow Ring and aligning the the indicator marks with the letter "F" on the Housing. To order a front exhaust tool from the factory, substitute the letter "F" for the letter "R" in the above models. Example: TD12RG4 Rear Exhaust Model becomes TD120FG4 Front Exhaust Model.

PLACING TOOL IN SERVICE

NEW GRINDER TO ACCESSORY COLOR MATCHING GUIDE


Ingersoll-Rand has pioneered a new color code system designed to:

1. Simplify the identification of rated tool speed via a unique corresponding color match.
2. Easily communicate the appropriate backing pads and

accessories for each tool through a matching color code system on the backing pads and/or other corresponding Grinder accessories.

3. The chart below demonstrates the color code system between the Grinder and the accessory.

(READ FROM LEFT TO RIGHT)



(Dwg. TPD1146-1)

SPÉCIFICATIONS

1/4" COLLET

Model	Speed/rpm
TD250RG4	25,000
TD200RG4	20,000
TD180RG4	18,000
TD120RG4	12,000

1/4" COLLET


TX250RG4	25,000
TX180RG4	18,000
TX120RG4	12,000

3" WHEEL GUARD

TX180RH63	18,000
-----------	--------

3" WHEEL GUARD

TXD180RH63	18,000
------------	--------




F

MANUEL D'EXPLOITATION ET D'ENTRETIEN DES MEULEUSES DES SÉRIES TD, TX ET TXD

NOTE

Les meuleuses des Séries TD, TX et TXD sont destinées aux travaux dans des espaces restreints dans l'industrie de fabrication, les chantiers navals, la fabrication de tuyauteries, la fabrication de matrices et les applications à espace limité. En particulier, elles sont idéales dans les endroits où les tubes, tuyauteries, gaines, etc. passent à travers des cloisons ou des châssis. Ces petites meuleuses d'angle sont très efficaces pour le meulage des cordons de soudure lorsqu'une bonne finition est requise.

Ingersoll-Rand ne peut être tenu responsable de la modification des outils par le client pour les adapter à des applications qui n'ont pas été approuvées par Ingersoll-Rand.



! ATTENTION

D'IMPORTANTES INFORMATIONS DE SECURITÉ SONT JOINTES.

LIRE CE MANUEL AVANT D'UTILISER L'OUTIL.

L'EMPLOYEUR EST TENU À COMMUNIQUER LES INFORMATIONS

DE CE MANUEL AUX EMPLOYÉS UTILISANT CET OUTIL.

LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES

MISE EN SERVICE DE L'OUTIL

- Toujours exploiter, inspecter et entretenir cet outil conformément au Code de sécurité des outils pneumatiques portatifs de l'American National Standards Institute (ANSI B186.1).
- Pour la sécurité, les performances optimales et la durabilité maximale des pièces, cet outil doit être connecté à une alimentation d'air comprimé de 6,2 bar (620 kPa) maximum à l'entrée, avec un flexible de 10 mm de diamètre intérieur.
- Couper toujours l'alimentation d'air comprimé et débrancher le flexible d'alimentation avant d'installer, déposer ou ajuster tout accessoire sur cet outil, ou d'entreprendre une opération d'entretien quelconque sur l'outil.
- Ne pas utiliser des flexibles ou des raccords endommagés, effilochés ou détériorés.
- S'assurer que tous les flexibles et les raccords sont correctement dimensionnés et bien serrés. Voir Plan TPD905-1 pour un exemple type d'agencement des tuyauteries.
- Utiliser toujours de l'air sec et propre à une pression maximum de 6,2 bar. La poussière, les fumées corrosives et/ou une humidité excessive peuvent endommager le moteur d'un outil pneumatique.
- Ne jamais lubrifier les outils avec des liquides inflammables ou volatiles tels que le kérósène, le gasoil ou le carburant d'aviation.
- Ne retirer aucune étiquette. Remplacer toute étiquette endommagée.

UTILISATION DE L'OUTIL

- Porter toujours des lunettes de protection pendant l'utilisation et l'entretien de cet outil.
- Porter toujours une protection acoustique pendant l'utilisation de cet outil.
- Tenir les mains, les vêtements flous et les cheveux longs, éloignés de l'extrémité rotative de l'outil.
- Prévoir, et ne pas oublier, que tout outil motorisé est susceptible d'à-coups brusques lors de sa mise en marche et pendant son utilisation.
- Garder une position équilibrée et ferme. Ne pas se pencher trop en avant pendant l'utilisation de cet outil. Des couples de réaction élevés peuvent se produire à, ou en dessous, de la pression d'air recommandée.
- La rotation des accessoires de l'outil peut continuer pendant un certain temps après le relâchement de la gâchette.
- Les outils pneumatiques peuvent vibrer pendant l'exploitation. Les vibrations, les mouvements répétitifs et les positions inconfortables peuvent causer des douleurs dans les mains et les bras. N'utiliser plus d'outils en cas d'inconfort, de picotements ou de douleurs. Consulter un médecin avant de recommencer à utiliser l'outil.
- Utiliser les accessoires recommandés par Ingersoll-Rand.
- Cet outil n'est pas conçu pour fonctionner dans des atmosphères explosives,
- Cet outil n'est pas isolé contre les chocs électriques,

NOTE

L'utilisation de rechanges autres que les pièces d'origine Ingersoll-Rand peut causer des risques d'insécurité, réduire les performances de l'outil et augmenter l'entretien, et peut annuler toutes les garanties.

Les réparations ne doivent être effectuées que par des réparateurs qualifiés autorisés. Consultez votre Centre de Service Ingersoll-Rand le plus proche.

Adresssez toutes vos communications au Bureau Ingersoll-Rand ou distributeur le plus proche.

© Ingersoll-Rand Company 1999





Imprimé aux É.U.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

SIGNIFICATION DES ETIQUETTES D'AVERTISSEMENT

! ATTENTION

LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES



AVERTISSEMENTS SPECIFIQUES AUX MEULEUSES

! ATTENTION

LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES

- Ne pas utiliser cet outil si la vitesse à vide réelle dépasse celle indiquée sur la plaque signalétique.
- Avant de monter une meule, après toute réparation de l'outil ou avant de fournir une meuleuse pour utilisation, vérifier la vitesse à vide de la meuleuse avec un tachymètre pour s'assurer que la vitesse réelle à 6,2 bar (620 kPa) ne dépasse pas celle poinçonnée ou imprimée sur la plaque signalétique. Les meuleuses sorties sur chantier doivent être vérifiées de la même façon au moins une fois par poste.
- Utiliser toujours le protège-meule Ingersoll-Rand fourni avec la meuleuse.
- Ne jamais utiliser une meule, une fraise ou tout autre accessoire ayant une vitesse de service inférieure à la vitesse à vide de la meuleuse sur laquelle il est monté. Respecter toujours la vitesse maximum inscrite sur les disques en papier de la meule.
- Inspecter toutes les meules avant de les monter pour vérifier qu'elles ne présentent pas d'éclats ou de fissures. Ne jamais utiliser une meule écaillée, fissurée ou ayant un endommagement quelconque. Ne jamais utiliser une meule qui a été trempée dans l'eau ou tout autre liquide.
- S'assurer que la meule se monte correctement sur l'arbre. Ne pas utiliser de bagues réductrices, à moins que ces bagues soient recommandées et fournies par le fabricant de la meule.
- Après avoir monté une nouvelle meule, tenir la meuleuse sous un établi en acier ou dans une pièce coulée et la faire tourner pendant au moins 60 secondes. S'assurer que personne ne se tient dans le

plan de rotation de la meule. Toute meule défectueuse, mal montée ou de dimension et vitesse incorrectes se cassera généralement à ce moment là.

- Pour commencer le travail avec une meule froide, l'appliquer lentement contre la pièce jusqu'à ce que la meule s'échauffe progressivement. Mettre la meule en contact avec la pièce en douceur en évitant tout choc ou pression excessive.
- Remplacer toujours un protège-meule endommagé, tordu ou très usé. Ne pas utiliser un protège-meule qui a été soumis à la rupture d'une meule.
- S'assurer que les flasques de meule couvrent au moins 1/3 du diamètre de la meule, et qu'ils sont exempts d'entailles, de bavures et d'arêtes vives. Utiliser toujours les flasques fournis par le fabricant; ne jamais utiliser de flaque de provenance douteuse ou de rondelle plate. Serrer fermement l'écrou du flaque.
- L'ouverture du protège-meule doit être orientée côté opposé à l'opérateur. Le bas de la meule ne doit pas dépasser le protège-meule.
- Les meuleuses de la Série TD120 ont une vitesse à vide de 12.000 tr/mn; les meuleuses des Séries TD180, TX180 et TXD180 ont une vitesse à vide de 18.000 tr/mn; Les meuleuses des Séries TD200 et TX200 ont une vitesse à vide de 25.000 tr/mn lorsqu'exploitées avec une pression d'air de 6,2 bar (620 kPa). L'exploitation à une pression supérieure produira une vitesse excessive.
- Toujours choisir une pince adaptée à la dimension de la queue de l'accessoire.

AVERTISSEMENTS SPECIFIQUES AUX MEULEUSES

- Toujours choisir une pince adaptée à la dimension de la queue de l'accessoire.
- La queue de l'outil doit toujours être insérée dans la pince sur au moins 10 mm. Serrer fermement l'écrou de pince pour éviter tout desserrage de l'accessoire pendant l'emploi de la meuleuse. Vérifier le serrage de

l'écrou de pince avant de mettre la meuleuse en marche. Ne jamais oublier que la vitesse admissible d'une meule sur tige doit être réduite lorsque la longueur de la tige entre le bout de la pince et la meule (porte-à-faux) est augmentée.

ATTENTION: Une mauvaise combinaison de roue d'affûtage, de protection de roue et de vitesse de l'outil peut provoquer un accident corporel. Les combinaisons correctes sont spécifiées ci-dessous:

Référence de la protection	Type de roue	Diamètre de roue mm (po.)	Epaisseur max de roue mm (po.)	Vitesse maximale (t/min)
LE2-931	1	3 (76)	1/2 (12,7)	20 500

MISE EN SERVICE DE L'OUTIL

LUBRIFICATION



Ingersoll-Rand No. 10
Ingersoll-Rand No. 50



Ingersoll-Rand No. 68


Utiliser toujours un lubrificateur avec ces outils. Nous recommandons l'emploi du filtre-régulateur-lubrificateur suivant :

É. U. – N°. C28-04-FKG0-28

Toutes les deux heures de fonctionnement, si un lubrificateur de ligne n'est pas utilisé, injecter 1/2 à 1 cm³ d'huile Ingersoll-Rand No. 10 dans le raccord d'admission.

AVERTISSEMENT

Ne pas marquer les codes d'identification client sur les surfaces non métalliques de cet outil. De telles actions pourraient affecter les performances de l'outil.




MONTAGE DE L'ACCESSOIRE DE DEFONÇAGE

Pour monter l'accessoire de défonçage TD-RK4 ou TD-RK6 sur une meuleuse TD200 ou TD250 équipée d'une pince, procéder comme suit:

1. Empêcher la rotation du corps de pince à l'aide de la clé de corps de pince et utiliser la clé de pince pour dévisser et déposer l'ensemble d'écrou de pince de la meuleuse. Déposer la pince.
2. Serrer l'outil dans un étai équipé de mordaches en cuir ou en cuivre, broche vers le haut, et à l'aide d'une clé de 1-1/2", dévisser et déposer l'écrou d'accouplement. L'écrou est fileté à gauche, et doit être tourné dans le sens des aiguilles d'une montre pour le déposer.
3. Déposer l'entretoise d'accouplement et monter l'entretoise de l'accessoire de défonçage.
4. Visser l'écrou d'accouplement sur le corps et le serrer à un couple de 27 à 34 Nm. L'écrou est fileté à gauche, et doit être tourné dans le sens contraire des aiguilles d'une montre pour le serrer.
5. Insérer la pince dans le corps de pince et visser à la main l'écrou de pince sur le corps de pince. Monter une fraise dans la pince et serrer l'écrou de pince.
6. Installer l'adaptateur de nez sur l'ensemble fraise/pince et le visser sur l'entretoise d'accouplement. Serrer l'adaptateur à un couple de 2,7 à 4,0 Nm. L'écrou est fileté à gauche, donc l'adaptateur doit être tourné dans le sens contraire des aiguilles d'une montre pour le serrer.
7. Monter la vis de verrouillage de l'adaptateur dans l'adaptateur et la serrer à un couple de 1,3 à 2,0 Nm.
8. Visser l'écrou de verrouillage sur l'adaptateur de nez.
9. Visser l'ensemble de nez sur l'adaptateur et ramener l'écrou de verrouillage contre l'ensemble. Serrer l'écrou à un couple de 19,0 à 25,8 Nm.
10. Si un guide de fraisage est utilisé, visser le guide dans l'ensemble de nez et le serrer à un couple de 4,1 à 5,4 Nm.

MISE EN SERVICE DE L'OUTIL

GUIDE DE FRAISAGE



Dimensions du guide de fraisage

(Plan TPD1208)

NUMERO DE REFERENCE POUR LA COMMANDE	A	B	C	D	E
R120-128-2 (pour tige de 1/4")	1-1/2	3/8	3/8	1/8	1/2-20NF
R120-128-7 (pour tige de 1/4")	2-1/2	1/2	1/2	3/16	1/2-20NF
LG2-129-1 (pour tige de 3/8")	2-1/2	1/2	5/8	1/8	5/8-18UNF

★ NB: Décalage = 1/2 (dimension "B" moins diamètre de la fraise)

Les équipements suivants sont disponibles contre supplément et doivent être commandés séparément:

1. Accessoire de défonçage

pour modèles utilisant des fraises de 1/4" de diamètre	Réf. TD-RK4
pour modèles utilisant des fraises de 3/8" de diamètre	Réf. TD-RK6
2. Guide de fraisage (pour accessoires de défonçage)

(pour tige de 1/4")	Réf. R120-128-2
(pour tige de 1/4")	Réf. R120-128-7
(pour tige de 3/8")	Réf. LG2-129-1

NOTE

Tous les modèles listés Page 5 peuvent être modifiés pour un échappement avant en inversant la bague de débit et en alignant les repères sur la lettre "F" du corps. Pour commander un outil à échappement avant à l'usine, remplacer la lettre "R" par la lettre "F" dans les modèles ci-dessus. Exemple: le modèle à échappement arrière TD12RG4 devient le modèle à échappement avant TD120FG4.

MISE EN SERVICE DE L'OUTIL

— NOUVEAU GUIDE DE CORRESPONDANCE MEULEUSE/ACCESSOIRE À CODE COULEUR —

Ingersoll-Rand a lancé un nouveau système de code couleur destiné à:

1. Simplifier l'identification des vitesses nominales des outils grâce à un code couleur de correspondance unique.
2. Faire correspondre facilement les plateaux-supports et les

accessoires à chaque outil grâce à l'introduction d'un code couleur d'identification sur les plateaux et/ou les accessoires des meuleuses.

3. Le tableau ci-dessous illustre le système d'identification couleur pour les meuleuses et les accessoires.

(A LIRE DE GAUCHE A DROITE)

COULEUR DE VITESSE SUR PLAQUE SIGNELETIQUE	VITESSE NOMINALE DE L'OUTIL	GAMME SURE DES ACCESSOIRES (VITESSE MAXIMALE DE FONCTIONNEMENT)							
		35 000	30 000	25 000	20 000	18 000	15 000	12 000	9 000
ROUGE ORANGE JAUNE VERT BLEU GRIS OCRE VIOLET	35 ,000 30 ,000 25 ,000 20 ,000 18 ,000 15 ,000 12 ,000 9 ,000	ROUGE	ORANGE	JAUNE	VERT	BLEU	GRIS	OCRE	VIOLET

(Plan TPD1146-1)

SPÉCIFICATIONS

1/4" PINCE

Modèle	Vitesse d'exploitation maximum
TD250RG4	25.000
TD200RG4	20.000
TD200RG4	18.000
TD120RG4	12.000

1/4" PINCE


TX250RG4	25.000
TX180RG4	18.000
TX120RG4	12.000

3" PROTÈGE-MEULE

TX180RH63	18.000
-----------	--------

3" PROTÈGE-MEULE

TXD180RH63	18.000
------------	--------




E

MANAL DE USO Y MANTENIMIENTO PARA AMOLADORAS MODELOS TD, TX Y TXD

NOTA

Las Amoladoras Serie TD, TX y TXD están diseñadas para trabajo a distancia mínima en la industria de fabricación de metales, astilleros, fabricación de tuberías y aplicaciones en espacios reducidos. Estas amoladoras resultan especialmente eficaces para aquellas situaciones en las que los conductos, tuberías, etc. atraviesan tabiques o bastidores. Estas pequeñas Amoladoras son muy eficaces para amolar cordones de soldadura y obtener un acabado fino.

Ingersoll-Rand no aceptará responsabilidad alguna por la modificación de las herramientas efectuada por el cliente para las aplicaciones que no hayan sido consultadas con Ingersoll-Rand.



AVISO

**SE ADJUNTA INFORMACIÓN IMPORTANTE DE SEGURIDAD.
LEA ESTE MANUAL ANTES DE USAR LA HERRAMIENTA.**

**ES RESPONSABILIDAD DE LA EMPRESA ASEGURARSE DE QUE EL OPERARIO
ESTÉ AL TANTO DE LA INFORMACIÓN QUE CONTIENE ESTE MANUAL.**

EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRÍA OCASIONAR LESIONES

PARA PONER LA HERRAMIENTA EN SERVICIO

- Utilice, examine y mantenga siempre esta herramienta conforme al código de seguridad para herramientas neumáticas portátiles de la American National Standards Institute (ANSI B186.1).
- Para seguridad, máximo rendimiento y vida de servicio de las piezas, use esta herramienta a una presión de aire máxima de 90 psig (6,2 bar/620 kPa) en la manguera de suministro de aire con diámetro interno de 10 mm.
- Corte siempre el suministro de aire y desconecte la manguera de suministro de aire antes de instalar, desmontar o ajustar cualquier accesorio de esta herramienta, o antes de realizar cualquier operación de mantenimiento de la misma.
- No utilice mangas de aire y accesorios dañados, desgastados ni deteriorados.
- Asegúrese de que todas las mangas y accesorios sean del tamaño correcto y estén bien apretados. Vea Esq. TPD905-1 para un típico arreglo de tuberías.
- Use siempre aire limpio y seco a una presión máxima de 90 psig. El polvo, los gases corrosivos y/o el exceso de humedad podrían estropear el motor de una herramienta neumática.
- No lubrique las herramientas con líquidos inflamables o volátiles tales como queroseno, gasoil o combustible para motores a reacción.
- No saque ninguna etiqueta. Sustituya toda etiqueta dañada.

USO DE LA HERRAMIENTA

- Use siempre protección ocular cuando maneje, o realice operaciones de mantenimiento en esta herramienta.
- Use siempre protección para los oídos cuando maneje esta herramienta.
- Mantenga las manos, la ropa suelta y el cabello largo alejados del extremo giratorio de la herramienta.
- Antípese y esté alerta sobre los cambios repentinos en el movimiento durante la puesta en marcha y el manejo de toda herramienta motorizada.
- Mantenga una postura de cuerpo equilibrada y firme. No estire demasiado los brazos al manejar la herramienta. Pueden ocurrir reacciones de alto par a, o a menos de, la recomendada presión de aire.
- Los accesorios de la herramienta podrían seguir girando brevemente después de haber soltado la palanca de estrangulación.
- Las herramientas neumáticas pueden vibrar durante el uso. La vibración, repetición o posiciones incómodas pueden dañarle los brazos y manos. En caso de incomodidad, sensación de hormigueo o dolor, deje de usar la herramienta. Consulte a un médico antes de volver a usarla otra vez.
- Utilice únicamente los accesorios Ingersoll-Rand recomendados.
- Esta herramienta no ha sido diseñada para trabajar en ambientes explosivos.
- Esta herramienta no está aislada contra descargas eléctricas.

NOTA

El uso de piezas de recambio que no sean las auténticas piezas Ingersoll-Rand podría poner en peligro la seguridad, reducir el rendimiento de la herramienta y aumentar los cuidados de mantenimiento necesarios, así como invalidar toda garantía.

Las reparaciones sólo serán realizadas por personal cualificado y autorizado. Consulte con el centro de servicio Ingersoll-Rand autorizado más próximo.

Toda comunicación se deberá dirigir a la oficina o al distribuidor Ingersoll-Rand más próximo.

© Ingersoll-Rand Company 1999


Impreso en EE. UU.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

ETIQUETAS DE AVISO

! AVISO

EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRÍA OCASIONAR LESIONES.

	ADVERTENCIA Use siempre protección ocular cuando utilice esta herramienta o realice operaciones de mantenimiento en la misma.
	ADVERTENCIA Las herramientas neumáticas pueden vibrar durante el uso. La vibración, los movimientos repetitivos o las posiciones incómodas podrían dañar los brazos y las manos. En caso de incomodidad, sensación de hormigueo o dolor, dejar de usar la herramienta. Consultar al médico antes de volver a utilizarla.
	ADVERTENCIA Mantener una postura del cuerpo equilibrada y firme. No estirar demasiado los brazos al manejar la herramienta.
	ADVERTENCIA Manejar la herramienta a una presión de aire máxima de 90 psig (6,2 bar/620 kPa).
	ADVERTENCIA Use siempre protección para los oídos cuando utilice esta herramienta.
	ADVERTENCIA Cortar siempre el suministro de aire y desconectar la manguera de suministro de aire antes de instalar, retirar o ajustar cualquier accesorio de esta herramienta, o antes de realizar cualquier operación de mantenimiento de la misma.
	ADVERTENCIA No utilizar mangueras de aire y accesorios dañados, desgastados ni deteriorados.

AVISOS ESPECÍFICOS PARA AMOLADORA

! AVISO

EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRÍA OCASIONAR LESIONES.

- No use esta herramienta si la velocidad libre real excede la indicada en la placa de identificación.
- Antes de montar una muela, y después de todas las reparaciones de herramienta y siempre que se proporcione una Amoladora para su uso, compruebe la velocidad libre de dicha Amoladora con un tacómetro para asegurarse que su velocidad real a 90 psig (620 bar/6,2 kPa) no exceda las rpm estampadas o impresas en la placa de identificación. Las Amoladoras usadas en trabajos deberán ser examinadas similarmente como mínimo una vez en cada jornada de trabajo.
- Use siempre el Cubremuela Ingersoll-Rand recomendado y suministrado con la Amoladora.
- No use nunca una muela, taladro rotatorio dental o cualquier otro accesorio que tenga una velocidad máxima de funcionamiento menor que la velocidad libre de la Amoladora en la que se esté usando. Cumpla siempre las rpm máximas indicadas en los distanciadores de la muela.
- Inspeccione todas las muelas antes de su montaje para ver si tienen grietas o roturas. No use una muela que esté rota o agrietada o dañada de cualquier otra forma. No use una muela que haya estado a remojo en agua o en cualquier otro líquido.
- Asegúrese de que la muela esté bien puesta en la espiga. No use anillos reductores para adaptar una muela a la espiga a menos que estos hayan sido suministrados y recomendados por el fabricante de muelas.
- Después de haber montado una muela nueva, sujetela la Amoladora bajo un banco de acero o en un molde y

hágala funcionar durante 60 segundos como mínimo. Asegúrese que no haya nadie en el entorno de operación de muela. Si la muela es defectuosa, está mal montada o es del tamaño y velocidad incorrectas, normalmente fallará en este momento.

- Cuando ponga en marcha una muela en frío, aplíquela lentamente al trabajo hasta que se caliente gradualmente. Contacte la zona de trabajo suavemente, y evite golpes o exceso de presión.
- Cambie siempre un cubremuela dañado, torcido o muy desgastado. No use un cubremuela que haya experimentado un fallo de muela.
- Asegúrese que las bridas de muela sean de un diámetro mínimo de 1/3 de la muela y que estén libres de marcas, abrasiones y bordes afilados. Use siempre las bridas de muela suministradas por el fabricante; no use nunca una brida casera o arandela normal. Apriete la Tuerca de Brida de manera segura.
- La apertura del cubremuela deberá estar orientada hacia afuera del operario. La parte inferior de la muela no deberá proyectarse fuera del cubremuela.
- Las Amoladoras Modelos TD120 tienen una velocidad libre de 12.000 rpm; Las Amoladoras Modelos TD180, TX180 y TXD180 tienen una velocidad libre de 18.000 rpm; Las Amoladoras Modelos TD200 y TX200 tienen una velocidad libre de 25.000 rpm cuando se operan a una presión de aire máxima de 90 psig (6,2 bar/620 kPa). Si se utiliza la herramienta a una presión de aire comprimido mayor, se causará exceso de velocidad.
- Empareje siempre el tamaño de pinza con el tamaño de vástago de accesorio.

(continuación)

AVISOS ESPECÍFICOS PARA AMOLADORA

- Inserte siempre el vástago de herramienta en la pinza un mínimo de 10 mm. Apriete la Tuerca de Pinza de manera segura para evitar que se salga el accesorio durante el funcionamiento de la Amoladora. Compruebe el apriete de Tuerca de Pinza antes de

usar la Amoladora. Preste especial atención al hecho de que la velocidad permitida de un punto de montaje disminuye cuando se incrementa la longitud de eje entre extremo de pinza y punto de montaje (saliente).

AVISO: Combinaciones incorrectas de rueda de rectificación, protector de rueda y velocidad de herramienta pueden resultar en lesionamientos. Las combinaciones correctas se especifican a continuación:

Número de Pieza del Protector	Tipo de Rueda	Diámetro de Rueda mm (in.)	Grosor Máximo de Rueda mm (in.)	Velocidad Máxima (rpm)
LE2-931	1	3 (76)	1/2 (12,7)	20 500

PARA PONER LA HERRAMIENTA EN SERVICIO

LUBRICACIÓN



Ingersoll-Rand Nº 10
Ingersoll-Rand Nº 50



Ingersoll-Rand Nº 68


Utilice siempre un lubricador de aire comprimido con estas herramientas. Recomendamos la siguiente unidad de Filtro-Lubricador-Regulador:

EE.UU. - Nº. C28-04-FKG0-28

Después de cada dos horas de uso, a menos que se use un lubricante de línea de aire comprimido, inyecte 1½ – 1 cc de Aceite Ingersoll-Rand Nº 10 en la Admisión de Aire.

PRECAUCIÓN

No marque ninguna superficie no metálica de esta herramienta con los códigos de identificación de cliente. Tal acción podría afectar al rendimiento de la herramienta.



(Esq. TPD905-1)


MONTAJE DEL ACCESORIO DE FRESCO

Para montar un accesorio de fresado TD-RK4 o TD-RK6 a una Amoladora TD200 o TD250 con pinza, proceda de la manera siguiente:

- Utilice la llave de cuerpo de pinza para evitar que gire el cuerpo de pinza y, utilizando una llave de tuerca de pinza, desenrosque y quite el conjunto de tuerca de pinza de la amoladora. Saque la pinza.
- Sujete la herramienta en un tornillo de banco con mordazas cubiertas de cobre o cuero con el husillo hacia arriba y, utilizando una llave de 1-1/2 pulg., desatornille la tuerca de abrazadera. Puesto que se trata de **una rosca hacia la izquierda**, gire la tuerca **en el sentido de las agujas del reloj** para quitarla.
- Saque el espaciador de abrazadera e instale el espaciador de abrazadera del accesorio de fresado.
- Enrosque la tuerca de abrazadera en la carcasa y apriete dicha tuerca entre 20 y 25 ft-lb (27 y 34 Nm) de par. Puesto que se trata de **una rosca hacia la izquierda**, gire la tuerca **en sentido contrario al de las agujas del reloj** para quitarla.
- Inserte la pinza en el cuerpo de pinza y enrosque la tuerca de pinza en el cuerpo de pinza sin apretarla. Inserte una broca de fresado en la pinza y apriete la tuerca de pinza.
- Inserte el adaptador de la pieza de extremo sobre el conjunto de pinza y broca de fresado, y enrósquelo en el espaciador de abrazadera. Apriete el adaptador entre 2 y 3 ft-lb (2,7 a 4,0 Nm) de par. Puesto que se trata de **una rosca hacia la izquierda**, gire el adaptador **en sentido contrario al de las agujas del reloj** para quitarlo.
- Instale el tornillo de bloqueo en el adaptador, y apriételo entre 12 y 18 pulg.-lb (1,3 a 2,0 Nm) de par.
- Enrosque la tuerca de bloqueo en el adaptador de la pieza de extremo.
- Enrosque el conjunto de pieza de extremo en el adaptador y gire la tuerca de bloqueo en sentido contrario, contra el conjunto. Apriete la tuerca de bloqueo entre 14 y 19 ft-lb (19,0 a 25,8 Nm) de par.
- Si se utiliza una guía de recorte, enrosque la guía en la pieza de extremo y apriete dicha guía entre 3 y 4 ft-lb (4,1 a 5,4 Nm) de par.

PARA PONER LA HERRAMIENTA EN SERVICIO

GUÍA DE RECORTE



Dimensiones de la guía de recorte

(Esq. TPD1208)

NUMERO DE PIEZA PARA PEDIDO	A	B	C	D	E
R120-128-2 (para mango de 1/4 pulg.)	1-1/2	3/8	3/8	1/8	1/2-20NF
R120-128-7 (para mango de 1/4 pulg.)	2-1/2	1/2	1/2	3/16	1/2-20NF
LG2-129-1 (para mango de 3/8 pulg.)	2-1/2	1/2	5/8	1/8	5/8-18UNF

★ Nota: Descentramiento = 1/2 (dimensión "B" menos diámetro de broca de recorte.)

El siguiente equipo está disponible a un precio adicional y debe ser pedido por separado:

1. Conjunto de accesorio de fresado
 - para modelos con broca de 1/4 pulg. de diámetro Pieza N°. TD-RK4
 - para modelos con broca de 3/8 pulg. de diámetro Pieza N°. TD-RK6
2. Guía de recorte (para accesorios de fresado)
 - para mango de 1/4 pulg. Pieza N°. R120-128-2
 - para mango de 1/4 pulg. Pieza N°. R120-128-7
 - para mango de 3/8 pulg. Pieza N°. LG2-129-1

NOTA

Todos los modelos que aparecen listados en la página 5 se pueden convertir en herramientas de escape delantero invirtiendo para ello el anillo de flujo y alineando las marcas de indicador con la letra "F" que aparece en la carcasa. Para pedir a la fábrica una herramienta de escape delantero, sustituya la letra "F" por "R" en los modelos mencionados más arriba. Ejemplo: el modelo de escape trasero TD12RG4 se convierte en el modelo de escape delantero TD120FG4.

PARA PONER LA HERRAMIENTA EN SERVICIO

NUEVO SISTEMA DE CÓDIGO DE COLORES


Ingersoll-Rand ha introducido un nuevo sistema de codificación de colores diseñado para:

1. Simplificar la identificación de la velocidad de herramienta regulada por una codificación de colores correspondientes única.
2. Comunicar fácilmente los accesorios y almohadillas de

refuerzo correspondientes a cada herramienta gracias a un sistema de codificación de colores en las almohadillas de repuesto o/otros accesorios de Amoladora correspondientes.

3. La tabla que aparece más abajo muestra el sistema de codificación de colores entre Amoladora y accesorio.

(LEA DE IZQUIERDA A DERECHA)



(Esq. TPD1146-1)

ESPECIFICACIONES

1/4" PINZA

Modelo	Velocidad Libre, rpm
TD250RG4	25.000
TD200RG4	20.000
TD180RG4	18.000
TD120RG4	12.000

1/4" PINZA


TX250RG4	25.000
TD180RG4	18.000
TD120RG4	12.000

CUBREMUELA

TD180RH63	18.000
-----------	--------

CUBREMUELA

TXD180RH63	18.000
------------	--------




P

MANUAL DE FUNCIONAMENTO E MANUTENÇÃO PARA ESMERILADORAS SÉRIES TD, TX E TXD

AVISO

Esmeriladoras Séries TD, TX e TXD são concebidas para industrias metalomecânicas, estaleiros navais, industria de tubos, moldes e aeronáutica. Estas pequenas Esmeriladoras são muito eficientes no esmerilamento de cordão de solda deixando um acabamento fino.

A Ingersoll-Rand não é responsável por modificações, feitas pelo cliente em ferramentas, nas quais a Ingersoll-Rand não tenha sido consultada.



! ADVERTÊNCIA

INFORMAÇÃO DE SEGURANÇA IMPORTANTE EM ANEXO

LEIA ESTE MANUAL ANTES DE OPERAR A FERRAMENTA.

É DA RESPONSABILIDADE DO EMPREGADOR COLOCAR A INFORMAÇÃO
DESTE MANUAL NAS MÃOS DO OPERADOR.

O NÃO CUMPRIMENTO DAS SEGUINTEZ ADVERTÊNCIAS PODE RESULTAR EM FERIMENTOS.

COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

- Sempre opere, inspecione e mantenha esta ferramenta de acordo com o Código de Segurança do Instituto Americano de Padrões Nacionais para Ferramentas Pneumáticas Portáteis (ANSI B186.1).
- Para segurança, máximo desempenho e máxima durabilidade das peças, opere esta ferramenta com uma pressão de ar máxima de 6,2 bar/620 kPa (90 psig) na entrada da mangueira de alimentação de ar com diâmetro interno de 10 mm (3/8").
- Desligue sempre a alimentação de ar e desconecte a mangueira de alimentação de ar antes de instalar, remover ou ajustar qualquer acessório nesta ferramenta, ou antes de executar qualquer serviço de manutenção nesta ferramenta.
- Não use mangueiras de ar ou adaptadores danificados, gastos ou deteriorados.
- Certifique-se de que todas as mangueiras e adaptadores sejam do tamanho correcto e estejam apertados com firmeza. Veja o Desenho TPD905-1 para um arranjo típico de tubagem.
- Use sempre ar seco e limpo com pressão máxima de 90 psig. Pó, fumos corrosivos e/ou humidade excessiva podem arruinar o motor de uma ferramenta pneumática.
- Não lubrifique as ferramentas com líquidos inflamáveis ou voláteis tais como querosene, diesel ou combustível de jactos.

- Não remova nenhum rótulo. Reponha qualquer rótulo danificado.

USANDO A FERRAMENTA

- Use sempre óculos de protecção quando estiver operando ou executando serviço de manutenção nesta ferramenta.
- Use sempre protecção contra ruído ao operar esta ferramenta.
- Mantenha as mãos, partes do vestuário soltas e cabelos compridos afastados da extremidade em rotação.
- Antecipe e esteja alerta a mudanças repentinhas no movimento quando ligar e operar qualquer ferramenta motorizada.
- Mantenha a posição do corpo equilibrada e firme. Não exagere quando operar esta ferramenta. Torques de reacção elevados podem ocorrer na ou abaixo da pressão de ar recomendada.
- Os acessórios da ferramenta podem continuar a girar brevemente após a pressão ter sido aliviada.
- Ferramentas accionadas pneumáticamente podem vibrar em uso. Vibração, movimentos repetitivos ou posições desconfortáveis podem ser prejudiciais às mãos e aos braços. Pare de usar a ferramenta caso ocorra algum desconforto, sensação de formigueiro ou dor. Procure assistência médica antes de retornar ao trabalho.
- Use acessórios recomendados pela Ingersoll-Rand.
- Esta Ferramenta não foi concebida para trabalhos em atmosferas explosivas.
- Esta Ferramenta não está isolada contra choques eléctricos.

AVISO

O uso de peças de substituição que não sejam genuinamente da Ingersoll-Rand podem resultar em riscos de segurança, diminuição do desempenho da ferramenta, aumento da necessidade de manutenção e pode invalidar todas as garantias.

As reparações devem ser feitas somente por pessoal treinado autorizado. Consulte o Centro de Serviços da Ingersoll-Rand mais próximo.

Envie Todos os Comunicados Para o Distribuidor ou Escritório da Ingersoll-Rand Mais Próximo.

© Ingersoll-Rand Company 1999


Impresso nos E.U.A.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

IDENTIFICAÇÃO DO RÓTULO DE ADVERTÊNCIA

! ADVERTÊNCIA

O NÃO CUMPRIMENTO DAS SEGUINTE ADVERTÊNCIAS PODE RESULTAR EM FERIMENTO.

	ADVERTÊNCIA Use sempre óculos de protecção quando estiver operando ou executando algum serviço de manutenção nesta ferramenta.
	ADVERTÊNCIA Use sempre protecção contra o ruído ao operar esta ferramenta.
	ADVERTÊNCIA Desligue sempre a alimentação de ar e desconecte a mangueira de alimentação de ar antes de instalar, remover ou ajustar qualquer acessório nesta ferramenta, ou antes de executar algum serviço de manutenção nesta ferramenta.
	ADVERTÊNCIA Ferramentas accionadas pneumáticamente podem vibrar em uso. Vibração, movimentos repetitivos ou posições desconfortáveis podem ser prejudiciais às mãos e aos braços. Pare de usar a ferramenta caso ocorra algum desconforto, sensação de formigueiro ou dor. Procure assistência médica antes de retornar ao trabalho.
	ADVERTÊNCIA Mantenha a posição do corpo equilibrada e firme. Não exagere quando operar esta ferramenta. Torques de reacção elevados podem ocorrer sob a pressão de ar recomendada.
	ADVERTÊNCIA Operar com pressão do ar Máxima de 90–100 psig(6.2–6.9bar).

ADVERTÊNCIAS ESPECÍFICAS SOBRE A ESMERILADORA

! ADVERTÊNCIA

O NÃO CUMPRIMENTO DAS SEGUINTE ADVERTÊNCIAS PODE RESULTAR EM FERIMENTO.

- Não use esta ferramenta se a velocidade livre total exceder a rpm indicada na placa de identificação.
- Antes de montar o disco, depois de qualquer reparação de ferramenta ou quando se pretende que uma Esmeriladora seja colocada em funcionamento, verifique a velocidade livre da Esmeriladora com um tacómetro para se certificar de que a sua velocidade real a 6,2 bar/620kPa (90 psig) não excede a rpm selada ou impressa na placa de identificação. As Esmeriladoras em funcionamento devem ser similarmente verificadas pelo menos uma vez em cada turno.
- Use sempre o Protector do Disco da Ingersoll-Rand fornecido com a Esmeriladora
- Não use qualquer disco de esmerilamento, broca ou outro acessório que possua uma velocidade máxima de operação menor do que a velocidade livre da Esmeriladora que esteja a ser usada. Respeite sempre a máxima rpm nos adaptadores de disco de esmerilamento.
- Verifique todas os discos de esmerilamento para ver se há lascas ou rachaduras antes da montagem. Não use um disco que esteja lascado ou rachado ou de alguma maneira danificado. Não use um disco que tenha sido encharcado com água ou qualquer outro líquido.
- Verifique se o disco de esmerilamento se encaixa na árvore de montagem. Não use rolamentos redutores para adaptar um disco na árvore de montagem a não ser que tais rolamentos tenham sido fornecidos ou recomendados pelo fabricante do disco.
- Depois de montar um novo disco, segure a Esmeriladora sob uma bancada de aço ou dentro de uma moldagem e

coloque-a em funcionamento por 60 segundos. Verifique se não há ninguém dentro do plano de operação. Se o disco estiver com algum defeito, inadequadamente montado ou se for do tamanho errado ou tiver velocidade incorrecta, este é o momento em que ele normalmente falhará.

- Quando iniciar um trabalho com um disco frio, ponha-o a trabalhar lentamente até que o disco aqueça gradualmente Faça um contacto suave com o local a ser trabalhado e evite de executar qualquer ação de batimento ou pressão excessiva.
- Reponha um protector do disco sempre que estiver danificado, torto ou severamente gasto. Não use um protector do disco que tenha sido sujeito a uma falha do disco.
- Certifique-se de que as flanges da roda sejam pelo menos 1/3 do diâmetro do disco de esmerilamento, livre de cortes, arestas e extremidades afiadas. Use sempre flanges do disco fornecidas pelo fabricante. Nunca use uma flange provisória ou uma anilha plana. Aperte bem a Porca da Flange.
- A abertura do protector deve estar afastada do operador. O fundo do disco não deve se extender para fora do protector.
- As Esmeriladoras de Ângulo Séries HA90 possuem uma velocidade livre de 9.000 rpm e as Séries HA120 e HXA120 possuem 12.000 rpm, quando operadas sob uma pressão de ar de 6,2 bar/620 kPa (90 psig). Operações sob condições de pressões mais elevadas resultarão em velocidades excessivas.

(continua)

ADVERTÊNCIAS ESPECÍFICAS SOBRE A ESMERILADORA

- Use sempre uma pinça cuja dimensão seja igual ao encabado ouro acessório.
- Insira sempre o encabado ouro da ferramenta com comprimento que não seja inferior a 10mm no colete. Aperte a Porca do Pinça seguramente para evitar que o acessório se desajuste durante a operação da

esmeriladora. Verifique o aperto da Porca do Pinça antes de operar a esmeriladora. Preste particular atenção ao facto de que a velocidade permitida de um ponto montado é diminuída quando o comprimento do eixo é aumentado entre a extremidade da pinça e o ponto montado. (pendurado)

ADVERTÊNCIA: Combinações incorrectas de disco de esmerilamento, protector disco e velocidade da ferramenta pode resultar em ferimento. As combinações correctas estão especificadas abaixo:

Número de Peça do Protector	Tipo do Disco	Diâmetro do Disco mm (pol.)	Espressura Máxima do Disco mm (pol.)	Velocidade Máxima rpm
LE2-931	1	(3) 76	12,7 (1/2)	20 500

COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

LUBRIFICAÇÃO



Ingersoll-Rand No. 10

Ingersoll-Rand No. 68

Ingersoll-Rand No. 50


Use sempre um lubrificador de ar de linha com estas ferramentas. Nós recomendamos a seguinte Unidade Filtro-Lubrificador-Regulador :

E.U.A. – No. C28-04-FKG0-28

Depois de cada duas horas de operação, se estiver usando um lubrificador de ar de linha, injecte 1/2 a 1 cc de Óleo Ingersoll-Rand No. 10 na Entrada de Ar.

CUIDADO

Não marque as superfícies não metálicas desta ferramenta com códigos de identificação do cliente. Tais acções podem afectar o desempenho da ferramenta.




MONTAGEM DO ACESSÓRIO DE CORTE

Para montar um acessório de corte TD-RK4 ou TD-RK6 numa Esmeriladora TD200 ou TD250 que tenha uma pinça, proceda da seguinte forma :

1. Use uma Chave Manual de Bocas para segurar a Máquina evitando assim que esta gire. Desaparafuse a porca da pinça da esmeriladora. Retire a Pinça.
2. Segure a ferramenta num torno de bancada, protegendo-a com mordentes de cobre ou couro, com o eixo para cima. Com uma chave de 1-1/2", desaparafuse e remova a Porca da Pinça. Esta é uma rosca à esquerda. Gire a porca **no sentido dos ponteiros do relógio** para removê-la.
3. Instale o Acessório de Corte.
4. Aperte a Porca da Pinça no Veio da Máquina com um torque entre 27 e 34 Nm (20 e 25 pés-lb). Esta é uma rosca à direita. Gire a Porca **no sentido contrário ao dos ponteiros do relógio** para a apertar.
5. Coloque a Pinça no veio da máquina e aperte livremente a Porca. Introduza um acessório de corte na pinça e aperte a respectiva porca.
6. Instale o Acessório Adaptador Final sobre a mó e aperte o Acessório entre 2,7 e 3,4 Nm (2,0 e 2,5 pés-lb). Esta é uma rosca à esquerda. Gire a Porca **no sentido contrário ao dos ponteiros do relógio** para a apertar.
7. Instale a Porca e aperte-a com um torque de 1,3 a 2,0 Nm (12 e 18 pés-lb).
8. Aperte a Porca e o Acessório Adaptador Final.
9. Esse aperto deve obedecer ao seguinte torque : 19,0 e 25,8 Nm (14 e 19 pés-lbs).
10. Se se usar uma Guia Final de Aperto, esta deverá ser colocada posteriormente ao acessório adaptador com um aperto entre 4,1 e 5,4 Nm (3 e 4 pés-lb).

COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

GUIA FINAL DE APERTO



Dimensões da Guia Final de Aperto

(Desenho TPD1208)

NÚMERO DE REFERÊNCIA PARA PEDIDO	A	B	C	D	E
R120-128-2 (para haste de 1/4")	1-1/2	3/8	3/8	1/8	1/2-20NF
R120-128-7 (para haste de 1/4")	2-1/2	1/2	1/2	3/16	1/2-20NF
LG2-129-1 (para haste de 3/8")	2-1/2	1/2	5/8	1/8	5/8-18UNF

★ Nota : Ressalto = 1/2 (Dimensão "B" menos o diâmetro do acessório da guia final de aperto).

O seguinte equipamento está disponível por um custo extra e deve ser encomendado separadamente :

1. Arranjo do Acoplamento do Acessório

para modelos que utilizem bites de diâmetro de 1/4" Referência No. TD-RK4
para modelos que utilizem bites de diâmetro de 3/8" Referência No. TD-RK6

2. Guia Final de Aperto (para Acoplamento do Acessório)

para haste de 1/4" Referência No. R120-128-2
para haste de 1/4" Referência No. R120-128-7
para haste de 3/8" Referência No. LG2-129-1

AVISO

Todos os modelos listados na página 5 podem ser trocados por ferramentas com escape frontal ao inverter o Anel de Fluxo e alinhar o indicador marcado com a "F" no Corpo. Para pedir uma ferramenta com escape frontal de fábrica substitua a letra "F" pela letra "R" nos modelos acima. Exemplo : O Modelo com Escape Traseiro TD12RG4 torna-se Modelo com Escape Frontal TD120FG4.

COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

— NOVO GUIA DE COMBINAÇÃO DE CORES ENTRE A ESMERILADORA E O ACESSÓRIO —

A Ingersoll-Rand é pioneira no desenho de um novo sistema de código de cores para :

1. Simplificar a identificação da velocidade aferida de uma ferramenta através de uma única combinação de cores correspondentes.

2. Comunicam facilmente os painéis traseiros e acessórios apropriados para cada ferramenta através de um sistema de códigos de combinação de cores nos painéis traseiros e/ou acessórios correspondentes à Esmeriladora.
3. A tabela abaixo demonstra o sistema de códigos de cores correspondentes à Esmeriladora e ao Acessório.

(LEIA DA ESQUERDA PARA A DIREITA)

COR DA VELOCIDADE NA PLACA DE IDENTIFICAÇÃO	VELOCIDADE AFERIDA DA FERRAMENTA	ACESSÓRIO DE INTERVALO SEGURO (MÁXIMA VELOCIDADE DE OPERAÇÃO)							
		35,000	30,000	25,000	20,000	18,000	15,000	12,000	9,000
VERMELHA	35,000	VERMELHA							
LARANJA	30,000		LARANJA						
AMARELA	25,000			AMARELA					
VERDE	20,000				VERDE				
AZUL	18,000					AZUL			
CINZA	15,000						CINZA		
MARRON								MARRON	
CLARO								CLARO	
VIOLETA	12,000								VIOLETA
	9,000	↓	↓	↓	↓	↓	↓		

(Desenho TPD1146-1)

ESPECIFICAÇÕES

1/4" PINÇA

Modelo	Velocidade Livre
TD250RG4	25.000
TD200RG4	20.000
TD180RG4	18.000
TD120RG4	12.000

1/4" PINÇA

TX250RG4	25.000
TX180RG4	18.000
TD120RG4	12.000


3" ROSCA DO FUSO

TX180RH63	18.000
-----------	--------

3" ROSCA DO FUSO

TXD180RH63	18.000
------------	--------

MAINTENANCE SECTION





PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

Common parts for ALL TD, TX and TXD Grinders						
1	Inlet Assembly	LG2-A465	15	Front End Plate Spacer	LG2-65
2	Inlet Screen	R1602-61	• 16	Front Seal Cup Assembly	61H-A32
3	Inlet Seal	R18LF-21	17	Front Rotor Bearing	LG2-24
4	Throttle Valve Spring Seat	LG3-592	18	Flow Ring for TD120 and TX120 (12 000 rpm) (grey)	LG2-103-0
4A	Throttle Valve Spring	7L-51		for TD180, TX180 and TXD180 (18 000 rpm) (brown)	LG2-103-1
4B	Throttle Valve	LG2-302		for TD200 and TX200 (20 000 rpm) (khaki)	LG2-103-2
4C	Throttle Valve Seat	LG2-303		for TD250 and TX250(25 000 rpm) (red)	LG2-103-3
4D	Throttle Valve Case	LG2-300A		High Profile Flange	LG2-23
5	Motor Housing	LG2-40	19	Low Profile Concentric Flange (for all models ending in C)	LG3R-23
6	Throttle Lever	LG2-273	# 19A	Flange Clamp	LG2-29
6A	Locking Throttle Lever Assembly (for all models ending in L or C)	LG2-A400	20	Exhaust Hose Adapter	LG2-184
*	Lever Lock	LG1-402	+ 20A	Exhaust Hose	3RL-284
*	Lock Spring	LG1-405	+ 20B	Hose Retainer	6WT-203
*	Lock Pin	5UT-757	+ 20C	Warning Label for models ending in H63-EU	EU-63-99
7	Throttle Lever Pin	61H-120	*	for all other models ending in -EU	EU-99
8	Throttle Valve Plunger	LG2-191		for all other models	LG2-99
9	Rear Rotor Bearing	R120-127				
10	Rear Rotor Bearing Spacer (2)	400-25-191				
11	Rear Rotor Bearing Retainer	LG1-118				
12	Rotor	LG2-53-4				
13	Vane Packet (set of 4 Vanes)	DG21-42-4				
14	Front End Plate	LG2-11				

* Not illustrated.

- To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (•) for every four tools in service.
 - + Standard equipment with models ending in **M**, **MC** or **ML** and **ALL** Front Exhaust models; optional equipment on all other models.

+ Standard equipment with models ending in **M**, **MC** or **ML** and **ALL** Front Exhaust models; optional equipment on all other models.

! WARNING


- # Always install a Locking Throttle Lever Assembly (6A) on a tool with a Low Profile Concentric Flange (19A). Do not equip a tool with a standard non-locking Lever (6) and Low Profile Concentric Flange. This can allow the tool to continue to run if dropped or set down.

MAINTENANCE SECTION

		PART NUMBER FOR ORDERING		PART NUMBER FOR ORDERING	
*	Nameplate				
	for TD120 models ending in -EU	LG212-EU-301	34	Arbor	LE2-4-5
	for all other TD120 models	LG212-301	35	Arbor Housing	LE2-20-5
	for TD180 models ending in -EU	LG218-EU-301	36	Arbor Housing Plug	EG220-92
	for all other TD180 models	LG218-301	37	Front Arbor Bearing	WFS182-22
	for TD200 models ending in -EU	LG220-EU-301	37A	Arbor Bearing Shield (for models ending in G4)	LE2-200
	for all other TD200 models	LG220-301	38	Arbor Bearing Retaining Ring	W22-118
	for TD250 models ending in -EU	LG225-EU-301		Parts common to all models ending in G4	
	for all other TD250 models	LG225-301	39	Collet Body	LG2-290
	for TX120 models	LE212-301	39A	Front Seal Cup	61H-32
	for TX180 models ending in -EU	LE218-EU-301	40	Collet	
	for all other TX180 models	LE218-301		for models ending in RT4 or -EU	G160HD-700-6mm
	for TXD180 models ending in -EU	LED218-EU-301		for all other models	G160HD-700-1/4
	for all other TXD180 models	LED218-301	41	Collet Nut Assembly	DG120-699A
	for TX200 models	LE220-301	41A	Collet Body Wrench	DG10-69
	for TX250 models ending in -EU	LE225-EU-301	41B	Collet Nut Wrench	DG120-69
	for all other TX250 models	LE225-301		Parts common to all models ending in H63	
23	Additional parts for all TD models		42	Guard Adapter Assembly	LE2-A710
21	Clamp Spacer	LG2-46	43	Guard Adapter Screw	231-638
22	Clamp Nut	LG2-27	44	3" Wheel Guard	LE2-931
	Additional parts for all extended TXD models		45	Wheel Guard Mounting Screw (3)	LE2-667
23	Clamp Sleeve	LE2-176	46	Mounting Screw Washer (3)	L01-67
24	Arbor	LE2-4	47	3" Straight Wheel Adapter	LE2-4-H63
25	Arbor Housing	LE2-20	47A	Front Seal Cup	61H-32
26	Arbor Housing Plug	EG220-92	48	3" Wheel Flange	DEG31-16
27	Front Arbor Bearing	WFS182-22	49	Flange Nut	23-697
28	Arbor Bearing Retaining Ring	W22-118		Accessories	
	Additional parts for all TX models		*	Bearing Inserting Tool (for TX and TXD models) (2 pieces)	LE2-950
29	Arbor Coupling	LE2-304	*	Cone Wheel Adapter (for TX models)	LE2-104-L6
30	Clamp Sleeve	LE2-276	*	Exhaust Deflector Assembly	04353207
31	Arbor Bearing Nut (2)	LE2-85			
32	Coupling Retaining Ring (2)	RX3-729			
33	Rear Arbor Bearing	LE2-22			

* Not illustrated.

MAINTENANCE SECTION
ROUTER ATTACHMENT FOR MODELS TD200 AND TD250 WITH COLLETS



(Dwg. TPC542)

PART NUMBER FOR ORDERING

Router Attachment Assembly		
	for models using 1/4" diameter bits	TD-RK4
	for models using 3/8" diameter bits	TD-RK6
75	Clamp Spacer	LG2-19
76	Nosepiece Adapter	LG2-124
77	Adapter Lock Screw	0E9-561
78	Nosepiece Assembly	
	for models using 1/4" collet	LG2-A125-1
	for models using 3/8" collet	LG2-A125-3
79	Nosepiece Bearing	
	for LG2-A125-1	TD200-127
	for LG2-A125-3	G160-22
80	Bearing Retaining Ring	
	for LG2-A125-1	RXA21-343
	for LG2-A125-3	3RL-28
81	Lock Nut	R120-126
82	Lock Nut Wrench	LG2-237

MAINTENANCE SECTION

⚠️ WARNING

- Always wear eye protection when operating or performing maintenance on this tool.
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.

LUBRICATION

Whenever one of these Grinders is disassembled for overhaul or replacement of parts, lubricate as follows:

1. Always wipe the Vanes (13) with a light film of oil before inserting them into the vane slots.
2. Lubricate the Front Seal Cup Assembly (16, 39A or 47A) with Ingersoll-Rand No. 50 Oil.
3. Inject 0.5 to 1.0 cc of Ingersoll-Rand No. 10 Oil into the Air Inlet Assembly (1) after assembly.

DISASSEMBLY

General Instructions

1. Do not disassemble the tool any further than necessary to replace or repair damaged parts.
2. When grasping a tool or part in a vise, always use leather-covered or copper-covered vise jaws to protect the surface of the part or tool and help prevent distortion. This is particularly true of threaded members and housings.
3. Do not remove any part which is a press fit in or on a subassembly unless the removal of that part is necessary for repairs or replacement.
4. Do not disassemble the tool unless you have a complete set of new gaskets and O-rings for replacement.
5. Do not press any needle bearing from a part unless you have a new needle bearing on hand for installation. Needle bearings are always damaged during the removal process.

Steps common to ALL models ending in G4

1. Using the Collet Body Wrench (41A) to hold the Collet Body (39) from turning and the Collet Nut Wrench (41B) on the Collet Nut Assembly (41), unscrew and remove the Nut.
2. Remove the Collet (40).

Steps common to ALL models ending in H63

1. Use an adjustable spanner wrench in one of the holes in the Wheel Adapter (47) and a 9/16" wrench to loosen and remove the Flange Nut (49). Remove the Wheel Flange (48) and grinding wheel.

2. Using a 5/32" hex wrench, loosen the Guard Adapter Screw (43) and pull the Guard Adapter Assembly (42) and assembled Guard (44) from the Arbor Housing (35).

Steps common to ALL TD models

1. Grasp the tool in copper-covered or leather-covered vise jaws with the spindle upward and using a 1-1/2" wrench, unscrew and remove the Clamp Nut (22). This is a **left-hand thread** and must be rotated **clockwise**.
2. Remove the Clamp Spacer (21) and Flange Clamp (20).
3. Pull the Flange (19) and Flow Ring (18) off the front of the Motor Housing (5).
4. Grasp the Collet Body and pull the assembled motor out of the Motor Housing. Remove the Motor Housing from the vise and remove the two Rear Rotor Bearing Spacers (10) from the bottom of the Housing.
5. Remove the Vanes (13) from the Rotor (12).
6. Grasp the Rotor in copper-covered or leather-covered vise jaws with the Collet Body (39) upward. Using the Collet Body Wrench (41A), unscrew and remove the Collet Body. Remove the Front Seal Cup Assembly (39A) from the Collet Body.

Steps common to ALL TXD models

1. Use a screwdriver to remove the Arbor Housing Plug (26) and rotate the Arbor (24) until the crosshole in the Arbor is aligned with the opening in the Arbor Housing (25).
2. Insert a 5/32" (4 mm) diameter hardened steel rod approximately 6" (150 mm) long through the arbor crosshole to sprag the Arbor. Using a spanner wrench on the Wheel Adapter (47), unscrew and remove the Adapter.
3. Grasp the tool in copper-covered or leather-covered vise jaws with the spindle upward and using a 1-1/2" wrench, unscrew and remove the Arbor Housing. This is a **left-hand thread** and must be rotated **clockwise**.
4. Remove the Clamp Sleeve (23), Flange Clamp (20), Flange (19) and Flow Ring (18) from the front of the Motor Housing (5).
5. Using snap ring pliers, remove the Arbor Bearing Retaining Ring (28).
6. Stand the Arbor Housing (25), threaded end upward, on the table of an arbor press and using a rod or piece of tubing that contacts the outer ring of the bearing, press the Front Arbor Bearing (27) from the Arbor Housing.
7. Grasp the Arbor and pull the assembled motor out of the Motor Housing. Remove the Motor Housing from the vise and remove the two Rear Rotor Bearing Spacers (10) from the bottom of the Housing.

MAINTENANCE SECTION

8. Remove the Vanes (13) from the Rotor (12).
9. Grasp the Rotor in copper-covered vise jaws with the Arbor upward. Using a 5/32" diameter rod through the crosshole, unscrew and remove the Arbor.

Steps common to ALL TX models

1. Use a screwdriver to remove the Arbor Housing Plug (36) and rotate the Arbor (34) until the crosshole in the Arbor is aligned with the opening in the Arbor Housing (35).
2. Insert a 5/32" (4 mm) diameter hardened steel rod approximately 6" (150 mm) long through the arbor crosshole to sprag the Arbor.

For models ending in H63

Using a spanner wrench on the Wheel Adapter (47), unscrew and remove the Adapter. Remove the Front Seal Cup Assembly (47A) from the Adapter.

For models ending in G4

Using the Collet Body Wrench (41A) on the Collet Body (39), unscrew and remove the Collet Body. Remove the Front Seal Cup Assembly (39A) from the Collet Body.

3. Grasp the tool in copper-covered or leather-covered vise jaws with the spindle upward and using a 1-1/2" wrench, unscrew and remove the Arbor Housing (35). This is a **left-hand thread** and must be rotated **clockwise**.
4. Remove the Clamp Sleeve (30), Arbor Coupling (29) and the Flange Clamp (20).
5. Grasping the Arbor Bearing Nut (31), pull the Arbor out of the Arbor Housing.
6. Using snap ring pliers, remove the Arbor Bearing Retaining Ring (38) from the Arbor Housing.
7. **For models ending in G4**, remove the Arbor Bearing Shield (37A).
8. Stand the Arbor Housing (35), threaded end upward, on the table of an arbor press and using a rod or piece of tubing that contacts the outer ring of the bearing, press the Front Arbor Bearing (37) from the Arbor Housing.
9. Insert a 5/32" (4 mm) diameter hardened steel rod approximately 6" (150 mm) long through the crosshole in the Arbor and using a 1/2" wrench on the Arbor Bearing Nut, unscrew and remove the Nut.
10. Using an arbor press, press the Rear Arbor Bearing (33) off the Arbor.
11. Pull the Flange (19) and Flow Ring (18) off the front of the Motor Housing (5).
12. Grasp the Arbor Bearing Nut on the rotor shaft and pull the assembled motor out of the Motor Housing. Remove the Motor Housing from the vise and remove the two Rear Rotor Bearing Spacers (10) from the bottom of the Housing.
13. Remove the Vanes (13) from the Rotor (12).
14. Grasp the Rotor in copper-covered or leather-covered vise jaws with the Arbor Bearing Nut upward. Using a 1/2" wrench, unscrew and remove the Arbor Bearing Nut.

Steps common to ALL models

1. If the Front Rotor Bearing (17) must be replaced, support the Front End Plate (14) between two blocks on the table of an arbor press. Place the blocks as close to the body of the Rotor (12) as possible and press the Rotor from the Bearing and End Plate. Remove the Front End Plate Spacer (15) and Front Seal Cup Assembly (16) from the hub of the Rotor.
2. If the Rear Rotor Bearing (9) must be replaced, use snap ring pliers to remove the Rear Rotor Bearing Retainer (11).
3. Using a bearing puller, pull the Rear Rotor Bearing off the hub of the Rotor.

Disassembly of the Inlet and Throttle

1. Using a 6 point 15/16" socket, unscrew and remove the Inlet Assembly (1).
2. Remove the Inlet Seal (3) and Inlet Screen (2) from the Inlet.
3. Remove the Throttle Valve Spring Seat (4), Throttle Valve Spring (4A) and Throttle Valve (4B) from the Motor Housing (5).
4. If the Throttle Valve Seat (4C) must be replaced, insert a hooked tool through the central opening of the Seat and, catching the underside of the Seat, pull it from the Housing.
5. If the Throttle Valve Cartridge Case (4D) must be replaced, insert two hooked tools through the central opening of the Case approximately 180 degrees apart and, catching the underside of the Case, pull it from the Housing.
6. Press the Throttle Lever Pin (7) from the Housing and remove the Throttle Lever (6). Remove the Throttle Valve Plunger (8).

ASSEMBLY

General Instructions

1. Always press on the **inner** ring of a ball-type bearing when installing the bearing on a shaft.
2. Always press on the **outer** ring of a ball-type bearing when pressing the bearing into a bearing recess.
3. Whenever grasping a tool or part in a vise, always use leather-covered or copper-covered vise jaws. Take extra care not to damage threads or distort housings.
4. Except for bearings, always clean every part and wipe every part with a thin film of oil before installation.
5. Check every bearing for roughness. If an open bearing must be cleaned, wash it thoroughly in **clean** solvent and dry with a clean cloth. **Sealed or shielded bearings should not be cleaned**. Work grease into every open bearing before installation.
6. Apply a film of O-ring lubricant to every O-ring before installation.

MAINTENANCE SECTION

Assembly of the Inlet and Throttle

1. Insert the Throttle Valve Plunger (8) into the Motor Housing (5).
2. Position the Throttle Lever (6) on the Motor Housing and using an arbor press, press the Throttle Lever Pin (7) into the Housing and Lever. The Lever will retain the Plunger in the Housing.
3. If the Throttle Valve Cartridge Case (4D) was removed, lubricate the outside and the throttle stem end of the Case with O-ring lubricant. Using a wooden dowel, push the Case, open end trailing, into the Motor Housing.
4. If the Throttle Valve Seat (4C) was removed, use a 5/8" wooden dowel with a flat end to push the Seat into the Motor Housing.
5. Push the small end of the Throttle Valve Spring (4A) onto the end of the Throttle Valve (4B) with the short stem until the Spring snaps into position around the hub and remains there. Install the dish end of the Throttle Valve Spring Seat (4) onto the large end of the Throttle Valve Spring.
6. Holding the Housing with the Lever downward, make sure the Plunger is out of the way and insert the assembled Throttle Valve, long stem end leading, into the housing recess.
7. Push the Inlet Screen (2), closed end leading, into the Inlet Assembly (1). After moistening a new Inlet Seal (3) with o-ring lubricant and being careful not to nick the Seal on the threads of the Inlet, install the Seal on the Inlet.
8. Thread the Inlet Assembly into the Housing and tighten it between 13 to 15 ft-lb (18 to 20 Nm) torque.

Assembly of the Motor

Steps common to ALL models

1. If the Rear Rotor Bearing (9) was removed, stand the Rotor (12) upright on the table of an arbor press with the threaded end downward. Make sure the threaded end passes through a hole drilled in a block so that the Rotor rests against the large rotor body. Press the Rear Rotor Bearing onto the hub of the Rotor.
2. Install the Rear Rotor Bearing Retainer (11) in the groove on the hub of the Rotor.
3. Install the Front End Plate (14), counterbored end trailing, onto the threaded hub of the Rotor. Using finger pressure, press the Front Seal Cup Assembly (16), felt end trailing, onto the end of the Front End Plate Spacer (15) that is opposite the large internal bevel. Continue pressing until the felt end is flush with the end of the Spacer. Lubricate the felt with Ingersoll-Rand No. 50 Oil. Place the assembled Spacer, Seal Assembly trailing, onto the threaded hub of the Rotor. Make sure the Seal Assembly enters the recess in the Front End Plate.

NOTICE

Before performing the next step, be aware that the Front Rotor Bearing is a flush ground bearing and must be installed in a specific manner. The end of the Bearing with a black stain or hash marks must be away from the Spacer.

4. Stand the Rotor on the table of an arbor press with the threaded end upward and press the Front Rotor Bearing (17) onto the hub of the Rotor.
5. Grasp the assembled Rotor in copper-covered or leather-covered vise jaws with the threaded rotor hub upward.
6. For TD models, using finger pressure, press the Front Seal Cup Assembly (39A or 47A), felt end trailing, onto the rotor end of the Collet Body (39) or Wheel Adapter (47). Continue pressing until the felt end is flush with the end of the Collet Body or Wheel Adapter. Lubricate the felt with Ingersoll-Rand No. 50 Oil.
7. If the Front Arbor Bearing (27) must be replaced on a Model TXD, proceed as follows before assembling the motor:
 - a. Place the Clamp Sleeve (23) on the table of an arbor press and install the large end of the Arbor Housing (25) on the Clamp Sleeve.
 - b. Slide the Front Arbor Bearing onto the threaded hub of the Arbor (24) and insert the Arbor, bearing end trailing, into the Housing. Make certain the end of the Arbor rests on the arbor press table and the Bearing is aligned with the bore in the Housing.
 - c. Install the small piece of the LE2-950 Bearing Inserting Tool over the Arbor and press the Bearing into the Housing until it stops against the shoulder of the Arbor.
 - d. Remove the Arbor from the Housing and Bearing but keep the parts together so that the same parts are installed together. Do not mix and match Arbors with Bearings and Housings.
8. Thread the Collet Body and Seal Assembly (for TD models), Arbor (24) (for TXD models) or the Arbor Bearing Nut (31), Retainer end leading, (for TX models) onto the Rotor and using a torque wrench, tighten the Collet Body, Arbor or Arbor Bearing Nut between 14 and 19 ft-lb (19 and 26 Nm) torque.
9. Inject approximately 3/4 cc of Ingersoll-Rand No. 68 Grease into the small recess at the bottom of the motor housing bore. Drop the two Rear Rotor Bearing Spacers (10) into the bottom of the motor housing bore.
10. Wipe each Vane (13) with a light film of oil and insert a Vane into each vane slot in the Rotor.

MAINTENANCE SECTION

11. Grasp the Collet Body, Arbor or Arbor Bearing Nut and insert the assembled Rotor into the Motor Housing (5).
12. Assemble the Flow Ring (18) with the Flange (19) before installing the Flange on the Housing. Mate the Flow Ring to the end of the Flange without perforations. The positioning of the Flow Ring is dictated by the desired exhaust. To set the tool exhaust, proceed as follows:
 - a. **For front exhaust tools**, align the notched projection on the edge of the Flow Ring with the letter "F" on the Housing.
 - b. **For rear exhaust tools**, align the notched projection on the edge of the Flow Ring with the letter "R" on the Housing.
13. Install the assembled Flange, Flow Ring leading, onto the front of the Motor Housing.
14. Grasp the Motor Housing in copper-covered or leather-covered vise jaws with the Collet Body, Arbor or Arbor Bearing Nut upward. Do not distort the Housing.
15. Position the Flange Clamp (20) against the Flange.

Steps common to ALL TX models

1. Lubricate the Arbor Coupling (29) with approximately 1 cc of Ingersoll-Rand No. 68 Grease and position the Coupling over the Arbor Bearing Nut (31). Position the Clamp Sleeve (30) over the Arbor Coupling against the Front Rotor Bearing (17).
2. If the Rear Arbor Bearing (33) was removed, proceed as follows:
 - a. Stand the larger piece of the LE2-950 Bearing Inserting Tool on the table of an arbor press.
 - b. Place the Rear Arbor Bearing on the surface of the Inserting Tool and align the central opening of the Bearing with the central opening of the Inserting Tool.
 - c. The large body of the Arbor (34) has an annular groove between the crosshole and one threaded end. Press that end of the Arbor into the Bearing until the shoulder of the Arbor stops against the Bearing.
3. If the Front Arbor Bearing (37) was removed from the Arbor Housing (35), proceed as follows:
 - a. If the Rear Arbor Bearing was not removed from the Arbor, insert a 5/32" (4 mm) hardened steel rod approximately 6" (150 mm) long through the crosshole and using a 1/2" wrench, unscrew and remove the Arbor Bearing Nut (31) from the Arbor. **Do not remove the Bearing.**

- b. Stand the larger piece of the No. LE2-950 Bearing Inserting Tool on the table of an arbor press and insert the Arbor, Rear Arbor Bearing end leading, into the central opening of the piece until the Bearing stops against the top of the Inserting Tool.
 - c. Install the Arbor Housing, threaded end first, over the Arbor until it stops against the Bearing and pilots on the Bearing Inserting Tool.
 - d. Position the Front Arbor Bearing on the Arbor and using the smaller piece of the No. LE2-950 Bearing Inserting Tool as a pressing tool and pilot, press the Bearing onto the Arbor until it stops against the arbor shoulder.
 - e. **For models ending in G4**, install the Arbor Bearing Shield (37A) in the Housing against the Bearing.
 - f. Using snap ring pliers, install the Arbor Bearing Retaining Ring (38) in the Arbor Housing.
4. Insert a 5/32" (4 mm) hardened steel rod approximately 6" (150 mm) long through the crosshole and using a 1/2" wrench, thread the Arbor Bearing Nut onto the Arbor against the Rear Arbor Bearing. Tighten the Nut between 14 and 19 ft-lb (19 and 26 Nm) torque.
 5. Align the rear Arbor Bearing Nut with the hex in the Arbor Coupling. Thread the Arbor Housing onto the Motor Housing and tighten the joint between 20 and 25 ft-lb (27 and 34 Nm) torque. This is a **left-hand thread**. Turn **counterclockwise** to tighten.
 6. **For collet models**, insert a 5/32" (4 mm) hardened steel rod approximately 6" (150 mm) long through the arbor crosshole. Thread the assembled Collet Body onto the Arbor and using a torque wrench, tighten the joint between 14 and 19 ft-lb (19 and 26 Nm) torque.

Steps common to ALL TXD models

1. Position the Clamp Sleeve (23) over the Arbor against the Front Rotor Bearing (17).
2. Thread the Arbor Housing (25) onto the Motor Housing and tighten the joint between 20 and 25 ft-lb (27 and 34 Nm) torque. This is a **left-hand thread**. Turn **counterclockwise** to tighten.
3. Using snap ring pliers, install the Arbor Bearing Retaining Ring (28) in the Arbor Housing.

Steps common to ALL TD models

1. Position the Clamp Spacer (21) over the Arbor against the Front Rotor Bearing (17).
2. Thread the Clamp Nut (22) onto the Housing and tighten the Nut between 20 and 25 ft-lb (27 and 34 Nm) torque. This is a **left-hand thread**. Turn **counterclockwise** to tighten.

MAINTENANCE SECTION

Steps common to ALL models ending in H63

1. Insert a 5/32" (4 mm) diameter hardened steel rod approximately 6" (150 mm) long through the opening in the Arbor Housing and Arbor to keep the Arbor from turning. Using an adjustable spanner wrench, tighten the Wheel Adapter (47) between 14 and 19 ft-lb (19 and 26 Nm) torque.
2. Remove the rod and install the Arbor Housing Plug (26 or 36).
3. If the Wheel Guard (44) was removed from the Guard Adapter (42), attach the Guard to the Adapter with the three Wheel Guard Mounting Screws (45) and Mounting Screw Lock Washers (46). Tighten each Screw between 2-1/2 and 3 ft-lb (3.4 and 4.1 Nm) torque.
4. Install the assembled Guard Adapter and Wheel Guard on the front end of the Arbor Housing, flush with the end of the Housing. Install the Guard Adapter Screw (43) into the Adapter and tighten the Screw between 3-1/2 and 4 ft-lb (4.7 and 5.4 Nm) torque.

5. Install in order the wheel, Wheel Flange (48) and Flange Nut (49).
6. Use an adjustable spanner wrench inserted into one of the holes in the Wheel Adapter to hold the Adapter from turning. Using a 9/16" wrench on the Flange Nut, tighten the Nut securely.

Steps common to ALL models ending in G4

1. Insert the Collet (40) into the Collet Body (39).
2. Thread the Collet Nut Assembly (41) onto the Collet Body and use the Collet Body Wrench (41A) and the Collet Nut Wrench (41B) to tighten the Nut to the Collet Body.

MAINTENANCE SECTION

TROUBLESHOOTING GUIDE		
Trouble	Probable Cause	Solution
Low power or low free speed	Insufficient air pressure	Check air line pressure at the Inlet of the Tool. It must be 90 psig (6.2 bar/620 kPa).
	Clogged muffler elements	Disassemble the Tool and agitate bare Motor Housing and Flange in clean, suitable, cleaning solution. If elements cannot be cleaned, replace the Motor Housing and/or the Flange.
	Plugged Inlet Screen	Clean the Inlet Screen in clean, suitable, cleaning solution or replace the Screen.
	Worn or broken Vanes	Install a complete set of new Vanes.
	Loose Clamp Nut or Arbor Housing	Tighten the Nut or Housing to 20 to 25 ft-lb (27 to 34 Nm) torque.
	Worn or broken Motor Housing	Replace the Motor Housing.
	Internal air leakage in the Motor Housing indicated by high air consumption/low speed or air leaking out the front and rear exhaust simultaneously.	Replace the Motor Housing.
	Grit buildup under the Throttle Lever restricting full Throttle Valve Plunger movement.	Remove the Throttle Lever and clean the groove in the Motor Housing.
	Bent stem on Throttle Valve	Replace the Throttle Valve.
Excessive runout	Front Seal Cup Assembly dragging against the shield of the Front Rotor Bearing	Reposition the Front Seal Cup Assembly.
	Bent rotor hub	Replace the Rotor.
	Loose Collet Nut	Tighten the Collet Nut until snug.
	Worn or damaged Collet or Collet Nut	Replace the damaged component and retest.
	Worn or damaged Front Rotor Bearing	Replace the Front Rotor Bearing.
	Bent, worn or broken Extension Arbor on TX or TXD models	Replace the Extension Arbor if, when mounted between centers, the runout on the arbor body exceeds 0.002" T.I.R. or 0.0005" T.I.R. on the bearing mounting diameters.
Scoring of End Plate	Worn or damaged Front Arbor Bearing on TX or TXD models	Replace the Front Arbor Bearing.
	Worn Front End Plate Spacer or Front End Plate	Install a new Front End Plate Spacer and Front End Plate.
	Worn Front Rotor Bearing	Install a new Front Rotor Bearing.

MAINTENANCE SECTION

TROUBLESHOOTING GUIDE

Trouble	Probable Cause	Solution
Leaky Throttle Valve	Dirt accumulation on Throttle Valve or Throttle Valve Seat	Disassemble, inspect and clean parts.
	Worn Throttle Valve or Throttle Valve Seat	Replace the Throttle Valve and/or Throttle Valve Seat.
	Excessive dirt build-up beneath the Throttle Lever	Clean out the slot area.
	Bent Throttle Valve Plunger	Replace the Plunger.
Exhausts at wrong direction	Incorrect orientation of the Flow Ring	Reverse the face of the Flow Ring against the Motor Housing.
Front Rotor Bearing runs hot	Incorrect installation of the Front Seal Cup Assembly	Reposition the Front Seal Cup Assembly flush with the face of the Front End Plate Spacer.
	Front End Plate Spacer rubbing the bore of the Front End Plate	Replace the Front End Plate and Front End Plate Spacer combination.
	Incorrect Front Rotor Bearing installation orientation	If a black stain or black hashmarks are not visible on the face of the Bearing when it is assembled with the End Plate and Rotor, the Bearing is installed backwards. If possible, remove the Bearing and install it correctly or replace the Bearing.
Slow tool idle	Bent or leaky Throttle Valve	Replace the Throttle Valve.
Air leakage around Flow Ring	Damaged, mutilated or missing Flange Clamp	Replace the Flange Clamp.
	Damaged Flow Ring	Replace the Flow Ring.
Rough operation/vibration	Improper lubrication or dirt buildup	Disassemble the Tool and clean in a suitable cleaning solution. Assemble the Tool and inject 3 cc of the recommended oil into the Inlet and run the Grinder long enough to coat the internal parts with the oil.
	Worn or broken Rear Rotor Bearing or Front Rotor Bearing	Replace the worn or broken Bearings. Examine the Front End Plate, Front End Plate Spacer Front Seal Cup Assembly and Rear Rotor Bearing Spacers and replace any damaged parts. If the rear end plate is damaged, replace the Rotor.
	Worn or broken Rear Arbor Bearing in TX models or Front Arbor Bearing in TX or TXD models	Replace the worn or broken Bearing.
	Dirt contaminated Front Arbor Bearing in TX or TXD models	Replace the Bearing.
	Bent, worn or broken Extension Arbor on TX or TXD models	Replace the Extension Arbor if, when mounted between centers, the runout on the arbor body exceeds 0.002" T.I.R. or 0.0005" T.I.R. on the bearing mounting diameters.

NOTICE

SAVE THESE INSTRUCTIONS. DO NOT DESTROY.