

TPD1354

03539343

Form P7064

Edition 8

June, 2000



## OPERATION AND MAINTENANCE MANUAL FOR SERIES 2934B AND 2940B SUPER DUTY IMPACTTOOLS

### NOTICE

Series 2934B and 2940B Impacttools are designed for use in structural fabrication, machinery maintenance, railroad maintenance, pipe and valve flange applications and installation of lag screws.

Ingersoll-Rand is not responsible for customer modification of tools for applications on which Ingersoll-Rand was not consulted.

### ⚠ WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.  
READ THIS MANUAL BEFORE OPERATING TOOL.**

**IT IS THE RESPONSIBILITY OF THE EMPLOYER TO PLACE THE INFORMATION  
IN THIS MANUAL INTO THE HANDS OF THE OPERATOR.**

**FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.**

#### PLACING TOOL IN SERVICE

- Always operate, inspect and maintain this tool in accordance with all regulations (local, state, federal and country), that may apply to hand held/hand operated pneumatic tools.
- For safety, top performance, and maximum durability of parts, operate this tool at 90 psig (6.2 bar/620 kPa) maximum air pressure at the inlet with 3/4" (19 mm) inside diameter air supply hose.
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.
- Do not use damaged, frayed or deteriorated air hoses and fittings.
- Be sure all hoses and fittings are the correct size and are tightly secured. See Dwg. TPD905-1 for a typical piping arrangement.
- Always use clean, dry air at 90 psig maximum air pressure. Dust, corrosive fumes and/or excessive moisture can ruin the motor of an air tool.
- Do not lubricate tools with flammable or volatile liquids such as kerosene, diesel or jet fuel.
- Do not remove any labels. Replace any damaged label.

#### USING THE TOOL

- Always wear eye protection when operating or performing maintenance on this tool.
- Always wear hearing protection when operating this tool.

- Keep hands, loose clothing and long hair away from rotating end of tool.
- Note the position of the reversing lever before operating the tool so as to be aware of the direction of rotation when operating the throttle.
- Anticipate and be alert for sudden changes in motion during start up and operation of any power tool.
- Keep body stance balanced and firm. Do not overreach when operating this tool. High reaction torques can occur at or below the recommended air pressure.
- Tool shaft may continue to rotate briefly after throttle is released.
- Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.
- Use accessories recommended by Ingersoll-Rand.
- Use only impact sockets and accessories. Do not use hand (chrome) sockets or accessories.
- Impact wrenches are not torque wrenches. Connections requiring specific torque must be checked with a torque meter after fitting with an impact wrench.
- This tool is not designed for working in explosive atmospheres.
- This tool is not insulated against electric shock.

### NOTICE

The use of other than genuine Ingersoll-Rand replacement parts may result in safety hazards, decreased tool performance, and increased maintenance, and may invalidate all warranties.

Repairs should be made only by authorized trained personnel. Consult your nearest Ingersoll-Rand Authorized Servicenter.

Refer All Communications to the Nearest  
Ingersoll-Rand Office or Distributor.

© Ingersoll-Rand Company 2000

Printed in U.S.A.





# WARNING LABEL IDENTIFICATION

## ⚠ WARNING


FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.


	<p><b>⚠ WARNING</b></p> <p>Always wear eye protection when operating or performing maintenance on this tool.</p>
---	--


	<p><b>⚠ WARNING</b></p> <p>Always wear hearing protection when operating this tool.</p>
---	---


	<p><b>⚠ WARNING</b></p> <p>Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.</p>
---	--

	<p><b>⚠ WARNING</b></p> <p>Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.</p>
---	---

	<p><b>⚠ WARNING</b></p> <p>Do not carry the tool by the hose.</p>
---	---

	<p><b>⚠ WARNING</b></p> <p>Do not use damaged, frayed or deteriorated air hoses and fittings.</p>
---	---

	<p><b>⚠ WARNING</b></p> <p>Keep body stance balanced and firm. Do not overreach when operating this tool.</p>
---	---

	<p><b>⚠ WARNING</b></p> <p>Operate at 90 psig (6.2 bar/ 620 kPa) Maximum air pressure.</p>
---	--

## PLACING TOOL IN SERVICE

### LUBRICATION



Ingersoll-Rand No. 50




Ingersoll-Rand No. 100

Always use an air line lubricator with these tools.  
We recommend the following Filter-Lubricator-Regulator Unit:

For USA – No. C28-04-FKG0-28  
For International – No. C28-C4-FKG0

After each forty-eight hours of operation, or as experience indicates, inject about 4 cc of Ingersoll-Rand No. 100 Grease into the Grease Fitting.



(Dwg. TPD905-1)

**SPECIFICATIONS**

Model	Type of Handle	Drive	Impacts per min.	Recommended Torque Range	■ Sound Level dB (A)		◆ Vibrations Level
					Pressure	● Power	
		in.		ft-lbs (Nm)			m/s <sup>2</sup>
2934B2	inside trigger	1" sq. dr.	750	500–1,100 (678–1,490)	114.5	127.5	16.7
2940B2	inside trigger	1" sq. dr.	850	1,000–1,600 (1,360–2,170)	115.5	128.5	15.7
2934B9	inside trigger	1" sq. dr. at 90°	780	500–660 (678–890)	96.2	109.2	13.6
2934A2	outside trigger	1" sq. dr.	750	500–1,100 (678–1,490)	114.5	127.5	16.7
2940A2	outside trigger	1" sq. dr.	850	1,000–1,600 (1,360–2,170)	115.5	128.5	15.7

- Tested in accordance with ANSI S5.1–1971 at free speed
- ◆ Tested to ISO8662–1 loaded with frictionbrake to 9 RPM
- ISO3744

**DECLARATION OF CONFORMITY**

We Ingersoll-Rand, Co.  
(supplier's name)

78192 Trappes Cedex France  
(address)

declare under our sole responsibility that the product,


Series 2934B and 2940B Super Duty Impacttools

to which this declaration relates, is in compliance with the provisions of  
98/37/EC Directives.

By using the following Principle Standards: ISO8662

Serial No. Range: (1994 → ) XUA XXXXX →

  
\_\_\_\_\_  
D. Vose  
Name and signature of authorised persons

  
\_\_\_\_\_  
Kevin R. Morey  
Name and signature of authorised persons


June, 2000  
\_\_\_\_\_  
Date

June, 2000  
\_\_\_\_\_  
Date

**NOTICE**

**SAVE THESE INSTRUCTIONS. DO NOT DESTROY.**

**When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.**



**MAINTENANCE SECTION**

**(Dwg. TPA1333-3)**



PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING


1	Inside Trigger Handle Assembly . . . . .	2934-A92A	25	Motor Housing Assembly	
2	Grease Fitting . . . . .	130SR-188		for 2934B . . . . .	2934-A40A
5	Trigger . . . . .	834-93A		for 2940B . . . . .	2940-A40
6	Trigger Pin . . . . .	534-265	26	Reverse Valve Bushing . . . . .	2934-330S
7	Throttle Valve Plunger . . . . .	2934-302	◆•	26A Air Port Gasket (2) . . . . .	R44H-210A
8	Throttle Valve Assembly . . . . .	2934-A50	◆	27 Air Port Gasket Retainer (2) . . . . .	2940-200
◆•	9 Throttle Valve Face . . . . .	2934-159		27A Exhaust Deflector . . . . .	2934-23A
◆	10 Throttle Valve Spring . . . . .	834-51	◆	27B Exhaust Silencer . . . . .	2940P-311
11	Straight Inlet . . . . .	845-565		27C Exhaust Baffle . . . . .	2934-124
◆•	12 Air Strainer Screen . . . . .	434-61		27D Exhaust Gasket . . . . .	2934-223
◆•	13 Reverse Valve Seal . . . . .	R00BR-210		27E Deflector Screw (2) . . . . .	R43F-104
◆•	15 Handle Gasket . . . . .	2934-283		27F Nameplate	
16	Motor Clamp Washer . . . . .	2934-207		for 2934B . . . . .	2934-301
17	Rear End Plate . . . . .	2934-12		for 2940B . . . . .	2940-301
◆	18 Rear Rotor Bearing . . . . .	508-97		27G Nameplate Screw (4) . . . . .	C32-302
19	Rotor			28 Reverse Lever . . . . .	2934-658A
	for 2934B . . . . .	2934-53	◆	29 Reverse Lock Plunger . . . . .	4U-663B
	for 2940B . . . . .	2940-53	◆	30 Reverse Lock Plunger Spring . . . . .	4U-664
◆•	20 Vane Packet (set of 6 Vanes)		◆•	31 Reverse Valve Assembly . . . . .	2934-A329
	for 2934 B . . . . .	2934-42-6		32 Reverse Valve Bushing Seal . . . . .	85H-167
	for 2940 B . . . . .	2940-42-6			
21	Cylinder				
	for 2934B . . . . .	2934-3			
	for 2940B . . . . .	2940-3			
22	Front End Plate . . . . .	2934-11			
◆	23 Front Rotor Bearing . . . . .	810-97			
24	Cylinder Dowel				
	for 2934B . . . . .	2934-98			
	for 2940B . . . . .	2940-98			

MAINTENANCE SECTION

\* Not illustrated.

◆ Indicates Tune-up Kit part.

• To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (•) for every four tools in service.

**PART NUMBER FOR ORDERING** 

**PART NUMBER FOR ORDERING** 


33	Hammer Case Assembly for 2934B . . . . .	2934-A727	48	1" Square Drive Anvil Standard Length for 2934B . . . . .	2934-726
	for 2940B . . . . .	2940-A727		for 2940B . . . . .	2940-726
34	Hammer Case Bushing . . . . .	2934-641		6" Extended Length for 2934B . . . . .	2934-314-6
34A	Hammer Case Label for 2934B and 2940B . . . . .	WARNING-2-99		for 2940B . . . . .	2940-314-6
*	Oversize Hammer Case Bushing .005" oversize . . . . .	293-641-5	49	Socket Retainer . . . . .	RR10015S
	.010" oversize . . . . .	2934-641-10	50	Outside Trigger Handle Assembly . . . . .	2934-A1
	.015" oversize . . . . .	2934-641-15	51	Trigger . . . . .	844-78
◆ 35	Hammer Case Gasket . . . . .	2934-36	52	Trigger Pin . . . . .	F02-15
36	Hammer Case Cap Screw (4) . . . . .	834-638		Also includes illustrated parts 2, 7, 8, 9, 10, 11, 12, and 13 . . . . .	---
37	Hammer Case Cap Screw Lock Washer (4) . . . . .	34U-58	53	Dead Handle . . . . .	834-48
38	Handle Cap Screw (4) . . . . .	510-638	54	Dead Handle Bracket . . . . .	2934-364
39	Handle Cap Screw Lock Washer (4) . . . . .	8U-58	55	Dead Handle Bracket Spacer (2) . . . . .	2934-140
40	Hammer Frame Assembly for 2934B . . . . .	2934-A703	*	Horizontal Hanger . . . . .	2934-366
	for 2940B . . . . .	2940-A703	*	Horizontal Hanger Spacer (2) . . . . .	2934-140
41	Hammer Pin (2) for 2934B . . . . .	2934-704	*	Side Spade Handle . . . . .	T15-41
	for 2940B . . . . .	2940-704	*	Side Spade Handle Stud . . . . .	534-448
42	Hammer (2) for 2934B . . . . .	2934-724	*	Side Spade Handle Stud Nut . . . . .	107-73A
	for 2940B . . . . .	2940-724	*	Grease Gun . . . . .	R000A2-228
43	Spline Drive Anvil Assembly for 2934B . . . . .	2934-A526	*	Tune-up Kit (includes illustrated parts 3, 9, 10, 12, 13, 15, 18, 20, 23, 26A [2], 27 [2], 27B, 29, 30, 32 and 35) for 2934B . . . . .	2934-TK3
	for 2940B . . . . .	2940-A526		for 2940B . . . . .	2940-TK3
44	Socket Retaining Ball . . . . .	D04-280	*	Exhaust Deflector Kit (includes illustrated parts 27A thru 27E) . . . . .	2934-K23
45	Retaining Ball Plunger . . . . .	845-230			
46	Retaining Plunger Spring . . . . .	2940-231			
47	Plunger Retaining Pin . . . . .	845-128			

\* Not illustrated.  
◆ Indicates Tune-up Kit part.

**MAINTENANCE SECTION**

# MAINTENANCE SECTION

## MODEL 2934B9 IMPACTOOL WITH NO. 2934A90 ANGLE ATTACHMENT



The 2934B Impactool can be furnished with a 1" square drive 2934A90 Angle Attachment and when so furnished is designated as 2934B9. Following are the parts used only in the 2934B9. All parts not listed are the same as for a 2934B Impactool with Inside Trigger Handle, Side Spade Handle and a 1" square drive standard length Anvil.

**PART NUMBER FOR ORDERING**

**PART NUMBER FOR ORDERING**


100	Hammer Case Assembly . . . . .	2934-A827	110	Bevel Pinion Clamp	
101	Hammer Case Bushing . . . . .	2934-641		Washer (4) . . . . .	808-207
*	Hammer Case Label . . . . .	WARNING-2-99	111	Bevel Gear . . . . .	436A90-601
	Angle Attachment Assembly . . .	2934A90	112	Bevel Gear Spindle . . . . .	436A90-607
102	Angle Housing Assembly . . .	436A90-A600	113	Bevel Gear Bearing Retainer . .	436A90-632
103	Grease Fitting . . . . .	130SR-188	114	Angle Housing Connector . . . .	436A90-680
104	Bevel Pinion Assembly . . . . .	436A90-A602	115	Connector Lock Pin (2) . . . . .	436A90-609
105	Retainer Plunger . . . . .	8U-715	116	Connector Retaining Sleeve . . .	436A90-681
106	Retainer Plunger Spring . . .	5UHD-718	117	Retaining Sleeve Spring . . . . .	436A90-682
107	Bevel Pinion Bearing or Bevel Gear Bearing (2) . . . . .	436A90-593	118	Connector Retaining Sleeve Stop . . . . .	3BM-303
108	Bevel Pinion Spacer . . . . .	436A90-608	119	Connector Retaining Ball (3) . .	8U-722
109	Bevel Pinion Driver . . . . .	2934A90-563	*	Socket Retainer . . . . .	RR10015S

\* Not illustrated.



# MAINTENANCE SECTION

## PIPED AWAY EXHAUST KIT WITH MUFFLER



(Dwg. TPA559)

**PART NUMBER FOR ORDERING**

**PART NUMBER FOR ORDERING**

	Piped-Away Exhaust Kit with Muffler .....	2940-KM184	163	Exhaust Hose .....	R21-230
	without Muffler .....	2940-K184	164	Hose Clamp (2) .....	R21-31
160	Exhaust Adapter .....	2940-167	165	Hose Connector (for 2940-KM184) .....	R21-185
161	Exhaust Adapter Gasket .....	2940-30	166	Muffler (for 2940-KM184) ...	R21-674
162	Adapter Cap Screw (2) .....	AL-638			

## MAINTENANCE SECTION

### WARNING

**Always wear eye protection when operating or performing maintenance on this tool.**

**Always turn off air supply and disconnect air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.**

### LUBRICATION

Each time a Series 2934B or 2940B Impactool is disassembled for maintenance and repair or replacement of parts, lubricate the tool as follows:

1. Work approximately 12 to 15 cc of Ingersoll–Rand No. 100 Grease into the impact mechanism. Coat the Anvil (48) lightly with grease. Also, coat the inside of the Hammer Case Bushing (34) with grease. Inject approximately 2 to 4 cc of grease into the Grease Fitting (2).
2. Use Ingersoll–Rand No. 50 Oil for lubricating the motor. Inject approximately 1 to 2 cc of oil into the Straight Inlet (11) before attaching the air hose.

### DISASSEMBLY

#### General Instructions

1. Do not disassemble the tool any further than necessary to replace or repair damaged parts.
2. Whenever grasping a tool or part in a vise, always use leather covered or copper–covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members and housings.
3. Do not remove any part which is a press fit in or on a subassembly unless the removal of that part is necessary for repairs or replacement.
4. Do not disassemble the tool unless you have a complete set of new gaskets and O–rings for replacement.

#### Disassembly of the Impactool

1. Grasp tool in copper–covered or leather–covered vise jaws with square drive upward.

2. Using a hex wrench, unscrew and remove the two Deflector Screws (27E). Remove Exhaust Deflector (27A) and Exhaust Gasket (27D) and, if necessary, pull Exhaust Baffle (27C) and Exhaust Silencer (27B) from Deflector.
3. Using a hex wrench, unscrew and remove the four Hammer Case Cap Screws (36) and Lock Washers (37). Remove Dead Handle Bracket (54) and two Bracket Spacers (55).
4. While lightly tapping on the end of Anvil (48) with a plastic hammer, lift off Hammer Case (33).
5. Remove the Hammer Case Gasket (35).
6. Remove Anvil by rotating it as it is lifted out of the assembly.
7. Lift remaining hammer assembly off rotor shaft.
8. Push two Hammer Pins (41) out of the Hammer Frame Assembly (40) and slide two Hammers (42) out of the Frame.

#### Disassembly of the Impact Mechanism

1. Set mechanism, driver end up, on a workbench.

### NOTICE

**Note the twin hammers within the Hammer Frame. These are identical, but must be placed in the Hammer Frame in a certain relationship. Using a felt–tipped pen, mark the top hammer “T↑” and the bottom hammer “B↑” with the arrows pointing upward. Mark both Hammers on the same end.**

2. With mechanism sitting upright on a workbench, slowly rotate Anvil in a clockwise direction until it comes up solid.

### NOTICE

**If you continue to rotate the Anvil, it will cam the Hammers out of engagement. Do not allow this to happen; merely rotate the Anvil until it comes up solid.**

## MAINTENANCE SECTION

3. Hold Hammer Frame firmly and, without disturbing hammers, gently lift Anvil, simultaneously rotating it clockwise about 1/8 of a turn, from the Hammer Frame.

### NOTICE

**The twin hammers will be free to slide from the Hammer Frame when the Hammer Pins are removed. Do not drop the Hammers.**

4. With Anvil removed, lift out the two Hammer Pins,
5. Remove the Hammers.

### Disassembly of the Reverse Valve

1. Lightly clamp Motor Housing Assembly (25) in leather-covered or copper-covered vise jaws with Trigger Handle Assembly (1) upward.

### NOTICE

**Excessive clamping pressure will distort the Motor Housing and make motor removal extremely difficult. Do not insert the hammer case end of the Motor Housing more than 1" (25 mm) into the vise jaws.**

2. Using a hex wrench, unscrew and remove the four Handle Cap Screws (38) and Lock Washers (39). Lift assembled handle and Handle Gasket (15) off Motor Housing and set them aside.
3. Lift Motor Clamp Washer (16) off Housing.
4. Move Reverse Lever (28) to center position and using a drift pin to push from below, grasp Lever and lift Reverse Valve Assembly (31) out of Housing.

### NOTICE

**Make certain the Lever is in the center position to avoid jamming the Reverse Lock Plunger (29) when the Reverse Valve Assembly is removed.**

5. Pull Lever off Reverse Valve and remove Reverse Valve Bushing Seal (32) from groove on Valve.
6. Using needle nose pliers, remove Reverse Lock Plunger and Reverse Lock Plunger Spring (30) from Motor Housing.

### Disassembly of the Motor

1. Remove assembled motor and Motor Housing from vise jaws and using a plastic hammer, tap splined shaft of Rotor (19) to dislodge Rotor from Front Rotor Bearing (23).
2. Lift Motor Housing (25) off Rotor, Rear End Plate (17) and Rear Rotor Bearing (18) which will remain together as a unit.
3. Remove six Vanes (20) from Rotor.
4. Pull Rear End Plate off Rotor.

5. Open a set of vise jaws wide enough to clear hub of Rear End Plate and sharply rap hub end of end plate on top of jaws to dislodge Rear Rotor Bearing.
6. Remove Cylinder Dowel (24) and lay Motor Housing on top of vise jaws with Front Rotor Bearing (23) downward between jaws. Using a soft drift pin, tap Bearing out of the Housing.
7. To remove Cylinder (21) and Front End Plate (22), thread four 1/4"-20 thread socket head cap screws that are at least 3" (75 mm) long into handle end of Housing. Grasping Housing with installed screws downward, sharply strike heads of screws on a sturdy table to dislodge Cylinder. Cylinder should drop out of Housing after a few impacts. If it does not, proceed as follows:

### ⚠ WARNING

**The following procedure requires the use of heat. Take all necessary precautions to prevent burns. Carefully heat alternate sides of Housing until it is very warm. Using thick, heavy gloves to avoid being burned, grasp Housing and repeat attempt to dislodge Cylinder.**

8. Remove two Air Port Gaskets (26A) and Air Port Gasket Retainers (27) from Housing.

### Disassembly of the Handle

1. Clamp Trigger Handle Assembly in leather-covered or copper-covered vise jaws with the Straight Inlet (11) upward.
2. Using a wrench, unscrew and remove Inlet as well as Air Strainer Screen (12) and valve Spring (10).
3. Remove Throttle Valve Assembly (8) and Valve Plunger (7) from Handle.
4. If Trigger (5) must be removed, use an arbor press to push Trigger Pin (6) from the Handle and slide Trigger out of slot in Handle.

## ASSEMBLY

### General Instructions

1. Always press on the **inner** ring of a ball-type bearing when installing the bearing on a shaft.
2. Always press on the **outer** ring of a ball-type bearing when installing the bearing in a bearing recess.
3. Whenever grasping a tool or part in a vise, always use copper-covered or leather-covered vise jaws. Take extra care with threaded members and housings.
4. Always clean every part and wipe every part with a thin film of oil before installation.
5. Apply a film of O-ring lubricant to all O-rings before final assembly.

## MAINTENANCE SECTION

### Assembly of the Handle

1. Position Trigger (5) in Handle (1) and using an arbor press, push Trigger Pin (6) full length into Handle so that it captures Trigger.
2. Clamp Handle in leather-covered or copper-covered vise jaws with air inlet opening upward.
3. Coat Throttle Valve Plunger (7) with oil and insert it, rounded end leading, into the inlet hole in Handle.
4. Install a new Throttle Valve Face (9) on Throttle Valve (8) and insert assembly, Valve Face leading, into inlet hole in Handle.
5. Encircle cone end of Air Strainer Screen (12) with large end of Throttle Valve Spring (10) and insert both parts, Spring leading, into the inlet hole in Handle.
6. Install Straight Inlet (11) over Strainer Screen in Handle and tighten Inlet between 20 and 25 ft-lb (27 and 34 Nm) torque.
7. Remove Handle from vise and test Trigger. If Trigger functions properly, place assembled Handle aside. If it does not function properly, disassemble Handle to determine cause of problem.

### Assembly of the Motor

1. Lightly clamp Motor Housing (25) in leather-covered or copper-covered vise jaws with handle end upward.

#### NOTICE

**Excessive clamping pressure will distort the Motor Housing and make motor installation extremely difficult. Do not insert the hammer case end of the Motor Housing more than 1" (25 mm) into the vise jaws.**

2. Coat inside surface of Housing and outer edge of Front End Plate (22) with a light film of oil.
3. Using a long tee hex wrench as an alignment pin, insert Front End Plate, copper face trailing, into Motor Housing. Align dowel hole in End Plate with dowel hole at the bottom of motor bore.
4. Lubricate and insert a new fiber Air Port Gasket Retainer (27) in one of the air ports inside Motor Housing.
5. Install an Air Port Gasket (26A) in the air port against Gasket Retainer with flat end of Gasket away from Retainer.
6. Repeat Steps 4 and 5 to install remaining Gasket and Retainer in the other air port.
7. Coat outside of Cylinder (21) with a light film of oil and using long tee hex wrench as an alignment pin to align the holes in Cylinder with holes in Front End Plate and Housing, insert Cylinder into Housing.

8. Coat inside of Cylinder and Rotor (19) with a light film of oil and insert the splined hub of Rotor through Cylinder into Front End Plate.
9. Coat each Vane (20) with a light film of oil and insert a Vane into each slot in the Rotor. Vanes must be installed with curved edge toward center of Rotor. Spin the Rotor to settle Vanes in position.
10. Using long tee hex wrench to align hole in Rear End Plate (17) with hole in Cylinder, insert the Rear End Plate, bronze face leading, into Motor Housing against the Cylinder. End Plate is properly seated when large trailing face of End Plate is slightly below face of Motor Housing.
11. Grease Rear Rotor Bearing (18) and install it in recess of Rear End Plate.
12. Remove alignment pin from assembled motor and install Cylinder Dowel (24). The Dowel is properly seated when end of Dowel does not protrude above End Plate.
13. Install Motor Clamp Washer (16) against Rear End Plate so that large outer edge of Washer contacts End Plate.


### Assembly of the Reverse Valve

1. Inject a small amount of grease into hole in Motor Housing (25) where Reverse Lock Plunger (29) will be installed. With grease to hold them in position, install Reverse Lock Plunger Spring (30) and Lock Plunger.
2. Install a new Reverse Valve Bushing Seal (32) in annular groove on Reverse Valve (31).
3. Coat Reverse Valve with a light film of oil and install it in Motor Housing with the side hole nearest to Seal pointed toward Rotor (19).
4. Position Reverse Lever (28) on Reverse Valve and while using a thin blade screwdriver to depress Reverse Lock Plunger, push Lever onto Reverse Valve.
5. Place a new Handle Gasket (15) on the Motor Housing.
6. Examine Reverse Valve Seal (13) located inside Handle and if it is nicked, deformed or worn, remove it and install a new Seal.
7. Fill rotor cavity in Handle with recommended grease and position Handle on the Motor Housing.
8. Install four Handle Cap Screws (38) and Lock Washers (39) and using an alternate tightening pattern, tighten Screws to between 10 and 12 ft-lb (13.5 and 16.3 Nm) torque.
9. Move Reverse Lever through the forward and reverse positions to make certain the Lever locks in position.
10. Turn assembly in vise jaws and clamp on Handle with rotor shaft upward.
11. Grease Front Rotor Bearing (23) and place it over rotor shaft.

## MAINTENANCE SECTION

12. Select a socket or piece of tubing that will fit over the outside race of the Bearing and tap it with a hammer to seat Bearing into Housing.
13. Pack Bearing with additional grease and rotate rotor shaft. If shaft does not rotate smoothly, rap end of rotor shaft with a soft hammer to set motor and try to rotate shaft again.

### Assembly of the Impact Mechanism



1. Coat Hammers (42) with a light film of Ingersoll-Rand Impactool Grease No. 100.
2. Replace Hammers in Hammer Frame (40) exactly as they were when you marked them prior to disassembly.

### NOTICE

**If you are installing new Hammers, or want to change the location of the existing Hammers to utilize both impacting surfaces, slide the Hammers in the Hammer Frame so that the half-round notch on one Hammer is located on one side of the Frame and the half-round notch on the other Hammer is located on the other side of the Frame.**

3. Replace Hammer Pins (41).
4. Examine base of Anvil (48) and note its contour. While looking down through Hammer Frame, swing the top Hammer to its full extreme one way or another until you can match the contour of the Anvil. Enter the Anvil into the Hammer Frame and through the first Hammer. Swing the bottom Hammer in opposite direction from the top Hammer and maneuver Anvil slightly until it drops into bottom Hammer.

### Assembly of the Impactool

1. Set assembled hammer mechanism onto rotor shaft spline.
2. Place Hammer Case Gasket (35) over mechanism and against face of Motor Housing.
3. Grease Anvil and top of Hammer Frame.
4. Place Hammer Case (33) over mechanism assembly against Gasket.
5. Assemble Dead Handle (53) to Dead Handle Bracket (54). Insert two Hammer Case Cap Screws (37) with Lock Washers (38) through Bracket and install two Dead Handle Bracket Spacers (55) on Screws. Position assembly against Hammer Case and thread the Screws into Housing.
6. Thread remaining two Cap Screws and Lock Washers into Housing and using an alternating pattern for all four fasteners, tighten Screws between 20 and 25 ft-lb (27 and 34 Nm) torque.
7. Install a new Exhaust Silencer (27B) in Exhaust Deflector (27A) and install the Exhaust Baffle (27C) in Deflector.
8. Position a new Exhaust Gasket (27D) against face of the Motor Housing. Position the assembled Deflector against the Gasket and secure it by tightening the two Deflector Screws (27E).

## MAINTENANCE SECTION

### TROUBLESHOOTING GUIDE

Trouble	Probable Cause	Solution
Low power	Dirty Inlet Bushing or Air Strainer Screen and/or Exhaust Silencer	Using a clean, suitable, cleaning solution, in a well ventilated area, clean Air Strainer Screen, Inlet Bushing and Exhaust Silencer.
	Worn or broken Vanes	Replace <b>complete</b> set of Vanes.
	Worn or broken Cylinder and/or scored End Plates	Examine Cylinder and replace it if it is worn or broken or if bore is scored or wavy. Replace End Plates if they are scored.
	Dirty motor parts	Disassemble tool and clean all parts with a suitable cleaning solution, in a well-ventilated area. Reassemble tool as instructed in this manual.
	Improper positioning of Reverse Valve	Make certain that Reverse Valve is <b>fully</b> engaged to the left or right.
Motor will not run	Incorrect assembly of motor	Disassemble motor and replace worn or broken parts and reassemble as instructed.
	Insufficient lubricant in the impact mechanism	Remove Hammer Case Assembly and lubricate impact mechanism.
Tool will not impact	Broken or worn impact mechanism parts	Remove Hammer Case and examine impact mechanism parts. Replace any worn or broken parts.
	Impact mechanism not assembled correctly	Refer to <b>Assembly of the Impact Mechanism</b> .

### NOTICE

**SAVE THESE INSTRUCTIONS. DO NOT DESTROY.**

## Service Centers

Ingersoll-Rand Company  
510 Hester Drive  
White House, TN 37188  
USA  
Tel: (615) 672 0321  
Fax: (615) 672 0801

Ingersoll-Rand Sales Company Limited  
Chorley New Road  
Horwich, Bolton  
Lancashire BL6 6JN  
England – UK  
Tel: (44) 204 880890  
Fax: (44) 204 880388

Ingersoll-Rand Equipements de Production  
111 Avenue Roger Salongro  
BP 59  
F-59450 Sin Le Noble  
France  
Tel: (33) 27 93 0808  
Fax: (33) 27 93 0800

Ingersoll-Rand GmbH  
Gewerbealle 17  
45478 Mülheim/Ruhr  
Germany  
Tel: (49) 208 9940  
Fax: (49) 208 9994445

Ingersoll-Rand Italiana SpA  
Casella Postale 1232  
20100 Milano  
Italy  
Tel: (39) 2 950561  
Fax: (39) 2 95380169

Ingersoll-Rand  
Camino de Rejas 1, 2-18 B1S  
28820 Cosiada  
Spain  
Tel: (34) 1 669 5850  
Fax: (34) 1 669 6054

Ingersoll-Rand Nederfand  
Produktieweg 10  
2382 PB Zoeterwoude  
Netherlands  
Tel: (31) 71 45220  
Fax: (31) 71 218671

Ingersoll-Rand Company SA  
PO Box 3720  
Airode 1451  
South Africa  
Tel: (27) 11 864 3930  
Fax: (27) 11 864 3954

Ingersoll-Rand  
Scandinavian Operations  
Kastruplundgade 221  
DK-2770 Kastrup  
Denmark  
Tel: (45) 32 526092  
Fax: (45) 32 529092

Ingersoll-Rand SA  
The Alpha Building  
Route des Arsenaux 9  
CH-1700 Fribourg  
Switzerland  
Tel: (41) 37 205111  
Fax: (41) 37 222932

Ingersoll-Rand Company  
Kuznetsky Most 21/5  
Entrance 3  
103698 Moscow  
Russia  
CIS  
Tel: (7) 501 882 0440  
Fax: (7) 501 882 0441

Ingersoll-Rand Company  
16 Pietro  
Ul Stawki 2  
PL-00193 Warsaw  
Poland  
Tel: (48) 2 635 7245  
Fax: (48) 2 635 7332