


OPERATION AND MAINTENANCE MANUAL FOR SERIES 8RS, 8S AND 8T ANGLE WRENCHES

NOTICE

Series 8RS, 8S and 8T Angle Wrenches are designed for heavy-duty close-quarter threaded fastener applications which require precise torque repeatability.

Ingersoll-Rand is not responsible for customer modification of tools for applications on which Ingersoll-Rand was not consulted.



! WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.
READ THIS MANUAL BEFORE OPERATING TOOL.**

**IT IS THE RESPONSIBILITY OF THE EMPLOYER TO PLACE THE INFORMATION
IN THIS MANUAL INTO THE HANDS OF THE OPERATOR.**

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

PLACING TOOL IN SERVICE

- Always operate, inspect and maintain this tool in accordance with American National Standards Institute Safety Code for Portable Air Tools (ANSI B186.1).
- For safety, top performance, and maximum durability of parts, operate this tool at 90 psig (6.2 bar/620 kPa) maximum air pressure at the inlet with 1/2" (13 mm) inside diameter air supply hose.
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.
- Do not use damaged, frayed or deteriorated air hoses and fittings.
- Be sure all hoses and fittings are the correct size and are tightly secured. See Dwg. TPD905-1 for a typical piping arrangement.
- Always use clean, dry air at 90 psig maximum air pressure. Dust, corrosive fumes and/or excessive moisture can ruin the motor of an air tool.
- Do not lubricate tools with flammable or volatile liquids such as kerosene, diesel or jet fuel.
- Do not remove any labels. Replace any damaged label.

USING THE TOOL

- Always wear eye protection when operating or performing maintenance on this tool.
- Always wear hearing protection when operating this tool.

- Keep hands, loose clothing and long hair away from rotating end of tool.
- Note the position of the reversing lever before operating the tool so as to be aware of the direction of rotation when operating the throttle.
- Anticipate and be alert for sudden changes in motion during start up and operation of any power tool.
- Keep body stance balanced and firm. Do not overreach when operating this tool. High reaction torques can occur at or below the recommended air pressure.
- Tool accessories may continue to rotate briefly after throttle is released.
- Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.
- Use accessories recommended by Ingersoll-Rand.
- Use only impact sockets and accessories. Do not use hand (chrome) sockets or accessories.
- The Throttle Valve Cap is under pressure from the Throttle Valve Spring. Use care when removing the Throttle Valve Cap. (On tools where applicable.)
- Whenever the Angle Head is installed or repositioned, the Throttle Lever must be positioned so that reaction torque will not tend to retain the throttle in the "ON" position.
- This tool is not designed for working in explosive atmospheres.
- This tool is not insulated against electric shock.

NOTICE

The use of other than genuine Ingersoll-Rand replacement parts may result in safety hazards, decreased tool performance, and increased maintenance, and may invalidate all warranties.

Repairs should be made only by authorized trained personnel. Consult your nearest Ingersoll-Rand Authorized Servicenter.

Refer All Communications to the Nearest
Ingersoll-Rand Office or Distributor.

© Ingersoll-Rand Company 1999


Printed in U.S.A.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

WARNING LABEL IDENTIFICATION

⚠ WARNING

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

	⚠ WARNING		⚠ WARNING		⚠ WARNING
Always wear eye protection when operating or performing maintenance on this tool.		Always wear hearing protection when operating this tool.		Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.	
	⚠ WARNING		⚠ WARNING		⚠ WARNING
Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.		Do not carry the tool by the hose.		Do not use damaged, frayed or deteriorated air hoses and fittings.	
	⚠ WARNING		⚠ WARNING	Operate at 90 psig (6.2 bar/ 620 kPa) Maximum air pressure.	
Keep body stance balanced and firm. Do not overreach when operating this tool.		90 psig (6.2bar/620kPa)			

PLACING TOOL IN SERVICE

LUBRICATION



Ingersoll-Rand No. 10

Ingersoll-Rand No. 28

Ingersoll-Rand No. 66


Always use an air line lubricator with these tools.
We recommend the following Filter-Lubricator-Regulator Unit:

For USA – No. C28-04-FKG0-28

Before starting the Tool and after each two or three hours of operation, unless the air line lubricator is used, detach the air hose and inject about 2.5 cc of Ingersoll-Rand No. 10 Oil into the air inlet.

After each forty-eight hours of operation, or as experience indicates, inject about 1 cc of Ingersoll-Rand No. 28 Grease into the gear case Grease Fitting.

After each forty-eight hours of operation, or as experience indicates, inject about 1 cc of Ingersoll-Rand No. 66 Grease into the angle head Grease Fitting.



(Dwg. TPD905-1)

HOW TO ORDER AN ANGLE WRENCH

INLINE HANDLE REVERSIBLE STALL

Model	Torque Range (Soft Draw)				Free Speed	Square Drive
	50 psi pressure		90 psi pressure			
ft-lb	Nm	ft-lb	Nm	rpm	in.	
8RSL32	12.0	16.3	18.0	24.4	1,200	3/8
8RSM32	15.0	20.3	23.0	31.2	930	3/8
8RSN32	19.0	25.8	30.0	40.7	700	3/8
8RSP53	26.0	35.3	40.0	54.2	510	1/2
8RSQ53	32.0	43.4	50.0	67.8	430	1/2

INLINE HANDLE NONREVERSIBLE STALL

8SM32	16.0	21.7	23.0	31.2	1,110	3/8
8SN32	21.0	28.5	30.0	40.7	840	3/8
8SP53	28.0	38.0	40.0	54.2	610	1/2

INLINE HANDLE NONREVERSIBLE SHUT-OFF


8TM32	16.0	21.7	23.0	31.2	1,110	3/8
8TN32	21.0	28.5	30.0	40.7	840	3/8
8TP53	28.0	38.0	40.0	54.2	610	1/2
8TQ53	35.0	47.5	50.0	67.8	520	1/2

MANUEL D'EXPLOITATION ET D'ENTRETIEN DES CLÉS D'ANGLE DES SÉRIES 8RS, 8S ET 8T

NOTE

Les clés d'angle des séries 8RS, 8S et 8T sont destinées au serrage dans des espaces restreints des grosses fixations filetées nécessitant une répétabilité précise du couple.

Ingersoll-Rand ne peut être tenu responsable de la modification des outils par le client pour les adapter à des applications qui n'ont pas été approuvées par Ingersoll-Rand.



ATTENTION

D'IMPORTANTES INFORMATIONS DE SECURITÉ SONT JOINTES.

LIRE CE MANUEL AVANT D'UTILISER L'OUTIL.

L'EMPLOYEUR EST TENU À COMMUNIQUER LES INFORMATIONS DE CE MANUEL AUX EMPLOYÉS UTILISANT CET OUTIL.

LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES

MISE EN SERVICE DE L'OUTIL

- Toujours exploiter, inspecter et entretenir cet outil conformément au Code de sécurité des outils pneumatiques portatifs de l'American National Standards Institute (ANSI B186.1).
- Pour la sécurité, les performances optimales et la durabilité maximale des pièces, cet outil doit être connecté à une alimentation d'air comprimé de 6,2 bar (620kPa) maximum à l'entrée, avec un flexible de 13 mm de diamètre intérieur.
- Couper toujours l'alimentation d'air comprimé et débrancher le flexible d'alimentation avant d'installer, déposer ou ajuster tout accessoire sur cet outil, ou d'entreprendre une opération d'entretien quelconque sur l'outil.
- Ne pas utiliser des flexibles ou des raccords endommagés, effilochés ou détériorés.
- S'assurer que tous les flexibles et les raccords sont correctement dimensionnés et bien serrés. Voir Plan TPD905-1 pour un exemple type d'agencement des tuyauteries.
- Utiliser toujours de l'air sec et propre à une pression maximum de 6,2 bar. La poussière, les fumées corrosives et/ou une humidité excessive peuvent endommager le moteur d'un outil pneumatique.
- Ne jamais lubrifier les outils avec des liquides inflammables ou volatiles tels que le kérósène, le gasoil ou le carburant d'aviation.
- Ne retirer aucune étiquette. Remplacer toute étiquette endommagée.

UTILISATION DE L'OUTIL

- Porter toujours des lunettes de protection pendant l'utilisation et l'entretien de cet outil.
- Porter toujours une protection acoustique pendant l'utilisation de cet outil.
- Tenir les mains, les vêtements flous et les cheveux longs, éloignés de l'extrémité rotative de l'outil.

- Noter la position du levier d'inversion avant de mettre l'outil en marche de manière à savoir dans quel sens il va tourner lorsque la commande est actionnée.
- Prévoir, et ne pas oublier, que tout outil motorisé est susceptible d'à-coups brusques lors de sa mise en marche et pendant son utilisation.
- Garder une position équilibrée et ferme. Ne pas se pencher trop en avant pendant l'utilisation de cet outil. Des couples de réaction élevés peuvent se produire à, ou en dessous, de la pression d'air recommandée.
- La rotation des accessoires de l'outil peut continuer pendant un certain temps après le relâchement de la gâchette.
- Les outils pneumatiques peuvent vibrer pendant l'exploitation. Les vibrations, les mouvements répétitifs et les positions inconfortables peuvent causer des douleurs dans les mains et les bras. N'utiliser plus d'outils en cas d'inconfort, de picotements ou de douleurs. Consulter un médecin avant de recommencer à utiliser l'outil.
- Utiliser les accessoires recommandés par Ingersoll-Rand.
- N'utiliser que les douilles et les accessoires pour clés à chocs. Ne pas utiliser les douilles et accessoires (chromés) de clés manuelles.
- Le chapeau de la soupape de commande est soumis à la pression du ressort de soupape. Prendre les soins nécessaires lors de la dépose du chapeau de soupape de commande. (Sur les outils concernés).
- A chaque fois que le renvoi d'angle est installé ou repositionné, le levier de commande doit être positionné de manière à ce que le couple de réaction n'ait pas tendance à maintenir le levier de commande en position "MARCHE".
- Cet outil n'est pas conçu pour fonctionner dans des atmosphères explosives.
- Cet outil n'est pas isolé contre les chocs électriques.

NOTE

L'utilisation de rechanges autres que les pièces d'origine Ingersoll-Rand peut causer des risques d'insécurité, réduire les performances de l'outil et augmenter l'entretien, et peut annuler toutes les garanties.

Les réparations ne doivent être effectuées que par des réparateurs qualifiés autorisés. Consultez votre Centre de Service Ingersoll-Rand le plus proche.

Adressez toutes vos communications au Bureau Ingersoll-Rand ou distributeur le plus proche.

© Ingersoll-Rand Company 1999


Imprimé aux É.U.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

SIGNIFICATION DES ETIQUETTES D'AVERTISSEMENT

ATTENTION

LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES



MISE EN SERVICE DE L'OUTIL

LUBRIFICATION



Ingersoll-Rand No. 10

Ingersoll-Rand No . 28

Ingersoll-Rand No . 66

Utiliser toujours un lubrificateur avec ces outils. Nous recommandons l'emploi du filtre-régulateur-lubrificateur suivant :

É.U. – No . C28–04–FKG0–28


Toutes les deux ou trois heures de fonctionnement, si un lubrificateur de ligne n'est pas utilisé, débrancher le flexible d'alimentation et verser environ 2,5 cm³ d'huile

Ingersoll-Rand No 10 dans le raccord d'admission de l'outil.

Toutes les quarante-huit heures de fonctionnement, ou en fonction de l'expérience, injecter environ 1 cm³ de graisse

Ingersoll-Rand No. 28 dans le raccord de graissage du boîtier d'engrenages.

Toutes les quarante-huit heures de fonctionnement, ou en fonction de l'expérience, injecter environ 1cm de graisse Ingersoll-Rand No. 66 dans le raccord de graissage du renvoi d'angle.



(Plan TPD905–1)

MISE EN SERVICE DE L'OUTIL

SPÉCIFICATIONS


Modèle	Dispositif de couple	Plage de couple (Serrage élastique)		Vitesse à vide	entr. carré
		50 psi ft-lbs (Nm)	90 psi ft-lbs (Nm)		
8RSL32	calage	12,0 (16,3)	18,0 (24,4)	1.200	3/8
8RSM32	calage	15,0 (20,3)	23,0 (31,2)	930	3/8
8RSN32	calage	19,0 (25,8)	30,0 (40,7)	700	3/8
8RSP53	calage	26,0 (35,3)	40,0 (54,2)	510	1/2
8RSQ53	calage	32,0 (43,3)	50,0 (67,8)	430	1/2
8SM32	calage	16,0 (21,7)	23,0 (31,2)	1.110	3/8
8SN32	calage	21,0 (28,5)	30,0 (40,7)	840	3/8
8SP53	calage	28,0 (38,0)	40,0 (54,2)	610	1/2
8TM32	arrêt	16,0 (21,7)	23,0 (31,2)	1.110	3/8
8TN32	arrêt	21,0 (28,5)	30,0 (40,7)	840	3/8
8TP53	arrêt	28,0 (38,0)	40,0 (54,2)	610	1/2
8TQ53	arrêt	35,0 (47,5)	50,0 (67,8)	520	1/2

MANUAL DE USO Y MANTENIMIENTO PARA LLAVES ANGULARES MODELO 8RS, 8S Y 8T

NOTA

Las Llaves Angulares Serie 8RS, 8S y 8T están diseñadas para fijaciones de roscas robustas en operaciones de mínima distancia que requieran repetibilidad de par con precisión.

Ingersoll-Rand no aceptará responsabilidad alguna por la modificación de las herramientas efectuada por el cliente para las aplicaciones que no hayan sido consultadas con Ingersoll-Rand.



! AVISO

SE ADJUNTA INFORMACION IMPORTANTE DE SEGURIDAD.

LEA ESTE MANUAL ANTES DE USAR LA HERRAMIENTA.

**ES RESPONSABILIDAD DE LA EMPRESA ASEGURARSE DE QUE EL OPERARIO
ESTE AL TANTO DE LA INFORMACION QUE CONTIENE ESTE MANUAL.**

EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRIA OCASIONAR LESIONES.

PARA PONER LA HERRAMIENTA EN SERVICIO

- Utilice, examine y mantenga siempre esta herramienta conforme al código de seguridad para herramientas neumáticas portátiles de la American National Standards Institute (ANSI B186.1).
- Para seguridad, máximo rendimiento y durabilidad de piezas, use esta herramienta a una máxima presión de aire de 90 psig (6,2 bar/620kPa) en la admisión de manguera de suministro de aire de diámetro interno de 13 mm.
- Corte siempre el suministro de aire y desconecte la manguera de suministro de aire antes de instalar, desmontar o ajustar cualquier accesorio de esta herramienta, o antes de realizar cualquier operación de mantenimiento de la misma.
- No utilice mangueras de aire y accesorios dañados, desgastados ni deteriorados.
- Asegúrese de que todas las mangueras y los accesorios sean del tamaño correcto y estén bien apretados. Vea Esq. TPD005-1 para un típico arreglo de tuberías.
- Use siempre aire limpio y seco a una máxima presión de 90 psig. El polvo, los gases corrosivos y/o el exceso de humedad podrían estropear el motor de una herramienta neumática.
- No lubrique las herramientas con líquidos inflamables o volátiles tales como queroseno, gasoil o combustible para motores a reacción.
- No saque ninguna etiqueta. Sustituya toda etiqueta dañada.

USO DE HERRAMIENTA

- Use siempre protección ocular cuando utilice esta herramienta o realice operaciones de mantenimiento en la misma.
- Use siempre protección para los oídos cuando utilice esta herramienta.

NOTA

El uso de piezas de recambio que no sean las auténticas piezas Ingersoll-Rand podría poner en peligro la seguridad, reducir el rendimiento de la herramienta y aumentar los cuidados de mantenimiento necesarios, así como invalidar toda garantía.

Las reparaciones sólo serán realizadas por personal cualificado y autorizado. Consulte con el centro de servicio Ingersoll-Rand autorizado más próximo.

Toda comunicación se deberá dirigir a la oficina o al distribuidor Ingersoll-Rand más próximo.

© Ingersoll-Rand Company 1999

Impreso en EE.UU.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

ETIQUETAS DE AVISO

AVISO

EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRIA OCASIONAR LESIONES.

	ADVERTENCIA	Use siempre protección ocular cuando utilice esta herramienta o realice operaciones de mantenimiento en la misma.
	ADVERTENCIA	Use siempre protección para los oídos cuando utilice esta herramienta.
	ADVERTENCIA	Cortar siempre el suministro de aire y desconectar la manguera de suministro de aire antes de instalar, retirar o ajustar cualquier accesorio de esta herramienta, o antes de realizar cualquier operación de mantenimiento de la misma.
	ADVERTENCIA	Las herramientas neumáticas pueden vibrar durante el uso. La vibración, los movimientos repetitivos o las posiciones incómodas podrían dañarle los brazos y las manos. En caso de incomodidad, sensación de hormigueo o dolor, dejar de usar la herramienta. Consultar al médico antes de volver a utilizarla.
	ADVERTENCIA	Mantener una postura del cuerpo equilibrada y firme. No estirar demasiado los brazos al manejar la herramienta.
	ADVERTENCIA	Manejar la herramienta a una presión de aire máxima de 90 psig (6,2 bar/620 kPa).

PARA PONER LA HERRAMIENTA EN SERVICIO

LUBRICACION



Ingersoll-Rand N° 10

Ingersoll-Rand N° 28

Ingersoll-Rand N° 66


Utilice siempre un lubricador de aire comprimido con estas llaves de impacto. Recomendamos la siguiente unidad de Filtro-Lubricador-Regulador:

EE.UU. – N°. C28-04-FKG0-28

Antes de poner la herramienta en marcha y después de cada dos o tres horas de uso, a menos que se haya puesto lubricante de línea de aire comprimido, desconecte la manguera de aire e inyecte unos 2,5 cc de Aceite Ingersoll-Rand N° 10 en la admisión de aire.

Después de cada cuarenta y ocho horas de uso, o como indique la experiencia, inyecte así como 1 cc de Grasa Ingersoll-Rand N° 28 en el engrasador de carcasa de engranajes.

Después de cada cuarenta y ocho horas de uso, o como indique la experiencia, inyecte así como 1 cc de Grasa Ingersoll-Rand N° 66 en el engrasador de la cabeza angular.



PARA PONER LA HERRAMIENTA EN SERVICIO

ESPECIFICACIONES

Modelo	Dispositivo de Par	Gama de Par (Junta blanda)		Velocidad Cons- tante	Cuadr adillo
		50 psi ft-lbs (Nm)	90 psi ft-lbs (Nm)	rpm	pulg.
8RSL32	cala	12,0 (16,3)	18,0 (24,4)	1.200	3/8
8RSM32	cala	15,0 (20,3)	23,0 (31,2)	930	3/8
8RSN32	cala	19,0 (25,8)	30,0 (40,7)	700	3/8
8RSP53	cala	26,0 (35,3)	40,0 (54,2)	510	1/2
8RSQ53	cala	32,0 (43,3)	50,0 (67,8)	430	1/2
8SM32	cala	16,0 (21,7)	23,0 (31,2)	1.110	3/8
8SN32	cala	21,0 (28,5)	30,0 (40,7)	840	3/8
8SP53	cala	28,0 (38,0)	40,0 (54,2)	610	1/2
8TM32	cierre	16,0 (21,7)	23,0 (31,2)	1.110	3/8
8TN32	cierre	21,0 (28,5)	30,0 (40,7)	840	3/8
8TP53	cierre	28,0 (38,0)	40,0 (54,2)	610	1/2
8TQ53	cierre	35,0 (47,5)	50,0 (67,8)	520	1/2


IMANUAL DE FUNCIONAMENTO E MANUTENÇÃO PARA FERRAMENTAS PNEUMÁTICAS ANGULARES SÉRIES 8RS, 8S E 8T

P

AVISO

As Ferramentas Pneumáticas Angulares Modelos 8RS, 8S e 8T são concebidas para aplicações de aperto com rosca regulável em trabalhos pesados onde é necessário repetitividade de torque.

A Ingersoll-Rand não é responsável por modificações feitas pelo cliente em ferramentas nas quais a Ingersoll-Rand não tenha sido consultada.



! ADVERTÊNCIA

INFORMAÇÃO DE SEGURANÇA IMPORTANTE EM ANEXO

LEIA ESTE MANUAL ANTES DE OPERAR A FERRAMENTA.

É DA RESPONSABILIDADE DO EMPREGADOR COLOCAR A INFORMAÇÃO
DESTE MANUAL NAS MÃOS DO OPERADOR.

O NÃO CUMPRIMENTO DAS SEGUINTEIS ADVERTÊNCIAS PODE RESULTAR EM FERIMENTOS.

COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

- Sempre opere, inspecione e mantenha esta ferramenta de acordo com o Código de Segurança do Instituto Americano de Padrões Nacionais para Ferramentas Pneumáticas Portáteis (ANSI B186.1).
- Para segurança, máximo desempenho e máxima durabilidade das peças, opere esta ferramenta com uma pressão de ar máxima de 6,2 bar/620 kPa (90 psig) na entrada da mangueira de alimentação de ar com diâmetro interno de 13 mm (1/2").
- Desligue sempre a alimentação de ar e desconecte a mangueira de alimentação de ar antes de instalar, remover ou ajustar qualquer acessório nesta ferramenta, ou antes de executar qualquer serviço de manutenção nesta ferramenta.
- Não use mangueiras de ar ou adaptadores danificados, gastos ou deteriorados.
- Certifique-se de que todas as mangueiras e adaptadores sejam do tamanho correcto e estejam apertados com firmeza. Veja o Desenho TPD905-1 para um arranjo típico de tubagem.
- Use sempre ar seco e limpo com pressão máxima de 90 psig. Pó, fumos corrosivos e/ou humidade excessiva podem arruinar o motor de uma ferramenta pneumática.
- Não lubrifique as ferramentas com líquidos inflamáveis ou voláteis tais como querosene, diesel ou combustível de jactos.
- Não remova nenhum rótulo. Reponha qualquer rótulo danificado.

USANDO A FERRAMENTA

- Use sempre óculos de protecção quando estiver operando ou executando serviço de manutenção nesta ferramenta.
- Use sempre protecção contra ruído ao operar esta ferramenta.

AVISO

O uso de peças de substituição que não sejam genuinamente da Ingersoll-Rand podem resultar em riscos de segurança, diminuição do desempenho da ferramenta, aumento da necessidade de manutenção e pode invalidar todas as garantias.

As reparações devem ser feitas somente por pessoal treinado autorizado. Consulte o Centro de Serviços da Ingersoll-Rand mais próximo.

Envie Todos os Comunicados Para o Distribuidor ou
Escritório da Ingersoll-Rand Mais Próximo.

© Ingersoll-Rand Company 1999






Impresso nos E.U.A.

INGERSOLL-RAND®
PROFESSIONAL TOOLS

IDENTIFICAÇÃO DO RÓTULO DE ADVERTÊNCIA

! ADVERTÊNCIA

O NÃO CUMPRIMENTO DAS SEGUINTE ADVERTÊNCIAS PODE RESULTAR EM FERIMENTO.



COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

LUBRIFICAÇÃO



Ingersoll-Rand No. 10

Ingersoll-Rand No. 28

Ingersoll-Rand No. 66


Use sempre um lubrificador de ar de linha com estas ferramentas. Nós recomendamos a seguinte Unidade Filtro-Lubrificador-Regulador:

Para E.U.A. – No. C28-04-FKG0-28

Antes de ligar a Ferramenta e depois de duas ou três horas de operação, ao menos que um lubrificador de ar de linha seja usado, desligue a mangueira de ar e injecte aproximadamente 2,5 de Óleo Ingersoll-Rand No. 10 na entrada de ar.

Depois de quarenta e oito horas de operação, ou conforme a experiência indicar injecte cerca de 1 cc de Massa Lubrificadora Ingersoll-Rand No. 28 na caixa de engrenagem do Adaptador.

Depois de quarenta e oito horas de operação, ou conforme a experiência indicar injecte cerca de 1 cc de Massa Lubrificadora Ingersoll-Rand No. 66 no ângulo da cabeça do Adaptador.




(Desenho TPD905-1)

COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

ESPECIFICAÇÕES

Modelo	Equipamento de Torque	Intervalo de Torque (Apertos Ligeiros)	Velocidade Livre	Encabadouro Quadrado	
		50 psi Nm (pés-lb)	90 psi Nm (pés-lb)	rpm	pol.
8RSL32	paragem	16,3 (12,0)	24,4 (18,0)	1.200	3/8
8RSM32	paragern	20,3 (15,0)	31,2 (23,0)	930	3/8
8RSN32	paragern	25,8 (19,0)	40,7 (30,0)	700	3/8
8RSP53	paragern	35,3 (26,0)	54,2 (40,0)	510	1/2
8RSQ53	paragern	43,3 (32,0)	67,8 (50,0)	430	1/2
8SM32	paragern	21,7 (16,0)	31,2 (23,0)	1.110	3/8
8SN32	paragern	28,5 (21,0)	40,7 (30,0)	840	3/8
8SP53	paragern	38,0 (28,0)	54,2 (40,0)	610	1/2
8TM32	corte automático	21,7 (16,0)	31,2 (23,0)	1.110	3/8
8TN32	corte automático	28,5 (21,0)	40,7 (30,0)	840	3/8
8TP53	corte automático	38,0 (28,0)	54,2 (40,0)	610	1/2
8TQ53	corte automático	47,5 (35,0)	67,8 (50,0)	520	1/2

MAINTENANCE SECTION
MOTOR HOUSING ASSEMBLY



(Dwg. TPC592)



MAINTENANCE SECTION

PART NUMBER FOR ORDERING

		8RS, 8S	8T
1	Motor Housing Assembly Nonreversible for 8S or 8T models ending in 32 or 53	8SL-A40	8TL-A40
*	for 8T models ending in -EU	—	8TL-EU-A40
	Reversible for 8R models ending in 32 or 53	8RSL-A40	—
*	for 8R models ending in -EU	8RSL-EU-A40	—
	Warning Label for models ending in -EU	EU-99	EU-99
	for all other models	WARNING-2-99	WARNING-2-99
2	Shutoff Valve	—	8TL-172
3	Shutoff Valve Body	—	8TL-170
4	Shutoff Valve Spring	—	8TL-171
4A	Shutoff Valve Stop	—	8TL-176
♦• 5	Exhaust Silencer	8SL-311	8SL-311
• 6	Exhaust Deflector	8SL-23	8SL-23
	for models ending in -EU	8SL-EU-23	8SL-EU-23
	for all other models	8SL-23	8SL-23
♦• 7	Exhaust Deflector Seal (2)	AF160-291Z	AF160-291Z
8	Deflector Retaining Ring	8SL-203	8SL-203
9	Throttle Valve Plunger Assembly	8SL-A302	8SL-A302
♦• 10	Throttle Plunger Seal	8SL-259	8SL-259
11	Throttle Plunger Bushing Assembly	8SL-A503	8SL-A503
♦• 12	Throttle Plunger Bushing Seal	405-159	405-159
13	Throttle Valve Plunger Stop	8SL-305	8SL-305
14	Throttle Valve Seat Assembly	8SL-A303	8SL-A303
• 15	Valve Seat Face	8SL-159	8SL-159
♦• 16	Valve Seat Seal	AF120-290	AF120-290
17	Throttle Valve Ball	K6U-941	K6U-941
♦ 18	Throttle Valve Spring	8SL-262	8SL-262
19	Regulator Body Assembly	—	8TL-A173
20	Regulator Spring	—	8TL-180
21	Regulator Ball	—	2U-722
22	Regulator Adjusting Screw	—	8TL-174
23	Lock Screw	—	8TL-179
24	Bleed Adjusting Screw	—	8TL-175
25	Sensor Port Plug	—	5081T-266
26	Regulator Body Cap	—	8TL-181
♦ 27	Regulator Body Seal	—	C321-606
♦ 28	Air Strainer	834-61	834-61
29	Inlet Bushing	88V60-38	88V60-38
30	Throttle Lever	8SL-273	8SL-273
♦• 31	Throttle Lever Retaining Pin	MR-100	MR-100
32	Reverse Valve Assembly	8RSL-A329	—
33	Reverse Valve Seal (2)	85H-167	—

* Not illustrated.

♦ Indicates Tune-up Kit part.

• To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (♦) for every four tools in service.

MAINTENANCE SECTION

		PART NUMBER FOR ORDERING	
		8RS, 8S	8T
34	Reverse Valve Knob	8RSL-163	_____
35	Reverse Valve Knob Pin	R100B-120	_____
36	Detent Ball	8RSL-31	_____
37	Detent Spring	5RA-664	_____
38	Detent Adjusting Screw	8RSL-662	_____
39	Rotor		
	with L ratio gearing	8SL-53	8SL-53
	with M, N, P or Q ratio gearing	8SM-53	8SM-53
◆• 40	Vane Packet (set of 5 Vanes)	8SL-42-5	8SL-42-5
41	Rear Rotor Bearing Support		
	for nonreversible models	8SL-25	8SL-25
	for reversible models	8RSL-25	_____
◆• 42	Rear Bearing Support Gasket		
	for nonreversible models	8SL-283	8SL-283
	for reversible models	8RSL-283	_____
• 43	Rear Rotor Bearing	AG210-24Z	AG210-24Z
• 44	Rotor Bearing Retaining Nut	8SL-118	8SL-118
◆ 45	Rear End Plate Gasket	8SL-739	8SL-739
46	Rear End Plate	8SL-12	8SL-12
47	Cylinder		
	for nonreversible models	8SL-3	8SL-3
	for reversible models	8RSL-3	_____
48	Front End Plate	8SL-11	8SL-11
49	Front Rotor Bearing	WFS182-24	WFS182-24
50	Cylinder Dowel		
	for nonreversible models	8SL-98	8SL-98
	for reversible models	8RSL-98	_____
51	Front Rotor Bearing Support Assembly	8SL-A26	8SL-A26
52	Front Rotor Bearing Retainer	AFH120A-362	AFH120A-362
53	Horizontal Hanger	8SL-366	8SL-366
*	Shutoff Valve Label	_____	6WT-999
*	Tune-up Kit (includes illustrated parts 5, 7 [2], 10, 12, 16, 18, 27, 28, 31, 40, 42, and 45)	_____	8T-TK1


* Not illustrated.

◆ Indicates Tune-up Kit part.

• To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (•) for every four tools in service.

MAINTENANCE SECTION

GEAR CASE ASSEMBLY



(Dwg. TPC593)

PART NUMBER FOR ORDERING



		L Ratio	M Ratio	N Ratio	P Ratio	Q Ratio
75	Motor Clamp Washer	8SL-207	8SL-207	8SL-207	8SL-207	8SL-207
76	Gear Case Assembly	8SL-A37	8SL-A37	8SN-A37	8SN-A37	8SN-A37
77	Grease Fitting	D0F9-879	D0F9-879	D0F9-879	D0F9-879	D0F9-879
	Gear Head Assembly	—	—	8SN-A216A	8SP-A216A	8SQ-A216A
78	Gear Head	—	—	8SN-216A	8SP-216A	8SQ-216A
79	Planet Gear Assembly (3)					
	for N ratio gearing					
	(16 teeth, color-coded yellow) ..	—	—	8SN-A9	—	—
	for P ratio gearing					
	(15 teeth, color-coded red) ..	—	—	—	8SP-A9	—
	for Q ratio gearing					
	(17 teeth, color-coded green) ..	—	—	—	—	8SQ-A9


MAINTENANCE SECTION

PART NUMBER FOR ORDERING



		L Ratio	M Ratio	N Ratio	P Ratio	Q Ratio
80	Planet Gear Bearing (2 for each Planet Gear)	—	—	8SL-500	8SL-500	8SL-500
81	Planet Gear Shaft (3)	—	—	8SN-190	8SN-190	8SN-190
82	Rotor Pinion	—	—	8SN-17	8SP-17	8SQ-17
83	Gear Head Spacer	—	—	8SN-80	8SN-80	8SN-80
84	Spindle Assembly	8SL-A108A	8SM-A108A	8SN-A108A	8SP-A108A	8SP-A108A
	Spindle	8SL-108A	8SM-108A	8SN-108A	8SP-108A	8SP-108A
85	Spindle Planet Gear Assembly (3) for L ratio gearing (20 teeth, color-coded black)	8SL-A10	—	—	—	—
	for M ratio gearing (21 teeth, color-coded white)	—	8SM-A10	—	—	—
	for N ratio gearing (15 teeth, not color-coded)	—	—	8SN-A10	—	—
	for P or Q ratio gearing (18 teeth, color-coded red)	—	—	—	8SP-A10	8SP-A10
	WFS182-654	WFS182-654	—	—	WFS182-654	WFS182-654
86	Planet Gear Bearing	WFS182-654	WFS182-654	—	—	—
87	Bearing Roller (15 for each Planet Gear)	—	—	8SN-654	—	—
88	Roller Retainer (2 for each Planet Gear)	—	—	8SN-655	—	—
89	Planet Gear Shaft (3)	8SL-191	8SL-191	8SN-190	8SL-191	8SL-191
90	Spindle Spacer	WFS182-111	WFS182-111	WFS182-111	WFS182-111	WFS182-111
91	Spindle Bearing (2 for L and M ratios; 1 for N, P and Q ratios) ..	R1602-510	R1602-510	R1602-510	R1602-510	R1602-510
92	Gear Head Bearing	—	—	R1602-510	R1602-510	R1602-510
93	Reaction Bar Holder Assembly	8SL-A60	8SL-A60	8SL-A60	8SL-A60	8SL-A60
94	Bar Lock Screw	9SL-50	9SL-50	9SL-50	9SL-50	9SL-50
95	Adapter Bolt	9SL-49	9SL-49	9SL-49	9SL-49	9SL-49
96	Torque Reaction Bar	9SL-48	9SL-48	9SL-48	9SL-48	9SL-48

MAINTENANCE SECTION ANGLE ATTACHMENTS



PART NUMBER FOR ORDERING

		For Models ending in 32	For Models ending in 53
100	Angle Attachment	8SA32	8SA53
101	Angle Housing Assembly	8SA32-A550	8SA53-A600
102	Angle Housing Cap	8SA32-110	182A53-110
• 103	Grease Fitting	D0F9-879	D0F9-879
• 104	Upper Spindle Bearing	8SA32-603	182A53-603
• 105	Matched Gear Set	8SA32-A552	182A53-A602
106	Bevel Pinion (not sold separately)	_____	_____
107	Bevel Pinion Bearing	182A53-606	182A53-606
108	Bevel Pinion Bearing Spacer	182A53-A165	182A53-A165
109	Front Seal	R18LF-21	R18LF-21
110	Rear Seal	C321-606	C321-606
111	Bevel Pinion Thrust Bearing	R1610-105	R1610-105
	Bevel Pinion Thrust Washer	182A53-554	182A53-554

- To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (•) for every four tools in service.

MAINTENANCE SECTION

PART NUMBER FOR ORDERING

		For Models ending in 32	For Models ending in 53
112	Bevel Pinion Snap Ring	182A53-689	182A53-689
113	Bevel Pinion Retainer	182A53-589	182A53-589
◊ 114	Socket Adapter Spindle Assembly		
+	3/8" Square Drive Flush Spindle	8SA32-P507-3/8	_____
+	1/2" Square Drive Flush Spindle	_____	182A53-P507-1/2
+	3/8" Square Drive Recessed Spindle	8SA32-P607-3/8	_____
+	1/2" Square Drive Recessed Spindle	_____	182A53-A607-1/2
115	Socket Retainer	5020-716	804-716
116	Socket Retainer Spring	401-718	5UHD-718
◊ *	Flush Socket Spindle		
	1/2" Hexagon	8SA34-807	182A54-807
	13 mm Hexagon	8SA34-807M	182A13MF-807
	9/16" Hexagon	_____	182A55-807
	15 mm Hexagon	_____	8SA55-807M
	5/8" Hexagon	_____	182A56-807
	17 mm Hexagon	_____	8SA56-807M
• 118	Lower Spindle Bearing	8SA32-593	182A53-593
◊ 119	Bevel Gear Retainer	8SA32-578	_____
◊ 120	Bevel Gear Lock Nut	_____	182A53-578
121	Bevel Spacer Retainer	182A53-685	182A53-685
122	Spindle Bearing Cap	8SA32-531	182A53-531
*	Spindle Bearing Cap Wrench	8SA32-26	WFS182-26
124	Attachment Coupling Nut	8SA32-27	8SA32-27
125	Coupling Nut Retainer	182A53-29	182A53-29

* Not illustrated.

• To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (•) for every four tools in service.


◊ When ordering a Socket Adapter Spindle (114) or Flush Socket Spindle, also order a Bevel Gear Retainer (119) or Bevel Gear Lock Nut (120).

+ When using Spindle No. 8SA32-P507-3/8 or 182A53-P507-1/2, the rear face of the socket will be flush with the face of the Angle Housing.

When using Spindle No. 8SA32-P607-3/8 any socket not exceeding 15/16" diameter will fit up into the Angle Housing, thus reducing the overall height by 1/4".

When using Spindle No. 182A53-A607-1/2 any socket not exceeding 1-11/32" diameter will fit up into the Angle Housing, thus reducing the overall height by 1/4".

MAINTENANCE SECTION
ANGLE HOUSING EXTENSION ASSEMBLY



(Dwg. TPC420)

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

	6" Angle Housing Extension Assembly	8SL-A327-6	205	Extension Arbor Retainer	182A53-589
200	Extension Arbor	8SL-327-6	206	Extension Arbor Thrust Bearing	R1610-105
201	Arbor Housing	8SL-43-6	207	Extension Arbor Thrust Washer	182A53-554
202	Arbor Spacer	WFS182-111	208	Coupling Nut	8SA32-27
203	Arbor Bearing	R1602-510	209	Coupling Nut Retainer	182A53-29
204	Extension Arbor Snap Ring ..	182A53-689			

MAINTENANCE SECTION

⚠ WARNING

Always wear eye protection when operating or performing maintenance on this tool.

Always turn off air supply and disconnect air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.

LUBRICATION

Each time the Series 8RS, 8S, and 8T Angle Wrenches are disassembled for maintenance, repair or replacement of parts, lubricate the tool as follows:

1. Inject approximately 1 cc of Ingersoll-Rand No. 28 Grease into the Grease Fitting (77).
2. Inject approximately 1 cc of Ingersoll-Rand No. 66 Grease into the Grease Fitting (102).
3. Inject approximately 2-1/2 cc of Ingersoll-Rand No. 10 Oil into the air inlet before attaching the air hose.

DISASSEMBLY

General Instructions

1. Do not disassemble the tool any further than necessary to replace or repair damaged parts.
2. Whenever grasping a tool or part in a vise, always use leather-covered or copper-covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members and housings.
3. Do not remove any part which is a press fit in or on a subassembly unless the removal of that part is necessary for repairs or replacement.
4. Do not disassemble the tool unless you have a complete set of new gaskets and O-rings for replacement.
5. Do not press any needle bearing from a part unless you have a new needle bearing on hand for installation. Needle bearings are always damaged during the removal process.

Disassembly of the Angle Attachment

1. With the Gear Case Assembly (76) clamped in leather-covered or copper-covered vise jaws with the Angle Housing Assembly (100) upward, unscrew the Attachment Coupling Nut (124).
2. Carefully separate the Angle Housing Assembly from the Gear Case Assembly.

NOTICE

The Spindle Bearing Cap (122) has left-hand threads. Because an adhesive is used on the threads, it may be necessary to apply moderate heat to release the bond.

CAUTION

If the application of heat is necessary, apply it only to the area of the Angle Housing Assembly directly over the threads. If this procedure is not followed, the Lower Spindle Bearing (118) may be damaged.

3. Using the No. WFS182-26 Bearing Cap Wrench for the No. 8SA53 Angle Head, or using the No. 8SA32-26 Bearing Cap Wrench for the No. 8SA32 Angle Head, unscrew the Spindle Bearing Cap (122).

CAUTION

If more than one angle head is disassembled at a time, take care not to mix Bevel Gears (105) and Bevel Pinion (104) from different Angle Heads. These gear sets are specially matched and are available only as matched sets.

4. Withdraw the Socket Adapter Spindle Assembly (114) from the Angle Housing.
5. If required, remove the Bevel Gear Retainer (119) or Bevel Gear Lock Nut (120), the Bevel Gear (105), and the Lower Spindle Bearing (118) from the Socket Adapter Spindle Assembly.
6. If required, release the Socket Retainer (115) by removing the Socket Retainer Spring (116).
7. Remove the Bevel Pinion Snap Ring (112) and slip the Bevel Pinion Retainer (113), Thrust Bearing (110), and Thrust Washer (111) from the bevel pinion shaft.
8. Remove the Bevel Spacer Retainer (121) and withdraw the Bevel Pinion Bearing Spacer (107).

CAUTION

Do not remove the Pinion from Bevel Pinion Bearing (106) unless you have a new Bearing available.

9. Grasping the bevel pinion shank in leather-covered or copper-covered vise jaws, pull the Pinion from the Angle Housing. Rapping the open end of the Housing with a soft-faced hammer may help remove the Bevel Pinion (104) and Bearing.
10. Press the Upper Spindle Bearing (103) and Angle Housing Cap (101) out of the Angle Housing Assembly.

MAINTENANCE SECTION

Disassembly of Gearing Case Assembly

1. Clamp the Gear Case Assembly (76) in leather-covered or copper-covered vise jaws horizontally.
2. Carefully unscrew the Motor Housing Assembly (1) from the Gear Case.

NOTICE

The rear Spindle Bearing (91), Gear Head Bearing (92), and the Motor Clamp Washer (75) will either stay with the Motor Housing Assembly or the Gear Case Assembly.

3. Remove the Motor Clamp Washer and either Bearing if they stay with the Gear Case Assembly.

For N, P, or Q Gear Ratios only

4. Remove the Gear Head (78).

NOTICE

The Planet Gear Assembly (79) holds the Rotor Pinion (82) in place.

5. Remove the Planet Gear Shaft (81) that secures the Planet Gear Assembly (79).
6. Remove the Rotor Pinion.
7. If required, remove the Planet Gear Bearing (80) from the Planet Gear Assembly.

For all Ratios

8. Remove the Spindle Assembly (84).

NOTICE

The Bearing Rollers (87) are free to fall if the Roller Retainer (88) is removed from the Spindle Planet Gear Assembly (85).

9. Press the Planet Gear Shaft (89) from the splined end of the Spindle Assembly (84).

Disassembly of Motor

1. Grasp the shaft of the Rotor (50) in leather-covered or copper-covered vise jaws and pull the assembled motor from the Motor Housing Assembly (1).
2. Remove the Front Rotor Bearing Retainer (52) and the Front Rotor Bearing Support Assembly (51).
3. Holding the Cylinder (47), tap the splined end of the Rotor with a light, plastic-faced hammer to remove the Front Rotor Bearing (49), and Front End Plate (48).
4. Remove the Cylinder and Vanes (40) from the Rotor.
5. Remove the Rear Bearing Support Gasket (42) and the Rear Rotor Bearing Support (41).

6. Remove the Rotor Bearing Retaining Nut (44), the Rear Rotor Bearing (43), the Rear End Plate Gasket (45), and the Rear End Plate (46).
7. Examine all motor parts for wear or damage as follows:
 - a. **Vanes** – Check for evidence of cracking, chipping or spalling. Replace the complete set of Vanes if any of these conditions exists.
 - b. **Rotor Bearings** – Check for looseness or roughness. Replace a Bearing if either condition is detected.
 - c. **Cylinder** – Examine the bore. If it is cracked, wavy or rough, replace the Cylinder.
 - d. **End Plates** – Examine the rotor side for scoring. Polish out shallow score marks using fine (320 grit) emery cloth placed on a hard, flat surface. Replace End Plates having deep score marks.
 - e. **Rotor** – Polish the ends of the Rotor with fine emery cloth to remove score marks. Check the spline for excessive wear. Replace a Rotor with a worn or broken spline.

Disassembly of the Throttle Mechanism

1. Clamp the Motor Housing Assembly (1) in leather-covered or copper-covered vise jaws with the Throttle Lever (30) upward.
2. Drive the Throttle Lever Retaining Pin (31) that secures the Throttle Lever (30), from the Motor Housing.
3. Remove the Throttle Valve Plunger Stop (13), the Throttle Plunger Bushing Assembly (11), and the Throttle Valve Plunger Assembly (9).
4. Rotate the Motor Housing to gain access to the Inlet Bushing (29).
5. Remove the Inlet Bushing, Air Strainer (28), Throttle Valve Spring (18), Throttle Valve Ball (17), Valve Seat Face (15), Throttle Valve Seat Assembly (14), and the Valve Seat Seal (16).

Disassembly of the Shutoff Valve

For Series 8T only

1. Remove the Regulator Body Cap (26).
2. Loosen the Lock Screw (23) and remove the Regulator Adjusting Screw (22).
3. Remove the Regulator Spring (20), and the Regulator Ball (21).
4. Carefully remove the Regulator Body Assembly (19).
5. Remove the Shutoff Valve (2), Shutoff Valve Body (3), the Shutoff Valve Spring (4) and the Shutoff Valve Stop (4A).

MAINTENANCE SECTION

Disassembly of the Reverse Valve

For Series 8RS only

NOTICE

The Detent Ball (36) is spring-loaded. Do not lose the Detent Ball or the Detent Spring (37).


1. Carefully unscrew the Detent Adjusting Screw (38) and remove the Detent Spring and the Detent Ball.
2. Remove the Reverse Valve Knob Pin (35) and the Reverse Valve Knob (34).
3. Pull the Reverse Valve Assembly (32) from the bushing in the Motor Housing Assembly (1).

ASSEMBLY

General Instructions

1. Always press on the **inner** ring of a ball-type bearing when installing the bearing on a shaft.
2. Always press on the **outer** ring of a ball-type bearing when pressing the bearing into a bearing recess.
3. Whenever grasping a tool or part in a vise, always use leather-covered or copper-covered vise jaws. Take extra care with threaded parts and housings.
4. Always clean every part and wipe every part with a thin film of oil before installation.
5. Check every bearing for roughness. If an open bearing must be cleaned, wash it thoroughly in a clean, suitable, cleaning solution and dry with a clean cloth. **Sealed or shielded bearings should not be cleaned.** Work grease into every open bearing before installation.
6. Apply a film of O-ring lubricant to every O-ring before installation.
7. Unless otherwise noted, always press on the stamped end of a needle bearing when installing a needle bearing into a recess. Use a bearing inserting tool similar to the one shown in Dwg. TPD786.

Needle Bearing Inserting Tool



* Registered Trademark of DuPont Corporation.

Assembly of the Reverse Valve

For Series 8RS only

1. If required, place new Reverse Valve Seals (33) in the grooves on the Reverse Valve Assembly (32).
2. From the Lever (30) side, push the Reverse Valve into the reverse valve bushing in the Motor Housing (1).
3. Place the Reverse Valve Knob (34) onto the exposed hub of the Reverse Valve and secure it using the Reverse Valve Knob Pin (35).
4. Insert the Detent Ball (36), followed by the Detent Spring (37), into the small hole in the Reverse Valve Knob and secure them using the Detent Adjusting Screw (38).

Assembly of the Shut-off Valve

For Series 8T only

1. Place the Shutoff Valve Stop (4A), Shutoff Valve Spring (4), the Shutoff Valve Body (3), and the Shutoff Valve (2) into the bushing in the Motor Housing.

NOTICE

Make certain the Shutoff Valve Spring seats in the recess in the Shutoff Valve.

2. Place the Regulator Body Seal (27) on the Regulator Body Assembly (19), apply Loctite Pipe Sealant with Teflon®* to the threads on the Body and thread the Regulator Body into the Motor Housing Assembly (1) so that it fits snugly.

NOTICE

Do not tighten the Regulator Adjusting Screw (22). The Regulator Spring (20) may be damaged if the Screw is brought down snug.

3. Place the Regulator Ball (21) followed by the Regulator Spring, smaller diameter first, into the large hole in the top of the Regulator Body. Retain the Ball and Spring using the Regulator Adjusting Screw.
4. Apply Loctite Pipe Sealant with Teflon to the threads of the Sensor Port Plug (25) and insert it into the tapped hole adjacent to the Regulator Adjusting Screw (22) hole.
5. Lock the Regulator Adjusting Screw with the Lock Screw (23).

MAINTENANCE SECTION

6. Install the Exhaust Deflector Seals (7) into their grooves on the Motor Housing. Wrap the Exhaust Silencer (5) around the Housing in its recess. Slide the Exhaust Deflector (6) over the Seals and retain them using the Deflector Retaining Ring (8). If a Horizontal Hanger (53) is to be used, slide it over the Housing after the Exhaust Deflector and retain it using the Retaining Ring.
7. After assembling the Angle Wrench, adjust the shutoff mechanism as instructed in **Adjustment of Shutoff Valve**.

Assembly of Throttle

1. Insert the Valve Seat Face (15) into the internal groove and the Valve Seat Seal (16) to the external groove of the Throttle Valve Seat Assembly (14).
2. Insert and firmly seat the assembled Valve Seat, small diameter first, into the tapped end of the Motor Housing (1).
3. With the Housing held firmly in leather-covered or copper-covered vise jaws, inlet bushing end up, place the Throttle Valve Ball (17), the Throttle Valve Spring (18), smaller diameter first, and the Air Strainer (28) into the inlet bushing end.


NOTICE

Make certain that the Air Strainer sits within the Inlet Bushing (29).

4. Thread the Inlet Bushing into the Motor Housing and tighten it to 35 to 45 ft-lb (47 to 61 Nm) torque.
5. Place the Throttle Plunger Bushing Seal (12) on the Throttle Plunger Bushing Assembly (11) and thread the Bushing Assembly into the Motor Housing.
6. Place the Throttle Plunger Seal (10) on the Throttle Valve Plunger Assembly (9) and insert the Plunger, beveled end first, through the Throttle Plunger Bushing Assembly.
7. Install the Throttle Lever (30) using the Throttle Lever Retaining Pin (31) and operate the Lever to check for free movement.

Assembly of Motor

1. Slide the Rear End Plate (46), recessed face trailing, followed by the Rear Rotor Bearing (43), shielded side trailing, onto the threaded hub of the Rotor (39). Thread the Rotor Bearing Retaining Nut (44) onto the hub a few turns.
2. Support the Rear End Plate, see Dwg. TPD614, and place one 0.001" (0.03 mm) thick shim between the End Plate and a solid rotor boss.



(Dwg. TPD614)

3. While applying a 10 lb (4.54 kg) force downward as illustrated, tighten the Retaining Nut until the spacing of the Rotor and End Plate is approximately 0.001". Remove the shim and manually rotate the pre-loaded Rotor to detect rubbing between the Rotor and End Plate. If rubbing is detected, back the Nut off a turn and repeat this procedure.
4. Stand the assembled Rotor on a workbench with the splined end up. Slide the Cylinder (47) over the Rotor so the 1/8" (3 mm) diameter hole in the Cylinder is aligned with the slot in the Rear End Plate and so the recess port in the end of the Cylinder is to the left of the 1/8" hole when viewed from the splined end.
5. Wipe each Vane (40) with a light coat of Ingersoll-Rand No. 10 Oil. Insert a Vane into each slot in the Rotor. Slide the Front End Plate (48), recessed face trailing, onto the splined Rotor hub.
6. Press the Front Rotor Bearing (49) onto the splined hub and rotate the Rotor manually to make certain it moves freely without binding.

NOTICE

The dowel hole in the bore of the Housing is in line with the Throttle Lever.

7. Using an 1/8" (3 mm) diameter rod as a guide going through the notch in the Front End Plate, through the hole in the Cylinder, the notch in the Rear End Plate, and the holes in the Rear End Plate Gasket and the Rear Rotor Bearing Support, guide the motor into the bore of the Motor Housing Assembly (1).
8. Carefully remove the guide rod and replace it with the Cylinder Dowel (50).
9. Install the Front Rotor Bearing Retainer (52) in its groove inside the Front Rotor Bearing Support (51).

MAINTENANCE SECTION

Assembly of the Gearing Case Assembly


For the L and M Ratio Gearing

NOTICE

An L or M is stamped on the web of Spindles for L or M ratio gearing.

1. Press a Planet Gear Bearing (86) into each Spindle Planet Gear (85) to a depth of 0.051" to 0.059" (1.30 mm to 1.50 mm) from the face of the Gear using the proper bearing inserting tool, see Dwg. TPD637-1, Table A, and lubricate the Bearings as instructed in **LUBRICATION**.

Planet Gear Bearing Inserting Tool



(Dwg. TPD637-1)

2. Insert an assembled Planet Gear into each slot in the Spindle Assembly (84) and press a Planet Gear Shaft (89) into the Spindle through each Planet Gear from the smooth bore hub end of the Spindle.
3. Using the Rotor (50) as a pilot inside the Spindle, insert the Spindle Assembly into the Gear Case Assembly (76).
4. Turn the Gear Case end for end, with the small diameter of the Gear Case up, and slide the Spindle Spacer (90) onto the end of the Spindle.
5. Support the motor end of the Spindle and press the front Spindle Bearing (91) onto the end of the Spindle.

6. Place the Motor Clamp Washer (75), concave (dished) face first, over the unsplined end of the Spindle.
7. Press the rear Spindle Bearing (91) into the large recess in the Front Rotor Bearing Support (51) and slide the Bearing and Support onto the hub of the Spindle.

For the N, P and Q Ratio Gearing

NOTICE

An N, P, or Q is stamped on the web of Gear Heads for N, P and Q ratio gearing.

1. **For N ratio gearing** – Apply a liberal amount of the recommended grease to the inside diameter of each Spindle Planet Gear (85) and place fifteen Bearing Rollers (87) against the inside diameter of each Gear. Install a Roller Retainer (88) to each end of each Gear.
For P and Q ratio gearing – Press two Planet Gear Bearings (86) into each Planet Gear to a depth of 0.005" to 0.010" (0.13 mm to 0.25 mm) from the face of the Gear.
2. Insert an assembled Gear into each slot in the Spindle and press a Planet Gear Shaft (89) from the smooth bore end of the Spindle into the pin holes to retain the Gears.
3. Using the unassembled Gear Head (78) as a pilot through the center of the assembled Spindle Assembly (84), insert the Spindle and Planet Gears into the Gear Case. Take care to engage the Planet Gears with the internal gear in the Gear Case.
4. Slowly withdraw the Gear Head from the Gear Case.
5. Press two Planet Gear Bearings (80) into each of the Planet Gears (79).
6. Insert an assembled Planet Gear into each slot in the Gear Head, capturing the Rotor Pinion (82) in the Gear Head, and retain the Gears by pressing the Planet Gear Shafts (81) from the smooth outside diameter end of the Gear Head.
7. Slide the Gear Head Spacer (83) over the geared end of the Gear Head and insert this assembly into the Gear Case. Make certain the Gear Head properly meshes with the Spindle Planet Gears (85).

TABLE A

Bearing Number	A		B		C		D	
	Min	Max	Min	Max	Min	Max	Min	Max
WFS182-654	0.152"	0.153"	0.265"	0.266"	0.051"	0.059"	0.296"	0.312"
8SL-500	0.1207"	0.1217"	0.234"	0.235"	0.005"	0.010"	0.125"	0.140"

MAINTENANCE SECTION

8. Place the Gear Case Assembly on the workbench with the small diameter up and slide the Spindle Spacer (90) onto the end of the Spindle.
9. Support the motor end of the Gear Head and press the front Spindle Bearing (91) onto the Spindle.
10. Turn the Gear Case end for end and place the Motor Clamp Washer (75), concave (dished) face first, over the Gear Head. Make certain that the outside diameter of the Motor Clamp Washer contacts the end of the ring gear teeth.
11. Press the Gear Head Bearing (92) into the large recess in the Front Rotor Bearing Support and slide the Bearing onto the hub of the Gear Head.
12. Slide the Reaction Bar Holder Assembly (93) over the Gear Case Assembly. Secure it to the Gear Case by tightening the Adapter Bolt (95). Place the Torque Reaction Bar (96) into the Reaction Bar Holder Assembly and secure it with the Bar Lock Screw (94).

Assembly of Angle Attachment


1. Lubricate the Bevel Pinion (104) as instructed in **LUBRICATION** and insert it, gear end first, into the long bore of the Angle Housing Assembly (100).
2. Lubricate the Bevel Pinion Bearing (106) as instructed in **LUBRICATION** and insert it, unstamped end first, into the bore of the Angle Housing, after the Bevel Pinion.
3. Using a bearing inserting tool, see Dwg. TPD786, press the Bearing so the stamped face is 1-11/32" (34 mm) below the end face of the Angle Housing.
4. Install the Front Seal (108) and the Rear Seal (109) onto the Bevel Pinion Bearing Spacer (107).
5. Insert the Spacer, small diameter first, into the long bore of the Angle Housing and retain it using the Bevel Spacer Retainer (121).
6. Lubricate the Bevel Pinion Thrust Bearing (110) as instructed in **LUBRICATION**. Install, in the following order; the Bevel Pinion Thrust Washer (111), Bevel Pinion Thrust Bearing and the Bevel Pinion Retainer (113), recessed face trailing, over the splined end of the Bevel Pinion. Retain these parts using the Bevel Pinion Snap Ring (112).
7. If the Lower Spindle Bearing (118) has been removed, press the new Bearing onto the Socket Adapter Spindle Assembly (114) with the red side closest to the square drive end.
8. Press the Bevel Gear (105), geared side trailing, onto the ground end of the Spindle and into contact with the Lower Spindle Bearing.
9. **For No. 8SA32** – Retain the Bevel Gear using the Bevel Gear Retainer (119).

For No. 8SA53 – Clean the threads on the Spindle, apply a film of thread locking compound to the threads, apply the Bevel Gear Lock Nut (120) and tighten it to a minimum of 25 ft-lb (34 Nm) torque.

CAUTION

Press on the stamped face of the Upper Spindle Bearing (103). Failure to do so will cause damage to the Bearing.

10. If the Spindle Upper Bearing was removed, press a new Bearing into the Angle Housing (100) from the large threaded end to the dimension, shown in Dwg. TPD636 and Table B.



(Dwg. TPD636)

TABLE B

Minimum Dimension "A"		
Angle Attachment	in	mm
8SA32	0.718	18.25
8SA53	0.683	17.35
Maximum Dimension "A"		
8SA32	0.728	18.50
8SA53	0.693	17.60

11. Lubricate the Upper Spindle Bearing as instructed in **LUBRICATION** and press the Angle Housing Cap (101) into its recess.
12. Insert the assembled Socket Adapter Spindle Assembly (114) into the Angle Housing, clean the threads on the Angle Housing and Spindle Bearing Cap (122), apply a film of thread locking compound to the threads and tighten the Bearing Cap to a minimum of 25 ft-lb (34 Nm) torque.

MAINTENANCE SECTION

13. Slide the Attachment Coupling Nut (124), threaded end trailing, over the splined end of the Angle Housing.
14. Apply the Coupling Nut Retainer (125) to the external groove on the splined end of the Angle Housing.
15. Engage the spline on the Bevel Pinion (104) with the matching spline on the Spindle Assembly (84) and tighten the Coupling Nut (124) to a minimum of 35 ft-lb (47 Nm) torque.

Adjustment of Shutoff Valve

NOTICE

Adjustment to the Shutoff Valve system is preset at the factory. Do not adjust any part of the Valve unless, after prolonged use of the Tool, the Tool shuts off prematurely or the Tool fails to shut off. Only if either of these conditions exist are you to adjust the Valve. Adjust the Valve according to the procedures below.

If premature shutoff occurs, proceed as follows:

NOTICE

The Bleed Adjusting Screw is located in the tapped port marked "A" on the face of the Regulator Body Assembly. The port marked "S" is a signal port to be used with monitoring equipment.

1. Set the inlet air pressure at 90 psig (6.2 bar/620 kPa) with the motor running. Slightly rotate the Bleed Adjusting Screw (24) counterclockwise and slowly depress the Throttle lever to determine continual motor operation. If necessary, repeat this procedure until the motor runs and remains running with the Lever depressed.
2. Securely anchor the Wrench and run it on a Model J Skidmore Test Stand a number of times at 50 psig (3.4 bar/340 kPa) air pressure and at 90 psig air pressure. The tool must shut off when tested at each pressure setting. If the Angle Wrench fails to shut off, adjust the Shutoff Valve as follows:
3. Operate the tool at 90 psig as instructed in Step 2. Release the Throttle lever and rotate the Bleed Adjusting Screw slightly clockwise and retest the tool. Continue testing and adjusting the Valve a slight amount each time until the Wrench shuts off properly.

TEST AND INSPECTION PROCEDURE

Run the performance tests at 90 psig (6.2 bar/620 kPa) air pressure at the inlet of the tool using 1/2" (13 mm) inside diameter supply hose.

1. Check the free speed of the Angle Wrench using a hand-held tachometer applied to the spindle. The minimum allowable free speeds are listed below.

Model	Stamped Free Speed, rpm (r/min)	Minimum Free Speed rpm (r/min)
8SM32	1110	1000
8SN32	840	760
8SP53	610	550
8RSL32	1140	1030
8RSM32	890	800
8RSN32	670	610
8RSP53	490	440
8RSQ53	420	380
8TM32	1110	1000
8TN32	840	760
8TP53	610	550
8TQ53	520	470

2. Using a Model J Skidmore tester, operate the Wrench to determine torque output. The minimum allowable torque levels are as follows:

Model	Minimum Torque	
	ft-lb	Nm
8SM32	23	31
8SN32	30	41
8SP53	40	54
8RSL32	16	22
8RSM32	21	28
8RSN32	27	37
8RSP53	36	49
8RSQ53	45	61
8TM32	23	31
8TN32	30	41
8TP53	40	54
8TQ53	50	68

MAINTENANCE SECTION

3. There must be no objectionable leaks in any non-exhaust areas. The exhaust deflector must rotate manually.
4. The throttle must operate freely and must not remain open when the lever is released with air at the inlet
5. The angle attachment, gear case and motor case must not generate excessive heat. Operate the tool at free speed for 20 seconds.

WARNING

Disconnect the air supply hose to the tool before proceeding.

6. Rotate the output spindle using a wrench. The spindle must rotate smoothly with no binding.
7. Examine the tool to see that the throttle lever is on the opposite side of and in line with the output spindle.

TROUBLESHOOTING GUIDE

Trouble	Probable Cause	Solution
Low power or low free speed	Low air pressure	Check the air line pressure at the inlet. The pressure must not exceed 90 psig (6.2 bar/620 kPa) at the inlet.
	Plugged Inlet Bushing Screen or Air Strainer Screen	Clean the Screen in a clean, suitable, cleaning solution. If it cannot be cleaned, replace it.
	Worn or broken Vanes	Replace the complete set of Vanes.
	Loose Rotor Bearing Retaining Nut	Tighten the Nut.
	Worn or broken Cylinder	Replace the Cylinder if it is worn or broken or if the bore is scored or wavy.
	Scoring of End Plates	Replace End Plates if they are scored.
	Improper lubrication or dirt build-up in the motor.	Lubricate the Wrench as instructed in LUBRICATION . If lubrication does not result in satisfactory operation, disassemble the motor inspect and clean all parts.
Scoring	Improper assembly	Make certain that all motor or Cylinder parts are properly aligned prior to clamping the motor assembly.
Gear Case gets hot	Excessing grease	Clean and inspect the Gear Case gearing parts and lubricate as instructed in LUBRICATION .
	Worn or damaged parts	Clean and inspect the Gear Case and gearing. Replace worn or broken components.
Tool fails to shut off	Dirt or burrs on Shutoff Valve or Bushing	Clean the parts and remove the burrs.
	Bleeder ports plugged	Clean the bleeder ports with fine wire.

NOTICE

SAVE THESE INSTRUCTIONS. DO NOT DESTROY.