


OPERATION AND MAINTENANCE MANUAL FOR SERIES 6A DRILLS

NOTICE

Series 6A Drills are designed for drilling operations in the aerospace, automotive, appliance, electronic, machining and furniture industries.

Ingersoll-Rand is not responsible for customer modification of tools for applications on which Ingersoll-Rand was not consulted.



⚠ WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.
READ THIS MANUAL BEFORE OPERATING TOOL.**

**IT IS THE RESPONSIBILITY OF THE EMPLOYER TO PLACE THE INFORMATION
IN THIS MANUAL INTO THE HANDS OF THE OPERATOR.**

**FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.
PLACING TOOL IN SERVICE**

- Always operate, inspect and maintain this tool in accordance with American National Standards Institute Safety Code for Portable Air Tools (ANSI B186.1).
- For safety, top performance, and maximum durability of parts, operate this tool at 90 psig (6.2 bar/620 kPa) maximum air pressure at the inlet with 3/8" (10 mm) inside diameter air supply hose.
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.
- Do not use damaged, frayed or deteriorated air hoses and fittings.
- Be sure all hoses and fittings are the correct size and are tightly secured. See Dwg. TPD905-1 for a typical piping arrangement.
- Always use clean, dry air at 90 psig maximum air pressure. Dust, corrosive fumes and/or excessive moisture can ruin the motor of an air tool.
- Do not lubricate tools with flammable or volatile liquids such as kerosene, diesel or jet fuel.
- Do not remove any labels. Replace any damaged label.

USING THE TOOL

- Always wear eye protection when operating or performing maintenance on this tool.

- Always wear hearing protection when operating this tool.
- Keep hands, loose clothing and long hair away from rotating end of tool.
- Anticipate and be alert for sudden changes in motion during start up and operation of any power tool.
- Keep body stance balanced and firm. Do not overreach when operating this tool. High reaction torques can occur at or below the recommended air pressure.
- Tool accessories may continue to rotate briefly after throttle is released.
- Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.
- Use accessories recommended by Ingersoll-Rand.
- The Throttle Valve Cap is under pressure from the Throttle Valve Spring. Use care when removing the Throttle Valve Cap. (On tools where applicable.)
- This tool is not designed for working in explosive atmospheres.
- This tool is not insulated against electric shock.
- This tool is not designed for working in explosive atmospheres.

NOTICE

The use of other than genuine Ingersoll-Rand replacement parts may result in safety hazards, decreased tool performance, and increased maintenance, and may invalidate all warranties.

Repairs should be made only by authorized trained personnel. Consult your nearest Ingersoll-Rand Authorized Servicenter.









Refer All Communications to the Nearest
Ingersoll-Rand Office or Distributor.
© Ingersoll-Rand Company 2000

Printed in U.S.A.


WARNING LABEL IDENTIFICATION

⚠ WARNING

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.



**International Warning Label:
Order Part No. _____**



PLACING TOOL IN SERVICE

LUBRICATION



Ingersoll–Rand No. 10 Ingersoll–Rand No. 67


Always use an air line lubricator with these tools.
We recommend the following Filter–Lubricator–Regulator Unit:

USA – No. C11-03-G00

International – No. C16-C3-A29

For models with D, H, J, JJ, K or L gearing, inject approximately 2 to 3 cc of Ingersoll–Rand No. 67 Grease into the Grease Fitting in the Gear Case after each 50 000 cycles or 160 hours of operation, whichever occurs first.

For models with M, R or S gearing, inject approximately 3 to 4 cc of Ingersoll–Rand No. 67 Grease into the Grease Fitting in the Gear Case after each 50 000 cycles or 160 hours of operation, whichever occurs first.



(Dwg. TPD905-1)

HOW TO ORDER A DRILL

DRILL WITH PISTOL GRIP HANDLE

Model	Free Speed, rpm	Chuck Capacity	
		in	Nm
6ADST4	20 000	1/4	6
6AHST4	6 000	1/4	6
6AJST4	5 100	1/4	6
6AJJST4	3 950	1/4	6
6AKST4	3 100	1/4	6
6ALST4	2 150	1/4	6
6AMST6	1 500	3/8	10
6ARST6	500	3/8	10
6ASST6	350	3/8	10


MANUEL D'EXPLOITATION ET D'ENTRETIEN DES PERCEUSES DE LA SÉRIE 6A

NOTE

Les perceuses de la Série 6A sont destinées aux opérations de perçage dans les industries de l'aéronautique, de l'automobile, des appareils ménagers, de l'électronique, de l'usinage et des meubles.

Ingersoll-Rand ne peut être tenu responsable de la modification des outils par le client pour les adapter à des applications qui n'ont pas été approuvées par Ingersoll-Rand.

! ATTENTION



**D'IMPORTANTES INFORMATIONS DE SÉCURITÉ SONT JOINTES.
LIRE CE MANUEL AVANT D'UTILISER L'OUTIL.
L'EMPLOYEUR EST TENU DE COMMUNIQUER LES INFORMATIONS
DE CE MANUEL AUX EMPLOYÉS UTILISANT CET OUTIL.**

LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES.

MISE EN SERVICE DE L'OUTIL

- Toujours exploiter, inspecter et entretenir cet outil conformément au Code de sécurité des outils pneumatiques portatifs de l'American National Standards Institute (ANSI B186.1).
- Pour la sécurité, les performances optimales et la durabilité maximale des pièces, cet outil doit être connecté à une alimentation d'air comprimé de 6,2 bar (620 kPa) maximum à l'entrée, avec un flexible de 10 mm de diamètre intérieur.
- Couper toujours l'alimentation d'air comprimé et débrancher le flexible d'alimentation avant d'installer, déposer ou ajuster tout accessoire sur cet outil, ou d'entreprendre une opération d'entretien quelconque sur l'outil.
- Ne pas utiliser des flexibles ou des raccords endommagés, effilochés ou détériorés.
- S'assurer que tous les flexibles et les raccords sont correctement dimensionnés et bien serrés. Voir Plan TPD905-1 pour un exemple type d'agencement des tuyauteries.
- Utiliser toujours de l'air sec et propre à une pression maximum de 6,2 bar. La poussière, les fumées corrosives et/ou une humidité excessive peuvent endommager le moteur d'un outil pneumatique.
- Ne jamais lubrifier les outils avec des liquides inflammables ou volatiles tels que le kérosène, le gasoil ou le carburant d'aviation.
- Ne retirer aucune étiquette. Remplacer toute étiquette endommagée.

UTILISATION DE L'OUTIL

- Porter toujours des lunettes de protection pendant l'utilisation et l'entretien de cet outil.
- Porter toujours une protection acoustique pendant l'utilisation de cet outil.
- Tenir les mains, les vêtements flous et les cheveux longs, éloignés de l'extrémité rotative de l'outil.
- Prévoir, et ne pas oublier, que tout outil motorisé est susceptible d'à-coups brusques lors de sa mise en marche et pendant son utilisation.
- Garder une position équilibrée et ferme. Ne pas se pencher trop en avant pendant l'utilisation de cet outil. Des couples de réaction élevés peuvent se produire à, ou en dessous, de la pression d'air recommandée.
- La rotation des accessoires de l'outil peut continuer pendant un certain temps après le relâchement de la gâchette.
- Les outils pneumatiques peuvent vibrer pendant l'exploitation. Les vibrations, les mouvements répétitifs et les positions inconfortables peuvent causer des douleurs dans les mains et les bras. N'utiliser plus d'outils en cas d'inconfort, de picotements ou de douleurs. Consulter un médecin avant de recommencer à utiliser l'outil.
- Utiliser les accessoires recommandés par Ingersoll-Rand.
- Le chapeau de la soupape de commande est soumis à la pression du ressort de soupape. Prendre les soins nécessaires lors de la dépose du chapeau de soupape de commande. (Sur les outils concernés).
- Cet outil n'est pas conçu pour fonctionner dans des atmosphères explosives.
- Cet outil n'est pas isolé contre les chocs électriques.

NOTE

L'utilisation de rechanges autres que les pièces d'origine Ingersoll-Rand peut causer des risques d'insécurité, réduire les performances de l'outil et augmenter l'entretien, et peut annuler toutes les garanties.

Les réparations ne doivent être effectuées que par des réparateurs qualifiés autorisés. Consultez votre Centre de Service Ingersoll-Rand le plus proche.



Adresssez toutes vos communications au Bureau
Ingersoll-Rand ou distributeur le plus proche.
© Ingersoll-Rand Company 2000

Imprimé aux É.U.

SIGNIFICATION DES ÉTIQUETTES D'AVERTISSEMENT

ATTENTION

LE NON RESPECT DES AVERTISSEMENTS SUIVANTS PEUT CAUSER DES BLESSURES.

	ATTENTION Porter toujours des lunettes de protection pendant l'utilisation et l'entretien de cet outil.
	ATTENTION Porter toujours une protection acoustique pendant l'utilisation de cet outil.
	ATTENTION Couper toujours l'alimentation d'air comprimé et débrancher le flexible d'alimentation avant d'installer, déposer ou ajuster tout accessoire sur cet outil, ou d'entreprendre une opération d'entretien quelconque sur l'outil.
	ATTENTION Les outils pneumatiques peuvent vibrer pendant l'exploitation. Les vibrations, les mouvements répétitifs et les positions inconfortables peuvent causer des douleurs dans les mains et les bras. N'utiliser plus d'outils en cas d'inconfort, de picotements ou de douleurs. Consulter un médecin avant de recommencer à utiliser l'outil.
	ATTENTION Ne pas transporter l'outil par son flexible.
	ATTENTION Ne pas utiliser des flexibles ou des raccords endommagés, effilochés ou détériorés.
	ATTENTION Garder une position équilibrée et ferme. Ne pas se pencher trop en avant pendant l'utilisation de cet outil.
	ATTENTION Utiliser de l'air comprimé à une pression maximum de 6,2 bar (620 kPa).
Etiquette d'avertissement internationale: Commander Pièce No.	
	

MISE EN SERVICE DE L'OUTIL

LUBRIFICATION



Ingersoll-Rand No. 10 Ingersoll-Rand No. 67


Utiliser toujours un lubrificateur avec ces outils. Nous recommandons l'emploi du filtre-régulateur-lubrificateur suivant :

USA – No. C11-03-G00

International – No. C16-C3-A29

Pour les modèles équipés de la pignonnerie D, H, J, JJ, K ou L, injecter environ 2 à 3 cm³ de graisse Ingersoll-Rand No. 67 dans le raccord de graissage du boîtier d'engrenages tous les 50 000 cycles ou au minimum toutes les 160 heures de fonctionnement.

Pour les modèles équipés de la pignonnerie M, R, ou S, injecter environ 3 à 4 cm³ de graisse Ingersoll-Rand No. 67 dans le raccord de graissage du boîtier d'engrenages tous les 50 000 cycles ou au minimum toutes les 160 heures de fonctionnement.



(Plan TPD905-1)

MISE EN SERVICE DE L'OUTIL

SPÉCIFICATIONS


Modèle	Type de poignée	Capacité du mandrin		Vitesse à vide
		pouces	mm	tr/mn
6ADST4	pistolet	1/4	6	20 000
6AHST4	pistolet	1/4	6	6 000
6AJST4	pistolet	1/4	6	5 100
6AJJST4	pistolet	1/4	6	3 950
6AKST4	pistolet	1/4	6	3 100
6ALST4	pistolet	1/4	6	2 150
6AMST6	pistolet	3/8	10	1 500
6ARST6	pistolet	3/8	10	500
6ASST6	pistolet	3/8	10	350

MANUAL DE FUNCIONAMIENTO Y MANTENIMIENTO PARA TALADROS DE LA SERIE 6A

NOTA

Los taladros de la serie 6A están diseñados para las operaciones de taladrado en la industria aeroespacial, del automóvil, de electrodomésticos, electrónica, mecánica y del mueble.

Ingersoll-Rand no aceptará responsabilidad alguna por la modificación de las herramientas efectuada por el cliente para las aplicaciones que no hayan sido consultadas con Ingersoll-Rand.



AVISO

SE ADJUNTA INFORMACIÓN IMPORTANTE DE SEGURIDAD.

LEA ESTE MANUAL ANTES DE UTILIZAR LA HERRAMIENTA.

**ES RESPONSABILIDAD DE LA EMPRESA ASEGURARSE DE QUE EL OPERARIO
ESTÉ AL TANTO DE LA INFORMACIÓN QUE CONTIENE ESTE MANUAL.**

EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRÍA OCASIONAR LESIONES.

PARA PONER LA HERRAMIENTA EN SERVICIO

- Para mayor seguridad, rendimiento óptimo y larga vida útil de las piezas, utilice esta herramienta a una presión de aire máxima de 90 psig (6,2 bar/620 kPa) con una manguera de suministro de aire con diámetro interno de 10 mm.
- Corte siempre el suministro de aire y desconecte la manguera de suministro de aire antes de instalar, desmontar o ajustar cualquier accesorio de esta herramienta, o antes de realizar cualquier operación de mantenimiento de la misma.
- No utilice manguras de aire y racores dañados, desgastados o deteriorados.
- Asegúrese de que todos los racores y manguras sean del tamaño correcto y estén bien apretados. El Esq. TPD905-1 muestra una disposición característica de las tuberías.
- Use siempre aire limpio y seco a una presión máxima de 90 psig (6,2 bar/620 kPa). El polvo, los gases corrosivos y el exceso de humedad pueden estropear el motor de una herramienta neumática.
- No lubrique las herramientas con líquidos inflamables o volátiles tales como queroseno, gasoil o combustible para motores a reacción.
- No saque ninguna etiqueta. Sustituya toda etiqueta dañada.

UTILIZACIÓN DE LA HERRAMIENTA

- Lleve siempre protección ocular cuando utilice esta herramienta o realice operaciones de mantenimiento en la misma.

- Lleve siempre protección para los oídos cuando utilice esta herramienta.
- Mantenga las manos, la ropa suelta y el cabello largo alejados del extremo giratorio de la herramienta.
- Antípese y esté atento a los cambios repentinos en el movimiento durante la puesta en marcha y utilización de toda herramienta motorizada.
- Mantenga una postura del cuerpo equilibrada y firme. No estire demasiado los brazos al manejar la herramienta. Pueden darse elevados pares de reacción a la presión de aire recomendada, e incluso a presiones inferiores.
- Los accesorios de la herramienta podrían seguir girando brevemente después de haberse soltado la palanca de mando.
- Las herramientas neumáticas pueden vibrar durante el uso. La vibración, los movimientos repetitivos o las posiciones incómodas pueden dañarle los brazos y manos. En caso de incomodidad, sensación de hormigueo o dolor, deje de usar la herramienta. Consulte con el médico antes de volver a utilizarla.
- Utilice únicamente los accesorios Ingersoll-Rand recomendados.
- El muelle de la válvula reguladora ejerce presión contra la tapa de dicha válvula. Tenga cuidado al sacar la tapa. (Si procede, según la herramienta).
- Esta herramienta no ha sido diseñada para trabajar en ambientes explosivos.
- Esta herramienta no está aislada contra descargas eléctricas.

NOTA

El uso de piezas de recambio que no sean las auténticas piezas Ingersoll-Rand puede poner en peligro la seguridad, reducir el rendimiento de la herramienta y aumentar los cuidados de mantenimiento necesarios, así como invalidar toda garantía.

Las reparaciones sólo se deben encomendar a personal debidamente cualificado y autorizado. Consulte con el centro de servicio autorizado Ingersoll-Rand más próximo.

Toda comunicación se deberá dirigir a la oficina o al distribuidor Ingersoll-Rand más próximo.





© Ingersoll-Rand Company 2000

Impreso en EE. UU.

ETIQUETAS DE AVISO

AVISO

EL HACER CASO OMISO DE LOS AVISOS SIGUIENTES PODRÍA OCASIONAR LESIONES.



PARA PONER LA HERRAMIENTA EN SERVICIO

LUBRICACIÓN



Ingersoll-Rand Nº 10



Ingersoll-Rand Nº 67


Utilice siempre un lubricador de aire comprimido con estas herramientas. Recomendamos utilizar el siguiente conjunto de filtro-lubricador-regulador:

USA – Nº C11-03-G00

Internacional – Nº C16-C3-A29

Para modelos con engranaje D, H, J, JJ, K o L, inyecte aproximadamente de 2 a 3 cc de grasa Ingersoll-Rand Nº 67 en el engrasador de la caja de engranaje después de cada 50000 ciclos o 160 horas de funcionamiento (lo que ocurra primero).

Para modelos con engranaje M, R o S, inyecte aproximadamente de 3 a 4 cc de grasa Ingersoll-Rand Nº 67 en el engrasador de la caja de engranaje después de cada 50000 ciclos o 160 horas de funcionamiento (lo que ocurra primero).



(Esq. TPD905-1)

PARA PONER LA HERRAMIENTA EN SERVICIO

ESPECIFICACIONES

Modelo	Tipo de Empuñadura	Capacidad del porta-brocas		Velocidad en vacío U/min
6ADST4	Pistola	1/4	6	20 000
6AHST4	Pistola	1/4	6	6 000
6AJST4	Pistola	1/4	6	5 100
6AJJST4	Pistola	1/4	6	3 950
6AKST4	Pistola	1/4	6	3 100
6ALST4	Pistola	1/4	6	2 150
6AMST6	Pistola	3/8	10	1 500
6ARST6	Pistola	3/8	10	500
6ASST6	Pistola	3/8	10	350


MANUAL DE FUNCIONAMENTO E MANUTENÇÃO

BERBEQUINS SÉRIES 6A



AVISO

Os Berbequins 6A são concebidos para aplicações de perfuração em linhas de montagem, indústrias de equipamentos, eletrônicas, aeroespaciais e de mobílias.
A Ingersoll-Rand não é responsável por modificações, feitas pelo cliente em ferramentas, nas quais a Ingersoll-Rand não tenha sido consultada.



! ADVERTÊNCIA

**INFORMAÇÃO DE SEGURANÇA IMPORTANTE EM ANEXO.
LEIA ESTE MANUAL ANTES DE OPERAR A FERRAMENTA.
É DA RESPONSABILIDADE DO EMPREGADOR COLOCAR A INFORMAÇÃO
DESTE MANUAL NAS MÃOS DO OPERADOR.**

**O NÃO CUMPRIMENTO DAS SEGUINTESE ADVERTÊNCIAS PODE RESULTAR EM FERIMENTOS.
COLOCANDO A FERRAMENTA
EM FUNCIONAMENTO**

- Sempre opere, inspecione e mantenha esta ferramenta de acordo com o Código de Segurança do Instituto Americano de Padrões Nacionais para Ferramentas Pneumáticas Portáteis (ANSI B186.1).
- Opere, inspecione e mantenha sempre esta ferramenta de acordo com todas regulamentações (local, estadual, federal e do país), que possam ser aplicadas às ferramentas pneumáticas operadas manualmente ou seguras com as mãos.
- Para segurança, máximo desempenho e máxima durabilidade das peças, opere esta ferramenta com uma pressão de ar máxima de 6,2 bar/620 kPa (90 psig) na entrada da mangueira de alimentação de ar com diâmetro interno de 10 mm (3/8").
- Desligue sempre a alimentação de ar e desconecte a mangueira de alimentação de ar antes de instalar, remover ou ajustar qualquer acessório nesta ferramenta, ou antes de executar qualquer serviço de manutenção nesta ferramenta.
- Não use mangueiras de ar ou adaptadores danificados, gastos ou deteriorados.
- Certifique-se de que todas as mangueiras e adaptadores sejam do tamanho correcto e estejam apertados com firmeza. Veja o Desenho TPD905-1 para um arranjo típico de tubagem.
- Use sempre ar seco e limpo com pressão máxima de 90 psig. Pó, fumos corrosivos e/ou humidade excessiva podem arruinar o motor de uma ferramenta pneumática.
- Não lubrifique as ferramentas com líquidos inflamáveis ou voláteis tais como querosene, diesel ou combustível de jactos.

USANDO A FERRAMENTA

- Use sempre óculos de protecção quando estiver operando ou executando serviço de manutenção nesta ferramenta.
- Use sempre protecção contra ruído ao operar esta ferramenta.
- Mantenha as mãos, partes do vestuário soltas e cabelos compridos afastados da extremidade em rotação.
- Antecipe e esteja alerta a mudanças repentinas no movimento quando ligar e operar qualquer ferramenta motorizada.
- Mantenha a posição do corpo equilibrada e firme. Não exagere quando operar esta ferramenta. Torques de reacção elevados podem ocorrer na ou abaixo da pressão de ar recomendada.
- Os acessórios da ferramenta podem continuar a girar brevemente após a pressão ter sido aliviada.
- Ferramentas accionadas pneumáticamente podem vibrar em uso. Vibração, movimentos repetitivos ou posições desconfortáveis podem ser prejudiciais às mãos e aos braços. Pare de usar a ferramenta caso ocorra algum desconforto, sensação de formigueiro ou dor. Procure assistência médica antes de retornar ao trabalho.
- Use acessórios recomendados pela Ingersoll-Rand.
- O Tampa da Válvula Reguladora de Pressão está sob pressão da Mola da Válvula. Tenha cuidado ao removê-lo. (Apenas em algumas ferramentas.)
- Esta Ferramenta não foi concebida para trabalhos em atmosferas explosivas.
- Esta Ferramenta não está isolada contra choques eléctricos.

AVISO

O uso de peças de substituição que não sejam genuinamente da Ingersoll-Rand podem resultar em riscos de segurança, diminuição do desempenho da ferramenta, aumento da necessidade de manutenção e pode invalidar todas as garantias.

As reparações devem ser feitas somente por pessoal treinado autorizado. Consulte o Centro de Serviços da Ingersoll-Rand mais próximo.

Envie Todos os Comunicados Para o Distribuidor ou Escritório da Ingersoll-Rand Mais Próximo.

© Ingersoll-Rand Company 2000


Impresso nos E.U.A.



IDENTIFICAÇÃO DO RÓTULO DE ADVERTÊNCIA

ADVERTÊNCIA

O NÃO CUMPRIMENTO DAS SEGUINTE ADVERTÊNCIAS PODE RESULTAR EM FERIMENTOS.

	ADVERTÊNCIA	Use sempre óculos de protecção quando estiver operando ou executando algum serviço de manutenção nesta ferramenta.
	ADVERTÊNCIA	Use sempre protecção contra o ruído ao operar esta ferramenta.
	ADVERTÊNCIA	Desligue sempre a alimentação de ar e desconecte a mangueira de alimentação de ar antes de instalar, remover ou ajustar qualquer acessório nesta ferramenta, ou antes de executar algum serviço de manutenção nesta ferramenta.
	ADVERTÊNCIA	Ferramentas accionadas pneumáticamente podem vibrar em uso. Vibração, movimentos repetitivos ou posições desconfortáveis podem ser prejudiciais às mãos e aos braços. Pare de usar a ferramenta caso ocorra algum desconforto, sensação de formigueiro ou dor. Procure assistência médica antes de retornar ao trabalho.
	ADVERTÊNCIA	Mantenha a posição do corpo equilibrada e firme. Não exagere quando operar esta ferramenta. Torques de reacção elevados podem ocorrer sob a pressão de ar recomendada.
	ADVERTÊNCIA	Opere com pressão do ar Máxima de 90 psig (6,2–6,9 bar).
Rótulo de Advertência Inter-nacional No. de Referência para Pedido _____		

COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

LUBRIFICAÇÃO



Ingersoll-Rand No. 10



Ingersoll-Rand No. 67

Use sempre um lubrificador de ar de linha com estas ferramentas. Nós recomendamos a seguinte Unidade Filtro-Lubrificador-Regulador:


USA – No. C11-03-G00

Para Internacional – No. C16-C3-A29

Para modelos com engrenagem D, H, J, JJ, K ou L, injecte cerca de 2 a 3 cc de Massa Lubrificadora

Ingersoll-Rand No. 67 no Adaptador de Massa na Caixa de Engrenagens depois de cada 50 000 ciclos ou 160 horas de operação, o que ocorrer primeiro.

Para modelos com engrenagem M, R ou S, injecte cerca de 3 a 4 cc de Massa Lubrificadora Ingersoll-Rand No. 67 no Adaptador de Massa na Caixa de Engrenagens depois de cada 50 000 ciclos ou 160 horas de operação, o que ocorrer primeiro.




(Desenho TPD905-1)

COLOCANDO A FERRAMENTA EM FUNCIONAMENTO

Modelo	Tipo de Punho	Capacidade de Encabadoiro		Velocidade Livre
		mm	pol.	
6ADST4	pistooli	6	1/4	20 000
6AHST4	pistooli	6	1/4	6 000
6AJST4	pistooli	6	1/4	5 100
6AJJST4	pistooli	6	1/4	3 950
6AKST4	pistooli	6	1/4	3 100
6ALST4	pistooli	6	1/4	2 150
6AMST6	pistooli	10	3/8	1 500
6ARST6	pistooli	10	3/8	500
6ASST6	pistooli	10	3/8	350

MAINTENANCE SECTION

MOTOR PARTS



(Dwg. TPB968)



PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING


	Motor Housing Assembly for 6ARST6-EU and 6ASST6-EU ... for all other models ending in -EU ... for 6ARST6 and 6ASST6 for all other models	6AR-EU-DST40 6AH-EU-DST40 6AR-DST40 6AH-DST40	◆ 13 ◆ 14 ◆ • 15 ◆ • 16 ◆ • 17 ◆ 18 19 20	Muffler Element for R or S ratio for all other ratios Muffler Element (for R or S ratios only) ... Rear End Plate Gasket Rear Rotor Bearing Retaining Nut Bearing Thrust Washer Rear Rotor Bearing Rear End Plate	3RA-310 4RA-310 7L-311 6WRT-739 6WT-118 6WT-117 DG20-22 6AH-12
*	Warning Label for all models ending in -EU for all other models	EU-99 WARNING-7-99			
1	Motor Housing for all models ending in -EU for all other models	6AH-EU-BST40 6AH-BST40		Rotor for D, H, J or M ratios (9 teeth) for JJ ratio (12 teeth) for K or R ratios (9 teeth) for L or S ratios (6 teeth)	6AH-53 6AJ-53 6AK-53 6AL-53
2	Trigger Bushing	4RA-91			
3	Trigger Assembly	7AH-A93			
4	Trigger Trigger Pin	5RA-93 7AH-94			
◆ 5	Throttle Valve Seat	7AH-303			
◆ 6	Throttle Valve	7AH-302			
◆ 7	Throttle Valve Spring	3RA-51	◆ 21	Vane Packet (set of 4 Vanes)	6WT-42-4
8	Inlet Bushing Assembly	7AH-A565	22	Cylinder	6AH-3
◆ • 9	Air Strainer Screen	R0A2-61	23	Front End Plate	6WT-11
10	Inlet Bushing Spacer	7AH-65	24	Front Rotor Bearing	R00H-97
11	Muffler Assembly	3RA-A123	25	Cylinder Dowel	6WT-98
◆ 12	Muffler O-ring	85H-167			

* Not illustrated.

◆ Indicates Tune-up Kit part.

• To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (•) for every four tools in service.

GEAR UNITS



(Dwg. TPA1363)

PART NUMBER FOR ORDERING			PART NUMBER FOR ORDERING		
26	Spindle Assembly for H ratio for JJ ratio for R or S ratio for K ratio for L ratio for M, D or J ratio	6AH-A8 6AJJ-A8 6AP-A8 6AK-A8 6AL-A8 6AM-A8	36	Gear Head Planet Gear Assembly (3) + for R ratio (20 teeth) + for S ratio (20 teeth) 37 Gear Head Planet Gear (for M ratio) (14 teeth) (3) 38 Gear Head Planet Gear Bearing (for M ratio) (3) Gear Case Assembly for D, H, JJ, J, K and L ratio models ending in -EU for all other D, H, JJ, J, K and L ratio models for M, R and S ratio models ending in -EU for all other M, R and S ratio models ..	6WTK-A10 6WTL-A10 6WTM-10 6WTM-500 6AH-EU-A37 6AH-A37 6AM-EU-A37 6AM-A37
27	Seal Support	5A-28			
28	Spindle Planet Gear Assembly (3) for JJ, R or S ratios (18 teeth) for J or M ratios (16 teeth) for K ratio (20 teeth) for L ratio (20 teeth)	6WTP-A10 6WTN-A10 6WTK-A10 6WTL-A10			
29	Spindle Planet Gear (for H ratio) (14 teeth) (3)	6WTM-10	36	Gear Case for D, H, JJ, J, K and L ratio models ending in -EU for all other D, H, JJ, J, K and L ratio models for M, R and S ratio models ending in -EU for all other M, R and S ratio models ..	6AH-EU-B37
30	Spindle Planet Gear Bearing (for H ratio) (3)	6WTM-500	40	Grease Fitting	D0F9-879
31	Gear Retainer	6LL-81	41	Spindle Bearing	5A-510
32	Rotor Pinion for H or M ratios (21 teeth) for J ratios (17 teeth)	6WTM-17 6WTN-17	◆ 42	Spindle Bearing Seal	6AH-103
33	Drive Plate (for D ratio)	6AD-171	43	Spindle Bearing Retainer	7L-28
34	Gear Head Spacer (for M, R or S ratios)	6LM-80	44	Grease Shield	5R-701
35	Gear Head for M ratio (marked M) for R ratio (marked R)	6LM-216 6LR-216A	◆ 45	Shield Retainer	6LL-343
	for S ratio (marked S)	6AS-216			

◆ Indicates Tune-up Kit part.

+ The gears used in both the No. 6WTL-A10 and No. 6WTK-A10 Planet Gear Assemblies have 20 teeth. The Gear (Part No. 6WTK-A10) can be distinguished by the annular groove through the middle of the tooth.

PART NUMBER FOR ORDERING		PART NUMBER FOR ORDERING	
46	Drill Chuck Spacer (2 for R or S ratios; 1 for all other ratios)	5A-90	51
47	Drill Chuck for D, H, JJ, J, K or L ratio (0 to 1/4" [0 to 6.0 mm] capacity)	R00A-99	52
	for M, R or S ratio (0 to 3/8" [0 to 10.0 mm] capacity)	6A-99	53
*	Chuck Key for R00A-99 chuck	R00A-J253	*
	for 6A-99 chuck	R0J-J253	*
48	Dead Handle Adapter (2)	6A-49	*
49	Dead Handle Assembly	R1A-A48	*
50	Pinch Bolt	510-638	Tune-up Kit (includes illustrated items 5, 6, 7, 9, 12, 13, 14, 15, 16, 17, 18, 21 and 42)
			6-DRILLS-TK1

* Not illustrated.

MAINTENANCE SECTION

⚠ WARNING

Always wear eye protection when operating or performing maintenance on this tool.

Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.

LUBRICATION

Each time a Series 6A Drill is disassembled for repair or replacement of parts, lubricate the tool as follows:

1. Moisten all O-rings with O-ring lubricant.
2. Work approximately 1.5 cc of Ingersoll-Rand No. 67 Grease into the Rear Rotor Bearing (18), Front Rotor Bearing (24) and the Spindle Bearing (41).
3. Work approximately 6 cc to 8 cc of Ingersoll-Rand No. 67 Grease into the D, H, J, JJ, K or L ratio gear train and 10 cc to 12 cc of Ingersoll-Rand No. 67 Grease into the M, R or S ratio gear train. Grease the Planet Gear Bearings (28, 30, 36 and 38), the gear teeth inside the Gear Case (39) and the planet gear shafts on the Spindle (26) and Gear Head (35).

DISASSEMBLY

General Instructions

1. Do not disassemble the tool any further than necessary to replace or repair damaged parts.
2. Whenever grasping a part in a vise, always use leather-covered or copper-covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members and housings.
3. Do not remove any part which is a press fit in or on a subassembly unless the removal of that part is necessary for repairs or replacement.
4. Do not disassemble the tool unless you have a complete set of new gaskets and O-rings for replacement.

Disassembly of the Gearing

1. For L, M, R or S ratio, loosen the Pinch Bolt (50) and remove the Dead Handle Assembly (49) and Handle Adapter (48).
2. Remove the Drill Chuck (47) by inserting the Chuck Key in one of the holes in the Chuck and tapping the Key sharply with a hammer.
3. Being careful not to distort the Motor Housing (1), grasp the flats on the Housing in leather-covered or copper-covered vise jaws with the Gear Case (40) facing upward.
4. Using a wrench on the flats of the Gear Case, loosen, but do not remove the Gear Case.

NOTICE

In the following step, be sure to hold the tool over a workbench so that you will not drop or lose parts.

5. Remove the tool from the vise and, while holding the tool horizontally, carefully unscrew the Gear Case and pull it away from the Motor Housing.
6. Using snap ring pliers, remove the Gear Retainer (31).
7. For D ratio, remove the Drive Plate (33).
8. For H, J, JJ, K or M ratio, the Rotor Pinion (32) may come out with the Gear Case, or it may have remained with the Rotor (20) when the Gear Case was removed. Remove the Rotor Pinion.
9. For R or S ratio, remove the Gear Head Planet Gear Assembly (36), Gear Head (35) and Gear Head Spacer (34).
For M ratio, remove the Gear Head Planet Gear (37), Gear Head Planet Gear Bearing (38), Gear Head (35) and Gear Head Spacer (34).
10. Remove the Spindle Planet Gear Assembly (28) or Spindle Planet Gear (29).
11. Push the Spindle from the Gear Case.
12. If it is necessary to remove the Spindle Bearing (41) from the front of the Gear Case, use a pair of internal snap ring pliers to remove the Spindle Bearing Retainer (43). Remove the Bearing Seal (42).
13. Do not remove the Spindle Bearing from the Gear Case unless it is absolutely necessary and you have a new bearing for replacement. If you must remove the bearing from the Gear Case, position the Gear Case vertically in an arbor press, internally threaded end facing upward. Using a 3/4" (19 mm) diameter brass rod against the bearing, press the Spindle Bearing from the Gear Case.
14. Tap the front end of the Gear Case on a workbench to remove the Grease Shield (44).
15. Remove the and Seal Support (27) from the Spindle.
16. If the Grease Shield Retainer (45) must be removed, insert a thin blade screwdriver under the tab, and rotary motion, spiral the Retainer out of the groove in the Gear Case.

Disassembly of the Motor

1. Grasp the splined end of the Rotor (20) in leather-covered or copper-covered vise jaws and pull the assembled motor from the Motor Housing (1).
2. Remove the Rear End Plate Gasket (15) from the Motor Housing.
3. Using a wrench, unscrew and remove the Rear Rotor Bearing Retaining Nut (16).
4. Remove the Rotor from the vise and remove the Bearing Thrust Washer (17), Rear End Plate (19), Cylinder (22) and Vanes (21).
5. Check the Front Rotor Bearing (24) for damage or roughness. If replacement is necessary, support the Front End Plate (23) between two blocks of wood on the table of an arbor press. Using a flat face punch on the inner ring, tap the Bearing out of the End Plate.

MAINTENANCE SECTION

Disassembly of the Pistol Grip Motor Housing

1. Carefully grasp the Motor Housing (1) in leather-covered or copper-covered vise jaws so that the handle is upward.
2. Unscrew and remove the Inlet Bushing Assembly (8).
3. Remove the Muffler Assembly (11) and Muffler O-ring (12) from the Muffler Assembly.
4. Withdraw the Air Strainer Screen (9), Throttle Valve Spring (7) and Throttle Valve (6) from the housing handle.
5. Withdraw the Trigger Assembly (3).
6. Remove the Muffler Element (13).
7. **For R or S ratios**, remove the Muffler Element (14).

NOTICE

In the following step, only remove the Throttle Valve Seat (5) when replacing it or when the Trigger Bushing (2) must be replaced.

8. To remove the Throttle Valve Seat, insert a wire hook through the central hole of the Seat and hooking the underside of the Seat, pull the Seat out of the Motor Housing.
9. Before removing the Trigger Bushing (2), all Seals and components must be removed from the Motor Housing.
 - a. Grasp the Motor Housing in copper-covered vise jaws with the Trigger Bushing upward.

CAUTION

In the following step, apply enough heat to warm the Housing, but do not exceed 200°F. Do not apply heat directly to the Skinsulate covering. Take all precautions necessary to avoid being burned during the following procedure.

- b. Using a torch, apply heat to the Motor Housing around the Bushing.
- c. Thread a 10-32 tap into the Bushing and pull the Bushing out of the Housing with the tap.

ASSEMBLY

General Instructions

1. Always press on the **inner** ring of a ball-type bearing when installing the bearing on a shaft.
2. Always press on the **outer** ring of a ball-type bearing when installing the bearing in a bearing recess.
3. Whenever grasping a tool or part in a vise, always use leather-covered or copper-covered vise jaws. Take extra care with threaded parts and housings.
4. Always clean every part and wipe every part with a thin film of oil before installation.

* Registered trademark of Loctite Corporation.

5. Apply a film of O-ring lubricant to all O-rings before final assembly.
6. Check every bearing for roughness. If an open bearing must be cleaned, wash it thoroughly in a suitable cleaning solution and dry with a clean cloth. **Sealed or shielded bearings should never be cleaned.** Work grease thoroughly into every open bearing before installation.

Assembly of the Pistol Grip Motor Housing

1. If the Trigger Bushing (2) was removed, proceed as follows:
 - a. Put a few drops of Loctite®* No. 601 Sealant on the end of a thin stick and insert the stick into the trigger bushing hole of the Motor Housing. Work the stick so that the Sealant flows against the shoulder inside the Housing.
 - b. Insert the Trigger Bushing into the Motor Housing (1) to a depth approximately one-half the length of the Bushing.
 - c. Put a few drops of Loctite No. 601 Sealant in the counterbore surrounding the outside diameter of the Bushing.
 - d. Rotate the Bushing approximately 180 degrees to make certain the Sealant makes complete contact around the outside of the Bushing.
 - e. Push the Bushing into the Housing until it bottoms against the shoulder inside the Housing.
 - f. Allow the Sealant to cure for eight hours at room temperature.
2. Carefully grasp the Motor Housing in leather-covered or copper-covered vise jaws, inlet end facing upward.
3. If the Throttle Valve Seat (5) was removed, use a flat-faced rod 1/2" (13 mm) in diameter by 3" (76 mm) long to push the Seat into the Motor Housing until it seats.
4. Press the Trigger (3) onto the grooved end of the Trigger Pin so that it is at right angles to the hole in the opposite end of the Pin.
5. Insert the Trigger Assembly into the Trigger Bushing so that the hole in the Trigger Pin aligns dead center with the hole in the Throttle Valve Seat.
6. **For R and S ratios**, work the Muffler Element (14) into the exhaust cavity in the handle of the Motor Housing.
7. Fold or roll the Muffler Element (13) and work it into the exhaust cavity in the handle of the Motor Housing.
8. Using needle nose pliers to hold the short stem end of the Throttle Valve (6), install the Valve inserting the long stem end through the hole in the Throttle Valve and Trigger Pin.

MAINTENANCE SECTION

9. Place the Air Strainer Screen (9), closed end first, inside the large end coil of the Throttle Valve Spring (7).
10. Insert the Throttle Valve Spring and Screen, small coil end first, so that the Spring encircles the end of the Throttle Valve.
11. Apply a thin coat of O-ring lubricant to the Muffler O-ring (12) and install the O-ring on the hub of the Muffler (11).
12. Install the Inlet Bushing Spacer (10) in the large hole in the Muffler Assembly (11).
13. Place the Muffler Assembly on the face of the handle so that the hub with the Muffler O-ring extends into the handle.
14. Thread the Air Inlet Bushing (8) into the large hole in the Muffler Assembly. Tighten the Bushing to a minimum of 26 ft-lb (35 Nm) torque.

Assembly of the Motor

1. If the Rear Rotor Bearing (18) was removed, use a sleeve that contacts the outer ring of the Rear Rotor Bearing and press the Rear Rotor Bearing into the Rear End Plate (19).
2. Place the Rear End Plate, bearing end trailing, on the threaded hub of the Rotor (20). Insert a 0.001" feeler gauge or shim between the face of the Rotor and End Plate. Place the Bearing Thrust Washer (17) on the threaded hub of the Rotor. Thread the Rear Rotor Bearing Retaining Nut (16) onto the hub of the Rotor and tighten it until the feeler gauge has a slight drag during removal. Remove the feeler gauge.

NOTICE

The Rotor must spin freely while holding the End Plate.

3. Lightly grasp the threaded hub of the Rotor in leather-covered or copper-covered vise jaws with the splined hub upward.
4. Wipe each Vane (21) with a film of light oil and place a Vane in each slot in the Rotor.
5. Looking down the axis of the Rotor and Cylinder (39), position the Cylinder over the Rotor with the cylinder dowel hole at twelve o'clock, the notch in cylinder face at ten o'clock and the two slots in the side of the Cylinder at two o'clock. Place the Cylinder down over the Rotor and Vanes and against the Rear End Plate.
6. Push the Front Rotor Bearing (24) into the recess in the Front End Plate (23).

NOTICE

Before pressing the Bearing onto the rotor shaft in the next step, align the cylinder dowel hole in the Rear End Plate, Cylinder and Front End Plate.

After pressing the Bearing onto the shaft, lightly rap the end of the splined hub with a plastic hammer to relax the load on the Bearing. The Rotor must rotate in the Bearing without drag.

7. Remove the assembled Rotor from the vise and using a sleeve that contacts the inner ring of the Front Rotor Bearing, press the Bearing, flat side of the Front End Plate first, onto the rotor shaft.
8. Position the Rear End Plate Gasket (15) in the bottom of the motor housing bore so that the dowel hole and air inlet port in the Gasket align with the dowel hole and air inlet in the housing bore face.
9. Using an assembly dowel 3/32" in diameter by 10" long (2.3 mm x 254 mm), align the dowel holes in the Front End Plate, Cylinder and Rear End Plate. Insert the assembly rod through the aligned holes so that about 3" (76 mm) of the rod extends beyond the Rear End Plate. Insert the extension into the dowel hole at the bottom of the housing bore, and slide the motor into the Motor Housing until it seats.
10. Withdraw the assembly dowel and insert the Cylinder Dowel (25) until the Cylinder Dowel is slightly below the surface of the Front End Plate.

Assembly of the Gearing

1. Stand the Gear Case (39), end with the flats upward, on a workbench.
2. If the Shield Retainer (45) was removed, install it in the second groove below the front face of the Gear Case.
3. Place the Grease Shield (44) in the Gear Case so that it butts against the Shield Retainer.
4. Using a sleeve that contacts the outer ring of the Bearing, press the Spindle Bearing (41) into the Gear Case until it butts against the Grease Shield. Install the Spindle Bearing Seal (42).
5. Using snap ring pliers, install the Spindle Bearing Retainer (43) against the Bearing Seal and into the groove in front of the Spindle Bearing.
6. Turn the Gear Case over so that the internal threaded end faces upward.
7. Install the Seal Support (27), large end first, over the hub of the Spindle (26).
8. Slide the Spindle into the Gear Case, threaded end first, until the Seal Support contacts the inner ring of the Spindle Bearing.
9. **For D ratio**, align the three holes in the Drive Plate (33) with the spindle pins and install the Drive Plate on the pins of the Spindle.
10. **For H Ratio**, push the Spindle Planet Gear Bearings (30) into the Spindle Planet Gears (29). Grease the assembled Spindle Planet Gears and Bearings and install them on the pins of the Spindle.
11. **For J, JJ, K, L, M, R or S ratio**, grease the bearings and gears of the Spindle Planet Gear Assemblies (28) and install them on the pins of the Spindle.

MAINTENANCE SECTION

12. **For M, R or S ratio,** install the Gear Head Spacer (34) in the Gear Case against the Spindle Planet Gears.
13. **For M, R or S ratio,** grease the splined hub of the Gear Head (35) and insert it into the Gear Case. The splined hub must pass through the Gear Head Spacer and mesh with the teeth of the Spindle Planet Gears.
14. **For M ratio,** push the Gear Head Planet Gear Bearings (38) into the Gear Head Planet Gears (37). Grease the assembled Gear Head Planet Gears and Bearings and install them on the pins of the Gear Head.
15. **For R or S ratio,** grease the bearings and gears of the Gear Head Planet Gear Assemblies (36) and install them on the pins of the Gear Head.
16. **For H or J ratio,** grease the Rotor Pinion (32) and install it in the center of the Spindle Planet Gears. Make certain the teeth of the Pinion and Planet Gears mesh.
For M ratio, grease the Rotor Pinion (32) and install it in the center of the Gear Head Planet Gears. Make certain the teeth of the Pinion and Planet Gears mesh.
17. Using snap ring pliers, install the Gear Retainer (31) in the shallow internal groove in the Gear Case behind the Drive Plate, Spindle Planet Gears or Gear Head Planet Gears.
18. Thread the assembled Gear Case onto the assembled Motor Housing until it is hand tight. Make certain the gear teeth on the Spindle mesh with the gear teeth of the Rotor Pinion, Gear Head Planet Gears or Spindle Planet Gears.

NOTICE

After hand tightening the Gear Case, run the motor at free speed on low air pressure while final tightening the Gear Case. Listen while tightening to make certain the gears mesh properly.

19. Tighten the Gear Case between 30 and 35 ft-lb (41 and 47 Nm) torque.
20. **For D, H, J, JJ, K or L ratio,** install one Drill Chuck Spacer (46) onto the drill spindle.
For M, R or S ratio, install two Drill Chuck Spacers (46) onto the drill spindle.
21. Thread the Drill Chuck (47) onto the drill spindle and tighten.
22. **For L, M, R or S ratio,** install the Dead Handle Adapter (48) and Dead Handle Assembly (49) onto the front end of the Gear Case. Tighten the Pinch Bolt (50) between 10 and 20 in. lb (1.4 and 2.3 Nm) torque.

TROUBLESHOOTING GUIDE

Trouble	Probable Cause	Solution
Loss of Power	Low air pressure	Check air supply. For top performance, the air pressure must be 90 psig (6.2 bar/620 kPa).
	Plugged Air Strainer Screen or Inlet Screen	Clean the Air Strainer or Screen in a clean, suitable cleaning solution. If the Screen cannot be cleaned, replace it.
	Clogged Muffler or Exhaust Silencer	Clean the Muffler Element in a clean, suitable cleaning solution. If it cannot be cleaned, replace it.
	Worn or broken Vanes	Replace a complete set of Vanes.
	Damaged Rear End Plate Gasket	Install a new Rear End Plate Gasket.
	Worn or broken Cylinder	Replace the Cylinder if it is cracked or if the bore appears wavy or scored.
	Improper lubrication or dirt build-up	Clean the Motor Unit parts and lubricate them as instructed.
Leaky Throttle Valve	Worn Throttle Valve and/or Throttle Valve Seat	Install a new Throttle Valve and/or Throttle Valve Seat.
	Dirt accumulation on Throttle Valve and/or Throttle Valve Seat	Pour about 3 cc of a clean, suitable cleaning solution into the air inlet and operate the tool for about 30 seconds. Immediately , pour 3 cc of the recommended oil into the air inlet and operate the tool for 30 seconds to lubricate all the cleaned parts.
Gear Case gets hot	Excessive grease	Clean and inspect Gear Case and gearing parts and lubricate as instructed.
	Worn or damaged parts	Clean and inspect the Gear Case and Gearing. Replace worn or broken components.

NOTICE

SAVE THESE INSTRUCTIONS. DO NOT DESTROY.

