



## INSTRUCTIONS FOR MODELS 2904P1, 2904P2 and 2904P4 IMPACTTOOLS

### NOTICE

Models 2904P1, 2904P2 and 2904P4 Impacttools are designed for use in general maintenance and production applications. Ingersoll–Rand is not responsible for customer modification of tools for applications on which Ingersoll–Rand was not consulted.



### ⚠ WARNING

**IMPORTANT SAFETY INFORMATION ENCLOSED.  
READ THIS MANUAL BEFORE OPERATING TOOL.**

**IT IS THE RESPONSIBILITY OF THE EMPLOYER TO PLACE THE INFORMATION  
IN THIS MANUAL INTO THE HANDS OF THE OPERATOR.**

**FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.**

#### PLACING TOOL IN SERVICE

- Always operate, inspect and maintain this tool in accordance with all regulations (local, state, federal and country), that may apply to hand held/hand operated pneumatic tools.
- For safety, top performance, and maximum durability of parts, operate this tool at 90 psig (6.2 bar/620 kPa) maximum air pressure at the inlet with 3/8" (10 mm) inside diameter air supply hose.
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.
- Do not use damaged, frayed or deteriorated air hoses and fittings.
- Be sure all hoses and fittings are the correct size and are tightly secured. See Dwg. TPD905–1 for a typical piping arrangement.
- Always use clean, dry air at 90 psig maximum air pressure. Dust, corrosive fumes and/or excessive moisture can ruin the motor of an air tool.
- Do not lubricate tools with flammable or volatile liquids such as kerosene, diesel or jet fuel.
- Do not remove any labels. Replace any damaged label.
- The use of a hose whip is recommended. A coupler connected directly to the air inlet increases tool bulk and decreases tool maneuverability.
- For maximum performance, the coupler on the wall should be the next size larger than the coupler used on the tool. The coupler closest to the tool should not be less than the proper air supply hose size.

#### USING THE TOOL

- Always wear eye protection when operating or performing maintenance on this tool.
- Always wear hearing protection when operating this tool.
- Keep hands, loose clothing and long hair away from rotating end of tool.
- Note the position of the reversing lever before operating the tool so as to be aware of the direction of rotation when operating the throttle.
- Anticipate and be alert for sudden changes in motion during start up and operation of any power tool.
- Keep body stance balanced and firm. Do not overreach when operating this tool. High reaction torques can occur at or below the recommended air pressure.
- Tool shaft may continue to rotate briefly after throttle is released.
- Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.
- Use accessories recommended by Ingersoll–Rand.
- Use only impact sockets and accessories. Do not use hand (chrome) sockets or accessories.
- Impact wrenches are not torque wrenches. Connections requiring specific torque must be checked with a torque meter after fitting with an impact wrench.
- This tool is not designed for working in explosive atmospheres.
- This tool is not insulated against electric shock.

### NOTICE

The use of other than genuine Ingersoll–Rand replacement parts may result in safety hazards, decreased tool performance, and increased maintenance, and may invalidate all warranties.

Repairs should be made only by authorized trained personnel. Consult your nearest Ingersoll–Rand Authorized Servicenter.

Refer All Communications to the Nearest  
Ingersoll–Rand Office or Distributor.

© Ingersoll–Rand Company 2000

Printed in U.S.A.

**INGERSOLL-RAND®**  
**PROFESSIONAL TOOLS**

# WARNING LABEL IDENTIFICATION



FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.

	<b>⚠ WARNING</b>
	Always wear eye protection when operating or performing maintenance on this tool.

	<b>⚠ WARNING</b>
	Always wear hearing protection when operating this tool.

	<b>⚠ WARNING</b>
	Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.

	<b>⚠ WARNING</b>
	Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before re-suming use.

	<b>⚠ WARNING</b>
	Do not carry the tool by the hose.

	<b>⚠ WARNING</b>
	Do not use damaged, frayed or deteriorated air hoses and fittings.

	<b>⚠ WARNING</b>
	Keep body stance balanced and firm. Do not overreach when operating this tool.

	<b>⚠ WARNING</b>
	Operate at 90 psig (6.2 bar/620 kPa) Maximum air pressure.


## USING THE POWER MANAGEMENT SYSTEM



Air wrenches are not torque control devices. Fasteners with specific torque requirements must be checked with suitable torque measuring devices after installation with an air wrench.

Models 2904P1, 2904P2 and 2904P4 Impacttools incorporate a Power Management System that allows the operator to select four power output settings. These settings range from minimum power output through maximum power output in the forward direction only. **The Air Wrench will always operate at maximum power output in the reverse direction, no matter what power output level is selected.**

### MODEL 2904P POWER MANAGEMENT SYSTEM



(Dwg. TPD1339)



The four power setting indicators of increasing size on the rear of the housing indicate increasing power output levels, are for reference only and **DO NOT** denote a specific power output. The smallest power setting indicator designates minimum power output, the two middle power setting indicators denote medium power outputs and the largest power setting indicator denotes maximum power output.

The power output can be further reduced in forward or reverse by using the variable throttle. Air supply systems which do not deliver adequate air pressure can affect power output at all settings.

# PLACING TOOL IN SERVICE

## LUBRICATION



Ingersoll-Rand No. 50



**Ingersoll-Rand No. 115-1LB** for routine external lubrication of the impact mechanism through the Hammer Case Grease Fitting.


Use **Ingersoll-Rand No. 105-1LB** or **Ingersoll-Rand 105-8LB** when disassembling and assembling the impact mechanism.

Always use of an air line lubricator with these tools. We recommend the following Filter-Lubricator-Regulator Unit:


**For USA – No. C18-03-FKG0-28**  
**For International – C18-C3-FKG0**

## CAUTION

Do not mark any nonmetallic surface on this tool with customer identification codes. Such actions could affect tool performance.



(Dwg. TPD905-1)



(Dwg. TPD1674-2)


# PLACING TOOL IN SERVICE

## SPECIFICATIONS

Model	Type of Handle	Drive	Impacts per min.	Recommended Torque Range	
				Forward ft-lb (Nm)	Reverse ft-lb (Nm)
2904P1	pistol grip	3/8"	1,500	25–200 [230 Max.] (34–272 [312 Max.] )	230 [260 Max.] (312 [352 Max.] )
2904P2	pistol grip	1/2"	1,500	25–190 [220 Max.] (34–258 [298 Max.] )	220 [250 Max.] (298 [339 Max.] )
2904P4	pistol grip	1/4" hex Q.C.	1,500	25–200 [230 Max.] (34–272 [312 Max.] )	230 [260 Max.] (312 [352 Max.] )

Model	■ Sound Level dB (A)		◆ Vibrations Level
	Pressure	Power	m/s <sup>2</sup>
2904P1	94.9	107.9	3.1
2904P2	93.7	106.7	3.1
2904P4	94.9	107.9	3.1

- Tested in accordance with PNEUROP PN8NTC1.2
- ◆ Tested to ISO8662–7 loaded with frictionbrake to 9 RPM



**DECLARATION OF CONFORMITY**

We   **Ingersoll-Rand, Co.**    
*(supplier's name)*


  **78192 Trappes Cedex France**    
*(address)*


*declare under our sole responsibility that the product,*  
  **Models 2904P1, 2904P2 and 2904P4 Impactools**  

*to which this declaration relates, is in compliance with the provisions of*  
  **98/37/EC**   Directives.

*By using the following Principle Standards:*                   **ISO8662, PNEUROP PN8NTC1**                  

*Serial No. Range*                   **(1999 → ) A99G XXXXX →**                  

      
*D. Vose*  
*Name and signature of authorised persons*

      
*Kevin R. Morey*  
*Name and signature of authorised persons*


  **April, 2000**    
*Date*

  **April, 2000**    
*Date*

**NOTICE**

**SAVE THESE INSTRUCTIONS. DO NOT DESTROY.**

**When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.**



**MAINTENANCE SECTION**



PART NUMBER FOR ORDERING →

PART NUMBER FOR ORDERING →

	1	Cylinder . . . . .	2112-3			Inlet Bushing Assembly . . . . .	2131-A565
	2	Front End Plate . . . . .	2112-11		20	Inlet Bushing . . . . .	2131-565
◆	3	Front Rotor Bearing . . . . .	2131-97	◆	21	Inlet Bushing	
◆	3A	Rear Rotor Bearing . . . . .	R00H-97			Screen . . . . .	5RA-61
◆●	4	Vane Packet (set of 6 Vanes) . . . . .	2112-42-6	◆	22	Inlet Parts Kit . . . . .	2131-K303
	5	Rotor . . . . .	2112-53		22A	Washer . . . . .	_____
◆	6	Rear Rotor Bearing Retainer . . . . .	4E-6	◆	22B	Inlet Bushing Seal . . . . .	_____
#◆◆	7	Motor Gasket . . . . .	2112-283		22C	Tilt Valve Spring . . . . .	_____
+	8	Hammer Case Screw (4) . . . . .	2112-638		22D	Tilt Valve . . . . .	_____
		Hammer Frame Assembly . . . . .	2112-A703		22E	Tilt Valve Seat . . . . .	_____
	9	Hammer Frame . . . . .	2112-703		22F	Tilt Valve Seat . . . . .	_____
	10	Hammer Pin (2) . . . . .	2112-704			Support . . . . .	_____
+	11	Hammer (2)			22G	Tilt Valve Seat Retainer . . . . .	_____
		for 2904P1 and 2904P4 . . . . .	2112-724		23	Inlet Retainer Clip . . . . .	2131-57
		for 2904P2 . . . . .	2904P-724	●	24	Trigger Assembly . . . . .	2131-A93
	12	Hammer Case Assembly . . . . .	2112-727	#◆	25	Trigger O-ring . . . . .	_____
	13	Hammer Case			26	Reverse Valve Assembly . . . . .	2131-A329
		Bushing . . . . .	2112-641	#◆	27	Reverse Valve O-ring (top) . . . . .	_____
	15	Grease Fitting . . . . .	D0F9-879	#◆	28	Reverse Valve O-ring	
#◆◆+	16	Hammer Case Gasket . . . . .	2112-36			(bottom) (blue) . . . . .	_____
	17	Housing Assembly . . . . .	2112-A40		29	Button Kit . . . . .	2112-K75
	18	Housing Label . . . . .	2112-99		30	Forward Button . . . . .	_____
	18A	Warning Label . . . . .	WARNING-2-99		31	Reverse Button . . . . .	_____
	19	Nameplate			32	Power Management Dial . . . . .	2112-A249
		for 2904P1 . . . . .	2904P1-301	#◆	33	Power Management	
		for 2904P2 . . . . .	2904P2-301			Dial Seal . . . . .	2112-248
		for 2904P4 . . . . .	2904P4-301				

- ◆ Indicates Tune-up Kit part.
- + Indicates Hammer Kit part.
- # Indicates Seal Kit part.
- To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (●) for every four tools in service.

MAINTENANCE SECTION

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

34	Inlet Clip Removal Tool .....	2131-322	*	Grease (for lubrication when disassembling and assembling the impact mechanism)	
	Anvil Assembly (for 2904P1) .....	2112P-A626		1 lb .....	105-1LB
35	Anvil .....	2112P-626		8 lb .....	105-8LB
◆36	Socket Retainer .....	5020-716		Protective Cover .....	2112-P32
◆37	Socket Retainer Spring .....	401-718		Grease Gun .....	R000A2-228
	Anvil Assembly (for 2904P2) .....	2112P-A726	*	Seal Kit (includes illustrated items 7, 16, 22B, 25, 27, 28 and 33) .....	2112-K36
38	Anvil .....	2112P-726	*	Tune-up Kit (includes illustrated items 3, 3A, 4, 6, 7, 16, 21, 22, 25, 27, 28, 33, 36 and 37) .....	2904P-TK2
39	Socket Retainer .....	804-716	*	Hammer Kit (for 2904P1) (includes illustrated items 8 [4], 11 [2], 16, and Anvil Assembly part number 2112P-A626) .....	2904P1-THK1
40	Socket Retainer Spring .....	5UHD-718	*	Hammer Kit (for 2904P2) (includes illustrated items 8 [4], 11 [2], 16 and Anvil assembly part number 2112P-A726) .....	2904P2-THK1
	Anvil Assembly (for 2904P4) (Quick Change) .....	2112-A926-4			
41	Quick Change Anvil .....	2112-926-4			
42	Thrust Ring Lock .....	5C1-853	*		
43	Thrust Ring .....	I0A902A2-932-4			
44	Retaining Sleeve Spring .....	2U-931-4			
45	Retaining Ball .....	2U-696			
46	Retaining Sleeve .....	2U-930-4	*		
47	Retaining Sleeve Stop .....	2U-933-4			
48	Hanger .....	2112-366			
*	Grease (1 lb) (for external lubrication of the impact lubrication of the impact mechanism) .....	115-1LB			

\* Not illustrated.

◆ Indicates Tune-up Kit part.



## MAINTENANCE SECTION

### DISASSEMBLY

#### General Instructions

1. Do not disassemble the tool any further than necessary to replace or repair damaged parts.
2. Whenever grasping a tool or part in a vise, always use leather-covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members and housings.

#### NOTICE

**Always use leather-covered vise jaws when clamping the handle in a vise. Leather will conform to the shape of the handle and allow the tool to be held securely. To prevent damage to the exhaust diffuser, never clamp only the bottom of the handle.**

3. Do not remove any part which is a press fit in or on a subassembly unless the removal of that part is necessary for repairs or replacement.
4. Do not disassemble the tool unless you have a complete set of new gaskets and O-rings for replacement.

#### Disassembly of the Impact Wrench

1. Clamp the handle of the impact wrench in a vise with leather-covered jaws with the square drive positioned horizontally.

#### NOTICE

**Avoid excessive clamping pressure which can damage the Housing and can cause difficulty when removing the parts.**

2. Unscrew and remove the four Hammer Case Screws (8).
3. While lightly tapping on the end of the Anvil (35, 38 or 41) with a plastic hammer, lift off the Hammer Case (12) and Hammer Case Gasket (16).

#### NOTICE

**The Front End Plate (2) might come off during the removal of the Hammer Case. Make sure that it does not drop on the floor or strike a hard or metallic surface since it might be damaged.**

4. Grasp the Hammer Frame (9) and carefully lift off the entire impact mechanism, making certain not to drop the two Hammer Pins (10).

#### Disassembly of the Square Drive Anvil

##### Model 2904P1 and 2904P2

1. Use a hooked wire to pull the Socket Retainer Spring (37 or 40) out of the end of the Anvil (35 or 38).
2. Remove the Socket Retainer (36 or 39).

##### Disassembly of the Quick-Change Anvil

##### Model 2904P4

1. Remove the Retaining Sleeve Stop (47).

#### NOTICE

**The Retaining Ball (45) will fall free when the Retaining Sleeve (46) is removed.**

2. Remove the Retaining Sleeve, Retaining Ball, Retaining Sleeve Spring (44), Thrust Ring (43) and Thrust Ring Lock (42).

#### Disassembly of the Impact Mechanism

1. Set the mechanism, driver end up, on the workbench.

#### NOTICE

**Note the twin hammers within the Hammer Frame. These are identical, but must be placed in the Hammer Frame in a certain relationship. Using a felt-tipped pen, mark the top “T↑” hammer and the bottom hammer “B↑” with the arrows pointing upward. Mark both Hammers on the same end.**

2. With the mechanism sitting upright on the workbench, slowly rotate the Anvil in a clockwise direction until it comes up solid.

#### NOTICE

**If you continue to rotate the Anvil, it will cam the Hammers out of engagement. Don't do this; merely rotate the Anvil until it comes up solid.**

3. Hold the Hammer Frame firmly and without disturbing the hammers, gently lift the Anvil while simultaneously rotating it clockwise about 1/8 of a turn, from the Hammer Frame.
4. With the Anvil removed, lift out the two Hammer Pins.

#### NOTICE

**The twin hammers are now free to slide from the Hammer Frame. Be careful do not to drop them.**


## MAINTENANCE SECTION

### Disassembly of the Motor

#### NOTICE

When pulling, disassembling or assembling the motor, we recommend replacement of the Motor Gasket (7).

1. Remove the Motor Assembly from the Housing (17) by pushing on the Power Management Dial (32) from the back of the Housing. Refer to Dwg. TPDD1322.



(Dwg. TPD1322)

#### NOTICE

If the Motor Assembly cannot be removed from the Housing by pushing, tap the Power Management Dial lightly until the Motor Assembly is free.


2. Remove the Power Management Dial from the rear of the Cylinder (1). Remove the Power Management Dial Seal (33) if it needs to be replaced.
3. Remove the Front End Plate (2) from the Cylinder by tapping the splined end of the Rotor (5) with a plastic hammer.

#### NOTICE

To prevent damage to the Cylinder, do not tap or strike Cylinder on a hard or metallic surface when removing the Rotor Bearings (3) and (3A).


To remove the Front Rotor Bearing, hold the Front End Plate with Front Rotor Bearing down and tap the Front End Plate on a flat, nonmetallic surface such as

a work bench. This will loosen the Front Rotor Bearing so that it will drop out of the Front End Plate. Refer to Dwg. TPD1323.



(Dwg. TPD1323)

4. Remove the Rear Rotor Bearing Retainer (6) from the rear of the Rotor (5). The Rotor can now be removed from the Cylinder. Remove the Vanes (4) from the Rotor if they need to be replaced.



(Dwg. TPD1324)

5. To remove the Rear Rotor Bearing, hold the Cylinder with the Rear Rotor Bearing down and tap the Cylinder on a flat, nonmetallic surface such as a work bench. This will loosen the Rear Rotor Bearing so that it will drop out of the Cylinder. Refer to Dwg. TPD1324.
6. Working from the rear of the Housing, push out the Motor Gasket (7).

#### NOTICE


When removing the Motor Gasket, do not use a screwdriver or any other sharp object which could damage the Gasket and/or Housing.

## MAINTENANCE SECTION

### Disassembly of the Throttle Mechanism


#### NOTICE

For ease of disassembly, we recommend using the Inlet Clip Removal Tool (34). Refer to Dwg. TPD1681.



(Dwg. TPD1681)


1. Secure the Inlet Bushing in a vise. Press in both tabs of the Inlet Retainer Clip (23) and pull upward on the Housing (17). This will allow the Inlet Bushing to come free from the Handle of the Housing. Refer to Dwg. TPD1326.
2. Pull the Trigger (24) from the front of the Housing and remove the Trigger O-ring (25).



(Dwg. TPD1326)

3. With the Inlet Bushing still in the vise, remove the Tilt Valve Seat Retainer (25G) and Tilt Valve Seat Support (25F). Use a hooked tool with no sharp edges

to remove the Tilt Valve Seat (25E) from the Inlet Bushing. Refer to Dwg. TPD1327.



(Dwg. TPD1327)

4. Remove the Tilt Valve (25D) and Tilt Valve Spring (25C) if damaged.
5. Remove the Inlet Bushing Seal (25B) and Inlet Retainer Clip (23) if damaged. Remove Washer (25A).

#### NOTICE

**Do not remove the Inlet Bushing Screen (21) from the Inlet Bushing unless it is damaged. Clean the Inlet Bushing Screen by using a suitable cleaning solution in a well ventilated area.**


### Disassembly of the Reverse Valve Mechanism

#### NOTICE

**The Reverse Valve Assembly cannot be removed without first removing the Forward and Reverse Buttons (30) and (31). Therefore, it is important that the procedure below be followed exactly.**

1. Notice the notches on either side of the partition. These notches indicate the correct location for insertion of a thin-bladed screwdriver used for removing the Forward and Reverse Buttons. Insert the screwdriver between the partition and the Button which is fully extended. **Gently** pry against the Button to disengage the detent so that the Button can be removed. After the Button is removed, reach inside the Housing and rotate the Reverse Valve to extend the remaining Button. Repeat the above procedure for the remaining Button. Refer to Dwg. TPD1328.


## MAINTENANCE SECTION



REMOVAL OF FORWARD/ REVERSE BUTTONS

(Dwg. TPD1328)

2. Insert thumb into the front of the Housing and push **down** on the Reverse Valve so that it can be removed through the bottom of the handle. Refer to Dwg. TPD1329.



REVERSE VALVE

(Dwg. TPD1329)

### NOTICE

Do not try to remove the Reverse Valve by pushing upward. It can only be removed by pushing it downward and out of the bottom of the handle. If the Reverse Valve does not come free, tap the bottom of the handle lightly with a rubber hammer until it drops out.

3. Remove the Top Reverse Valve O-ring (27) and the Bottom Reverse Valve O-ring (28) from the Reverse Valve.

## ASSEMBLY

### General Instructions

1. Whenever grasping a tool or part in a vise, always use leather-covered vise jaws to protect the surface of the part and help prevent distortion. This is particularly true of threaded members and housings.

### NOTICE

Always use leather-covered vise jaws when clamping the handle in a vise. Leather will conform to the shape of the handle and allow the tool to be held securely. To prevent damage to the

exhaust diffuser, never clamp only the bottom of the handle.

2. Always clean every part and wipe every part with a thin film of oil before installation.

### NOTICE


Do not remove grease from the impact mechanism or Hammer Case (12). If the impact mechanism has not been disassembled, inject Ingersoll-Rand No. 115-1LB Grease through the Hammer Case Grease Fitting (15).

When disassembling and assembling the impact mechanism, remove all grease from the impact mechanism and Hammer Case and lubricate the impact mechanism and Hammer Case Bushing (13) with Ingersoll-Rand No. 105-1LB Grease or Ingersoll-Rand No. 105-8LB Grease.

3. Apply a film of o-ring lubricant to all O-rings before final assembly.


### Assembly of the Reverse Valve Mechanism

1. Install the Bottom Reverse Valve O-ring (28) (color-coded blue) and the Top Reverse Valve bring (27) on the Reverse Valve (26).
2. Insert the Reverse Valve in the bottom of the handle making sure that two ears on the Reverse Valve are facing downward. Refer to Dwg. TPD1330.



(Dwg. TPD1330)

Use a wooden dowel to push the Reverse Valve up through the handle **until the top of the Reverse Valve is flush with or slightly above the bottom of the motor bore in the Housing** (17). Refer to Dwg. TPD1331.




(Dwg. TPD1331)

## MAINTENANCE SECTION

### NOTICE

If the Reverse Valve is pushed up too far and becomes wedged, it will have to be pushed back down through the handle and re-inserted from the bottom of the handle. The Reverse Valve cannot be removed by pushing it up through the handle and into the motor bore. If the Reverse Valve must be removed and re-installed, make sure that the Top and Bottom Reverse Valve O-rings have not been rolled off and are in their proper positions on the Reverse Valve.

3. When the Reverse Valve has been installed, rotate the Reverse Valve so that the tab on the Reverse Valve is at the rear of the Housing. Refer to Dwg. TPD1332.




(Dwg. TPD1332)

### NOTICE


**If the orientation of the Reverse Valve is not correct (tab facing the the rear of the Housing), the Trigger (28) and the Forward and Reverse Buttons (4A) and (4B) cannot be installed.**

4. Install the Trigger O-ring (25) on the Trigger. Insert the Trigger Assembly in the front of the Housing.
5. Rotate the Reverse Valve in either direction until an ear comes up against the Trigger.
6. Look through the Housing from the rear. If the tab on the Reverse Valve has been rotated to the left, install the right Button in the Housing. When one Button has been installed, push the Button in. This will rotate the Reverse Valve so that the other Button can be installed. Refer to Dwg. TPD1333.



(Dwg. TPD1333)

If the tab on the reverse Valve has been rotated to the right, install the left Button. Refer to Dwg. TPD1334.



(Dwg. TPD1334)

### NOTICE


**If the Forward/Reverse Buttons will not install easily, move the Reverse Valve slightly higher in the handle to provide better alignment with the Buttons.**

7. After the Forward/Reverse Buttons have been installed, remove the Trigger before proceeding with installation of the throttle mechanism.

### Assembly of Throttle Mechanism

1. Using an Inlet Bushing Screen Installation Tool, install the Inlet Bushing Screen (21), screened end first, in the bottom (hex end) of the Inlet Bushing (20). Insert the rounded end of the tool in the cone formed by the screen and tap the end of the tool to secure the rim of the screen in the Bushing. Refer to Dwg. TPD1473.

#### Inlet Bushing Screen Installation Tool



(Dwg. TPD1473)

2. Install the Washer (25A), Inlet Retainer Clip (23), Inlet Bushing Seal (25B), Tilt Valve Spring (25C), Tilt Valve (25D) Tilt Valve Seat (25E) and Tilt Valve Seat Support (25F).

## MAINTENANCE SECTION

### ⚠ WARNING

The Tilt Valve Seat Retainer (25G) must be properly installed in the groove in the Inlet Bushing (20). To check for correct installation of the Retainer, insert a pin into one of the holes in the Retainer and rotate the Retainer. A correctly installed Retainer will rotate freely but with some resistance in the groove of the Inlet Bushing. An incorrectly installed Retainer will pop out of the Inlet Bushing when the Retainer is rotated.

### ⚠ WARNING

Do not use compressed air to check installation of the Tilt Valve Seat Retainer or Inlet Bushing Screen unless the entire Inlet Bushing Assembly is installed in the tool with the Hammer Case installed and properly secured to the Motor Housing. Failure to do so could result in injury. Install the Tilt Valve Seat Retainer.

### NOTICE

When re-installing the Inlet Bushing Assembly (20), pull the Trigger (24) outward and make sure that the Reverse Button (31) is depressed before snapping the Inlet Bushing Assembly back into the Housing.

3. Install the Inlet Bushing Assembly by pushing it into the hole in the Housing until you see and hear the tabs on Inlet Retainer Clip snap into place through the slots in Housing handle.

### NOTICE

The Reverse Button (left) (31) must be pushed in before the Trigger can be installed. Otherwise, the Trigger will be damaged during installation.


4. Install the Trigger by pushing it into the handle until a click is heard indicating that it is properly engaged.

### Assembly of the Motor

### NOTICE


When disassembling, assembling or pulling the Motor, we recommend replacement of the Motor Gasket (7).

1. Install the Motor Gasket in the Housing making sure that the grooves in the tab of the Motor Gasket fit around ridge in the Housing. Refer to Dwg. TPD1336.



2. Install the Rear Rotor Bearing (3A) into the rear of the Cylinder (1).
3. Install the Rotor in the Cylinder and secure with the Rear Rotor Bearing Retainer (6).
4. Install Vanes (4) in the slots in the Rotor (5).
5. Install the Front Rotor Bearing (3) into the Front End Plate (2). Install the Front End Plate on the Cylinder by pressing on the inner race of the front Rotor Bearing until the Bearing is seated on the Rotor Shaft.
6. Install Power Management Dial (34) through the front of Housing into smaller diameter at rear. Position the Dial so that the arrow lines up with one of the power setting indicators. Install the Dial Seal (35) at the beginning of the same diameter.
7. Insert the motor assembly into the front of Housing so that the smaller diameter at the rear of the motor will seat the Dial Seal when the motor is pushed into its final location.

### Assembly of the Impact Mechanism



## MAINTENANCE SECTION

1. Coat the Hammers (11) with a light film of No. Ingersoll–Rand 105–1LB Grease or Ingersoll–Rand No. 105–8LB Grease.
2. Heavily coat the jaws of the Anvil (35, 38 or 41) with Ingersoll–Rand No. 105–1LB Grease or Ingersoll–Rand No. 105–8LB Grease.
3. Replace the Hammers in the Hammer Frame (9) exactly as they were when you marked them prior to disassembly.

### NOTICE

If you are installing new Hammers or want to change the location of the existing Hammers to utilize both impacting surfaces, slide the Hammers in the Hammer Frame so that the half–round notch on one Hammer is located on one side of the Frame and the half–round notch on the other Hammer is located on the other side of the Frame.

4. Replace the Hammer Pins (10).
5. Examine the base of the Anvil (35, 38 or 41) and note its contour. While looking down through the Hammer Frame, swing the top Hammer to its full extreme one way or another until you can match the contour of the Anvil. Enter the Anvil into the Hammer Frame and through the first Hammer. Swing the bottom Hammer in the opposite direction from the top Hammer and maneuver the Anvil slightly until it drops into the bottom Hammer. Refer to Dwg. TPD1535.

### Assembly of the Air Wrench

1. Position the Motor Housing (17) in leather–covered vise jaws with the splined shaft of the Rotor in a horizontal position.
2. Place the assembled impact mechanism down onto the splined hub of the Rotor.
3. Position the Hammer Case Gasket (16) against the face of the Motor Housing.


### NOTICE

Be sure that the flat on the bottom of the Hammer Case Gasket is installed in the corresponding flat in

the Housing. If the Hammer Case Gasket is not installed correctly, the Air Wrench will not function properly.

Refer to Dwg. TPD1335–1.

4. Apply a thin film of Ingersoll–Rand No. 105–1LB Grease or Ingersoll–Rand 105–8LB Grease on inside surface of the Hammer Case Bushing (13), and place the Hammer Case (12) down over the Anvil and against the Motor Housing.



(Dwg. TPD1335–1)

5. Install the Hammer Case Screws (8) and tighten them to 20 in–lb (2.26 Nm) torque.

### Assembly of the Square Drive Anvil

#### Model 2904P1 and 2904P2

1. Insert the Socket Retainer (36 or 39) in the Anvil.
2. Push the Socket Retainer Spring (37 or 40) in the end of the Anvil so that it secures the Socket Retainer.

### Assembly of the Quick–Change Anvil

#### Model 2904P4

1. Install the Thrust Ring Lock (42) on the Anvil (41).
2. Install the Thrust Ring (43), Retaining Sleeve Spring (44), Retaining Ball (40), Retaining Sleeve (46) and Retaining Sleeve Stop (47).

## MAINTENANCE SECTION

### TROUBLESHOOTING GUIDE

Trouble	Probable Cause	Solution
Low power	Dry Motor	<b>Daily</b> , inject 3 cc of Ingersoll–Rand No. 50 Oil into the inlet and run the tool to lubricate the motor.
	Inadequate air supply	Install proper air supply and connection. Refer to Dwg. TPD905–1 and Dwg. TPD1674–1 on pages 3 and 4.
	Dirty Inlet bushing Screen	Using a clean, suitable, cleaning solution in a well ventilated area, clean the Inlet Bushing Screen.
	Worn or broken Vanes	Replace a <b>complete</b> set of Vanes
	Worn or broken Cylinder and/or scored End Plates	Examine Cylinder. Check outside and ends for wear or damage and inside for scored or wavy bore. Replace Cylinder if any of these conditions exist. Replace End Plates if they are scored.
	Dirty motor parts.	Disassemble the Tool and clean in a clean, suitable, cleaning solution in a well ventilated area. Assemble the Tool and inject 3 cc of the recommended oil into Inlet and run Tool to lubricate internal parts.
	Damaged Reverse Valve	Replace Reverse Valve. Refer to <b>Installation of Reverse Valve.</b>
Motor will not run	Incorrect assembly of motor	Disassemble motor and replace worn or broken parts and reassemble. Refer to <b>Assembly of the Motor.</b>
	Insufficient lubricant in impact mechanism.	Lubricate impact mechanism through Hammer Case Grease Fitting using the recommended grease.
Tool will not impact	Broken or worn impact mechanism parts	Remove Hammer Case Assembly and examine impact mechanism parts. Replace any worn or broken parts.
	Impact mechanism not assembled correctly.	Refer to <b>Assembly of Impact Mechanism.</b>

#### NOTICE

**SAVE THESE INSTRUCTIONS. DO NOT DESTROY.**



## Service Centers

Ingersoll–Rand Company  
510 Hester Drive  
White House, TN 37188  
USA  
Tel: (615) 672 0321  
Fax: (615) 672 0801

Ingersoll–Rand Sales Company Limited  
Chorley New Road  
Horwich, Bolton  
Lancashire BL6 6JN  
England – UK  
Tel: (44) 204 880890  
Fax: (44) 204 880388

Ingersoll–Rand Equipements de Production  
111 Avenue Roger Salongro  
BP 59  
F–59450 Sin Le Noble  
France  
Tel: (33) 27 93 0808  
Fax: (33) 27 93 0800

Ingersoll–Rand GmbH  
Gewerbealle 17  
45478 Mülheim/Ruhr  
Deutschland  
Tel: (49) 208 99940  
Fax: (49) 208 9994445

Ingersoll–Rand Italiana SpA  
Casella Postale 1232  
20100 Milano  
Italia  
Tel: (39) 2 950561  
Fax: (39) 2 95380169

Ingersoll–Rand  
Camino de Rejas 1, 2–18 B1S  
28820 Cosiada (Madrid)  
España  
Tel: (34) 1 669 5850  
Fax: (34) 1 669 6054

Ingersoll–Rand Nederland  
Produktieweg 10  
2382 PB Zoeterwoude  
Nederland  
Tel: (31) 71 45220  
Fax: (31) 71 218671

Ingersoll–Rand Company SA  
PO Box 3720  
Airode 1451  
South Africa  
Tel: (27) 11 864 3930  
Fax: (27) 11 864 3954

Ingersoll–Rand  
Scandinavian Operations  
Kastruplundgade 221  
DK–2770 Kastrup  
Danmark  
Tel: (45) 32 526092  
Fax: (45) 32 529092

Ingersoll–Rand SA  
The Alpha Building  
Route des Arsenaux 9  
CH–1700 Fribourg  
Schweiz/Suisse  
Tel: (41) 37 205111  
Fax: (41) 37 222932

Ingersoll–Rand Company  
Kuznetsky Most 21/5  
Entrance 3  
103698 Moscow  
Russia  
CIS  
Tel: (7) 501 882 0440  
Fax: (7) 501 882 0441

Ingersoll–Rand Company  
16 Pietro  
Ul Stawki 2  
PL–00193 Warsaw  
Poland  
Tel: (48) 2 635 7245  
Fax: (48) 2 635 7332



