

Form OMMMINER
Edition 1
November 1988

**OPERATION AND MAINTENANCE MANUAL
for BEEBE**

**MODEL MINER 36
3 TON (Single Line)
6 TON (Double Line)
AIR CHAIN HOIST**

FOR TOP PERFORMANCE AND MAXIMUM DURABILITY OF PARTS, OPERATE THIS HOIST AT 90 psig (6.2 bar/620 kPa) with 3/4" (19 mm) MINIMUM AIR SUPPLY HOSE.

WARNING

Do not use this hoist for moving, lifting, supporting, or transporting people or lifting or supporting loads over people.

Always operate, inspect and maintain this Hoist in accordance with American National Standards Institute Code (ANSI/ASME B30.16) and any other applicable codes and regulations.

Read all the enclosed instructions and warning labels before installing, operating or repairing this hoist.

Refer all Communication to the Nearest
Ingersoll-Rand Material Handling Products
Office or Distributor.

© *Ingersoll-Rand Company 1988*

INGERSOLL-RAND®

.....
MATERIAL HANDLING PRODUCTS

SAFETY SUMMARY

WARNING: Do not use this hoist for moving, lifting, supporting, or transporting people or lifting or supporting loads over people.

WARNING: The supporting structures and load-attaching devices used in conjunction with this hoist must provide an adequate safety factor to handle the rated load, plus the weight of the hoist. If in doubt, consult a qualified structural engineer.

The National Safety Council, Accident Prevention Manual for Industrial Operations, Eighth Edition and other recognized safety sources make a common point: Employees who work near cranes or assist in hooking on or arranging a load should be instructed to keep out from under the load. From a safety standpoint, one factor is paramount: conduct all lifting operations in such a manner that if there were an equipment failure, no personnel would be injured. This means keep out from under a raised load and keep out of the line of force of any load.

To the best of our knowledge, INGERSOLL-RAND Material Handling Products hoists are manufactured in accordance with the latest standards in effect at time of manufacture.

However, contrary to common belief, the Occupational Safety and Health Act of 1970, as we understand it, generally places the burden of compliance with the user, not the manufacturer. Many OSHA requirements are not concerned or connected with the manufactured product but are, rather, connected with the final installation: "It is the owner's responsibility and user's responsibility to determine the suitability of a product for any particular use. Check all applicable industry, trade association, federal, state and local regulations. Read all operating instructions and warnings before operation."

Rigging: It is the responsibility of the operator to exercise caution, use common sense and be familiar with proper rigging techniques. See ANSI/ASME B30.9 for rigging information, American National Standards Institute, 1430 Broadway, New York, NY 10018.

NOTICE: Using other than genuine INGERSOLL-RAND Material Handling Products parts will result in the void of warranty.

Hoist returned with opened, bent or twisted hooks, or without chain and hooks, will not be repaired or replaced under warranty.

PARTS ORDERING INFORMATION

The use of replacement parts other than INGERSOLL-RAND Material Handling Products will invalidate the Company's warranty. For prompt service and genuine INGERSOLL-RAND Material Handling Products parts, provide your nearest Distributor with the following:

1. Complete model number and serial number as it appears on the nameplate. The model number is Miner 36.
2. Part number and part name as shown in manual.
3. Quantity required.

IMPORTANT NOTICE

It is our policy to promote safe delivery of all orders.

This shipment has been thoroughly checked, packed and inspected before leaving our plant and receipt for it in good condition has been received from the carrier. Any loss or damage which occurs to this shipment while enroute is not due to any action or conduct of the manufacturer.

VISIBLE LOSS OR DAMAGE

If any of the goods called for on the bill of lading or express receipt are damaged or the quantity is short, do not accept them until the freight or express agent makes an appropriate notation on your freight bill or express receipt.

CONCEALED LOSS OR DAMAGE

When a shipment has been delivered to you in apparent good condition, but upon opening the crate or container, loss or damage has taken place while in transit, notify the carrier's agent immediately.

DAMAGE CLAIMS

You must file claims for damage with the carrier. It is the transportation company's responsibility to reimburse you for repair or replacement of goods damaged in shipment. Claims for loss or damage in shipment must not be deducted from the Beebe invoice, nor should payment of Beebe invoice be withheld awaiting adjustment of such claims as the carrier guarantees safe delivery.

You may return products damaged in shipment to us for repair, which services will be for your account and form your basis for claim against the carrier.

General Warranty

Beebe International, Inc. ("Manufacturer") extends the following warranty to the original purchaser ("Purchaser") of each new product ("Product") manufactured or sold by it.

- (a) Manufacturer warrants Product to be free from defects in material and workmanship under normal use and service for a period of one year from Manufacturer's original sale.
- (b) Manufacturer's liability and Purchaser's sole remedy under this warranty, and for any and all other claims arising out of the purchase and use of Product, including any alleged negligence on the part of Manufacturer, is limited to repair or replacement, at Manufacturer's option, of such defective Product or part thereof, provided that the defective Product or part thereof is returned to Manufacturer's factory or authorized service center, **transportation prepaid**, and that examination by Manufacturer discloses that the Product is defective under the terms of this warranty.
- (c) Manufacturer does not warrant components of products provided by other manufacturers. However, to the extent possible, Manufacturer will pass along to Purchaser applicable warranties of such other manufacturers.
- (d) This warranty is conditioned upon installation and use of Product in accordance with Manufacturer's operating instructions. This warranty is **IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY**

WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. **Manufacturer shall have no liability or obligation as to any Product which has been misused, altered or changed in any way, including without limitation use of a "cheater" handle for extra leverage on hoists or pullers, conversion of hand winches or hoists to power operations,* or use of any Product for lifting, lowering or moving persons.**

- (e) MANUFACTURER SHALL IN NO EVENT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES arising from the sale, delivery or use of Products.

Manufacturer neither assumes nor authorizes any person to assume for it any other liability or obligation in connection with sale and use of Products other than stated above. **Caution:** Purchaser and user are cautioned to examine specific, local or other regulations, including American National Standard Regulations, which may apply to a particular type of product before installing or putting to use.

***Except power rewinding pursuant to operating instructions**

Please Note: Units purchased without chain and/or hooks must have Beebe chain and hooks installed before the warranty is valid.

BEEBE INTERNATIONAL, INC.

2724 SIXTH AVENUE SOUTH, SEATTLE, WASHINGTON 98134
PHONE (206) 624-0466, TELEX: 328795, P.O. BOX 24046

TELEFAX: 206 447-0715

20M GENWAR 1-86

This Page Intentionally Blank

WARNING: The supporting structures and load-attaching devices used in conjunction with this hoist must provide an adequate safety factor to handle the rated load, plus the weight of the hoist. If in doubt, consult a qualified structural engineer.

When attaching hook to rigging or load, make sure safety latch is engaged.

Air Supply

Always use an air filter and lubricator with the hoist. Install the lubricator as close to the hoist inlet as practical. Operate the hoist at 57 to 90 psig (4 to 6.2 bar/400 to 620 kPa). Do not exceed 120 psig (8.2 bar/820 kPa). The diameter of the air supply hose and the filter and lubricator must be at least 3/4 in. (19 mm). When the air supply hose is connected to the hoist, drip about 10 drops of nondetergent SAE 10 or 20W oil into the hoist inlet port.

This Page Intentionally Blank

SAFETY INSTRUCTIONS

WARNING -- READ THESE INSTRUCTIONS

1. Only allow qualified people (trained in safety and operation) to operate the hoist.
2. Only operate a hoist if you are physically fit.
3. When a "DO NOT OPERATE" sign is placed on the hoist controls, do not operate the hoist until the sign has been removed by designated personnel.
4. Before each shift, the operator should inspect the hoist for wear or damage.
5. Never use a hoist which inspection indicates is defective.
6. Periodically, inspect the hoist thoroughly and replace worn or damaged parts.
7. Lubricate the hoist regularly.
8. Do not use hoist if safety latch on a hook has been sprung or broken.
9. Check that the safety latches are engaged before using.
10. Never splice a hoist chain by inserting a bolt between links.
11. Only attach loads less than or equal to the rated capacity of the hoist. See warning labels attached to the hoist.
12. Never use the hoist chain as a sling.
13. Do not "side pull" or "yard."
14. Never operate a hoist with twisted, kinked, "capsized" or damaged load chain.
15. Do not force a chain or hook into place by hammering.
16. Never insert the point of the hook into a chain link.
17. Be certain the load is properly seated in the saddle of the hook.
18. Do not support the load on the tip of the hook.
19. Never run the load chain over a sharp edge. Use a sheave.
20. When using two hoists to move one load, select two hoists both having rated capacities equal to or more than the load. This provides adequate safety in the event of a sudden load shift or failure of one hoist.
21. Pay attention to the load at all times when operating the hoist.
22. Make sure all people are clear of the load path. Do not lift a load over people.
23. Never use the hoist for moving, lifting or lowering people, and never allow anyone to stand on a load.
24. Ease the slack out of the chain and sling when starting a move. Do not jerk the load.
25. Never leave an attached load unattended.
26. Never weld or cut a load attached to the hoist.
27. Never use the hoist chain as a welding electrode.
28. Do not operate hoist if chain jumping, excessive noise, jamming, overloading, or binding occurs.
29. Keep the load from hitting the load chain.
30. Always keep hands and clothing free from the controls.
31. Always rig the hoist properly and carefully.
32. Turn off, depressurize and disconnect the air lines before performing any maintenance.
33. Avoid collision or bumping of hoist.
34. After use, properly secure hoist and loads.

OPERATION

The three most important aspects of hoist operation are: (1) Follow all safety instructions when operating hoist, (2) Allow only qualified people to operate a hoist and (3) Subject each hoist to a regular inspection and maintenance procedure.

Hoist Movement

Lifting and lowering a load is controlled by the pendant. When the 6 ton hook block is being inhailed, the 3 ton hook is paying out and vice versa.

This Page Intentionally Blank

4. Troubleshooting

Troubles	Major causes	Troubleshooting
<p>Motor does not operate. Slow rotation or no rotation of motor.</p>	<ul style="list-style-type: none"> • Insufficient air pressure. • Supplied air volume is insufficient. • Inner diameter of piping is too small. • Strainer in the adapter at air inlet port is clogged. • Silencer is clogged. • Powder or dust in the motor. • Vane is enlarged because of wet atmosphere or long term of maintenance. • Vane is burnt owing to the dry operation. • Vane is worn or damaged. • Main valve does not open. • Control lever is bent or damaged. • Brake does not open. • Reduction gear: Wrong assembly or gear, bearing, etc. are worn or broken. 	<ul style="list-style-type: none"> • Increase air pressure. • Increase compressor output. • Enlarge inner diameter. • Clean. • Replace with new silencer. • Clean motor and lubricate. Clean air filter and replace filter element. • Replace vane. Discharge drain water from air filter. Or clean and replace filter element. • Clean the motor and polish the vane and replace if required. Supply oil to lubricator or clean the lubricator. • Replace the vane. • Tighten the connecting bolt on the respective part or disassemble and check. • Replace the control lever. • Clean air circuit of the brake. Thereafter, perform leakage test. • Disassembly and check are required. Replace the worn or broken parts.
<p>Brake does not work.</p>	<ul style="list-style-type: none"> • Lining is worn. • Oil on the lining. • Air exhaust hole of the brake cover is clogged. • Main valve does not return to the neutral position. 	<ul style="list-style-type: none"> • Replace with new brake disc. • Clean. Replace oil seal if required. • Clean. (See the section "Inspection of Brake".) • Check the operation system, e.g., bending of control lever. Disassemble and inspect the valve housing if required.

When hoist is malfunctioning, stop operation immediately and perform suitable troubleshooting.

Careless repair causes damage to the hoist. Therefore, be careful when repairing.

This Page Intentionally Blank

INSPECTION


There are two types of inspection, the frequent inspection performed by the operator and periodic inspections performed by qualified personnel.

Frequent Inspection

On hoists in continuous service, frequent inspection should be made at the beginning of each shift. In addition, visual inspections should be conducted during regular service for any damage or evidence of malfunction.

1. OPERATION. Check for visual signs or abnormal noises which could indicate a defect. Make sure all controls function properly and return to neutral when released. Check chain feed through the hoist and bottom block. If chain binds, jumps, or is excessively noisy or "clicks," clean and lubricate the chain. If problem persists, replace the chain. Do not operate the hoist until all defects have been corrected.
2. UPPER AND LOWER LIMIT. Test operation at slow speed with empty hook. If the hook does not stop in its normal position for either upper or lower limit, adjust or repair.
3. PNEUMATIC SYSTEM. Check air lines, valves and other components for leakage. Repair if necessary.
4. HOOK. Check for wear or damage, increase throat width, bent shank or bending of hook. Replace hooks with 15% increase in throat width or 10% bend. If the hook latch snaps past the tip of the hook, the hook is sprung and must be replaced.

Model No.:	Throat Width:	
	in.	(mm)
Miner 36 (3 Ton Bottom)	1.56	39.5
Miner 36 (6 Ton Bottom)	2.07	52.5
Miner 36 (6 Ton Top)	2.07	52.5



Check hook support bearings for lubrication and damage. Make sure they swivel easily and smoothly. Repair and lubricate as necessary.

5. HOOK LATCH. Make sure the hook latch is present and operating. Replace if necessary.
6. CHAIN. Examine each of the links for bending, cracks in weld areas or shoulders, transverse nicks and gouges, weld splatter, corrosion pits, striation -- minute parallel lines and chain wear, including bearing surfaces between chain links. Replace a chain that fails any of the inspections. Check chain lubrication and lubricate if necessary. See "Load Chain" under "LUBRICATION."

NOTE: Excessive wear or stretching may not be apparent from visual observation. Also, inspect chain by measuring five links in accordance with instructions under "Periodic Inspection."

NOTE: A worn load chain may cause the load sheave to wear rapidly. Inspect the load sheave and replace if damaged or worn.


7. CHAIN REEVING. Ensure welds on standing links are away from load sheave. Reinstall chain if necessary. Make sure chain is not capsized, twisted or kinked. Adjust as required.
8. LUBRICATOR AND FILTER. If plastic bowls are used on the filter or lubricator, check for cracks, clouding or other damage. Replace if cracked or damaged.

Periodic Inspection

According to ANSI/ASME B30.16-1987, frequency of periodic inspection depends on the severity of usage: **NORMAL**, yearly; **HEAVY**, semiannually; **SEVERE**, quarterly. Disassembly may be required for **HEAVY** or **SEVERE** usage. Keep accumulative written records of periodic inspections to provide a basis for continuing evaluation. Inspect all the items in a frequent inspection. Also inspect the following:

1. **FASTENERS.** Check rivets, cotter pins, cap screws and nuts on hook blocks and hoist body. Replace if missing and tighten if loose.
2. **ALL COMPONENTS.** Inspect for wear, damage, distortion, deformation and cleanliness. If external evidence indicates the need, disassemble. Check gears, shafts, bearings, sheaves, chain guides, springs and covers. Replace worn or damaged parts. Clean, lubricate and reassemble.
3. **HOOK.** Inspect hook for cracks using magnetic particle or other suitable method. Remove cover and inspect hook retaining nut and key or other hook retaining parts. Tighten or repair, if necessary.
4. **CHAIN SHEAVES.** Check for damage or excessive wear. Replace if necessary.
5. **MOTORS.** Check for satisfactory performance. If performance is poor, disassembly the components and check for worn vanes, gearing, bearings and shafts. The parts should be cleaned, lubricated and reassembled. Replace worn parts.
6. **BRAKES.** Ensure proper operation. Lift a capacity or near capacity load a few inches off the floor and check ability of braking system to stop and hold the load without excessive drift. If external inspection indicates the need, disassemble. Brake discs must be uniform and of sufficient thickness. Check friction surface of brake plates for wear, deformation or foreign deposits. Clean or replace if necessary.
7. **SUPPORTING STRUCTURE.** Check for distortion, wear and continued ability to support load.
8. **TROLLEY.** If a trolley is used, check that the trolley wheels track the beam properly and that clearance between wheels and beam is correct. Check trolley for smoothness of operation. Adjust or repair as necessary.
9. **LABELS.** Check for presence and legibility. Replace if necessary.
10. **LOAD CHAIN END ANCHORS.** Ensure both ends of load chain are securely attached. Secure if loose, repair if damaged, replace if missing. See "MAINTENANCE" for proper means of chain attachment.
11. **LOAD CHAIN.** Measure the chain for stretching by suspending a light load (50 to 100 pounds) from the hoist and measuring across five links sections all along the chain. When any five links in the working length reaches or exceeds the discard length, replace the entire chain. Always use a genuine **INGERSOLL-RAND** Material Handling Products replacement chain. For regular and nickle-diffused load chains:

Model:	Size:	Normal Length:		Discard Length:	
No.:	(mm)	in.	(mm)	in.	(mm)
Miner 36	13	7.087	180.0	7.228	183.6



12. **CHAIN CONTAINER.** Check for excessive wear. Replace if necessary.

LUBRICATION

Load Chain

WARNING: Failure to maintain clean and well lubricated load chain will void the manufacturer's warranty.

1. Lubricate load chain weekly, or more frequently, depending on severity of service.
2. In an corrosive environment, lubricate more frequently than normal.
3. Lubricate each link of the chain and apply new lubricant over existing layer.
4. Also lubricate hook and safety latch pivot points.
5. Use BEEBE Lubri-Link or a SAE 50 to 90W EP oil.
6. Clean chain to remove rust or abrasive dust build-up. After cleaning, lubricate the chain.

CAUTION: Do not use an acid-based solvent to clean the chain.

Lubricator

Check fluid level daily, add nondetergent SAE 10 or 20W motor oil as necessary. Adjust lubricator drip rate to 19 to 26 drops per minute. To adjust the optional INGERSOLL-RAND lubricator, turn the adjustment screw on top of lubricator counterclockwise to increase drip rate, clockwise to decrease drip rate. Annually, disassemble and clean lubricator bowl of dirt and other foreign material. Blow out internal passages.

Filter

Check filter with manual petcock daily and drain when necessary. Replace filter element when it becomes dirty or plugged. Annually, disassembly and clean filter bowl, also blow out filter element in reverse direction of normal air flow.

Disassembly

1. Coat all motor parts with a light film of SAE 10 or 20W nondetergent motor oil before assembling.
2. Clean and lubricate with new grease the chain wheel bearing and hook thrust bearing on the bottom hook blocks.
3. Repack gear reducers and fill the space between the small internal gear and the housing with grease.
4. Clean the inner mechanism of the brake and lubricate with lithium safonified silicon grease, NLGI Class No. 2, like Molykote Grease 33.

Recommended Lubricant Chart

Mfg.:	Air Motor: (Lubricator)	Gear Reducer: (Including Reducer Bearing)	Other Bearings:
Esso	Arox 22 Teresso 32	Lithtan EP 0	Beacon EP 2
Mobil	Almo Oil No. 525	Mobilux EP 0	Mobilux EP 0
Shell	Tellus Oil C32 Torcula Oil 32	Alvania Grease EPR0	Alvania Grease EP 2

MAINTENANCE

WARNING: Never perform maintenance on the hoist while it is supporting a load.

WARNING: Before performing maintenance, tag controls: DANGER - DO NOT OPERATE - EQUIPMENT BEING REPAIRED.

WARNING: Turn off, depressurize and disconnect the air lines before performing any maintenance.


WARNING: Only allow qualified service personnel to perform maintenance.

WARNING: Test hoist to 125% of its rated capacity before returning to service.

Chain Replacement (See Assembly Drawing for details of chain reeving)

NOTE: Do not remove the old chain from the hoist. Old chain is used to feed new chain through hoist.

1. Run 6 ton bottom block to six inches above the lowest point of travel and support.
2. Remove the 3 Ton hook.
3. Make a "C" link in NEW chain by grinding through one side of the end link. (If old chain was installed correctly, this assures that end link will be in correct alignment.)
4. Hook "C" link to old chain thus joining both chains. BE SURE WELDS of "standing" links on the new chain are facing away from the hoist load sheave.




5. Check that first link of new chain is started such that it will correctly attach to chain anchor.
6. Carefully "jog" the down button for the 6 ton hook block until the new chain runs sufficiently out the other side (24 to 36 inches).
7. Manually pull new chain through 6 ton hook block using old chain.
8. Attach end of new chain to anchor bolt on hoist. See "Correct Installation of Anchor Bolt." Check that chain is not twisted, kinked, "capsized" or damaged. Remove one link to untwist, if required.
9. Attach 3 ton hook.

Correct Installation of Anchor Bolt

When attaching the end link of the load chain on the six ton side, position the anchor bolt so that the marks on the head of the bolt are perpendicular to the hoist body as shown in the figure.


If the bolt is installed with the marks horizontal or otherwise tilted from vertical, there will be a clearance between the bolt and the inside of the link chain and the end link may wear out prematurely.



This Page Intentionally Blank

Main Assembly (Miner 36)



ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
10	Mid Section	1	5373442
20	Gear Box	1	5373443
30	Motor	1	5373444
40	Control Valve	1	5373445
50	Push Button Valve	1	5373446
60	E-Type Control	1	5373447
70	Coupling	1	5373371
80	Hexhead Bolt	2	5373524
90	Plain Washer	3	5373559
100	C.D. Washer	2	5373418
110	Hex Nut	2	5373415
120	Bolt	1	5373489
130	C.D. Washer	1	5373564
140	Hex Nut	1	5373558
150	Link Chain (Specify length)	1	Contact Factory
160	Load Sheave	1	5373448
170	Hook 3 T	1	5373545
180	Hook 6 T	2	5373525
190	Bottom Block 6 T	1	5373449
200	Buffer	1	5373529
210	Buffer Disc	1	5373490
220	Buffer Disc	1	5373469
230	Suspension	1	5373450



Mid Section (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
10	Housing	1	5373454
	Chain Wheel Set (Includes Pc's 20,30,40 & 50)	1	5373360
20	Chain Wheel	1	Not Sold Separately
30	Rotary Shaft Seal	1	5373547
40	Washer	1	5373548
50	Retainer Ring, C-Type	1	5373569
60	Ball Bearing	1	5373578
70	O-Ring	1	5373575
80	Chain Guide	1	5373470
90	Ball Bearing	2	5373581

Note: See main assembly parts list for part number for entire assembly.




Gear Box (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
10	Spacer	1	5373549
20	O-Ring	1	5373576
30	O-Ring	1	5373577
40	Planet Shaft	1	5373313
50	Ball Bearing	1	5373580
60	Gear Wheel	Set of 3	5373527
70	Needle Cage	6	5373455
80	Shaft	3	5373528
90	Ball Bearing	1	5373584
100	Internal Gear	1	5373550
110	Key	1	5373530
120	Ball Bearing	1	5373586
130	Planet Shaft	1	5373531
140	Ball Bearing	1	5373583
150	Gear Wheel	Set of 2	5373532
160	Needle Cage	4	5373493
170	Washer	2	5373533
180	Shaft	2	5373534
190	Internal Gear	1	5373535
200	Key	1	5373536
210	Gear Housing	1	5373451
220	Muffler	1	5373457
230	Cap Screw	4	5373393
240	Internal Gear	1	5373537
250	Key	1	5373538
260	Planet Shaft	1	5373539
270	Double Gear Wheel	Set of 2	5373540
280	Needle Cage	4	5373518
290	Shaft	2	5373541
300	Retaining Ring, C-Type	1	5373567
310	Ball Bearing	1	5373585
320	Shaft	1	5373462
330	Spacer	1	5373542
340	Retainer Ring, C-Type	1	5373565
350	Ball Bearing	1	5373579
360	Retainer Ring, C-Type	1	5373568
370	Retainer Ring, C-Type	1	5373566
380	Ring	1	5373495
390	Coned Disc Spring	1	5373543
400	Spacer	1	5373463
410	Spring Pin	1	5373423
420	O-Ring	1	5373437
430	Plug	1	5373588
	Silencer Set (Includes Pc's 440 & 450)	1	5373471
440	Silencer	4	Not Sold Separately
450	Support	2	Not Sold Separately
460	Gear Box Cover	1	5373456

Gear Box (Miner 36) (Cont.)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
470	C.D. Washer	5	5373561
480	Cap Screw	5	5373399
490	Handle	1	5373587
500	Spring Pin	2	5373424

Note: See main assembly parts list for part number for entire assembly.






Motor (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
	Motor Housing Complete (Including Pc's 10,11,12 & 20)	1	5373464
10	Motor Housing	1	Not Sold Separately
11	Pipe	4	Not Sold Separately
12	Pipe	12	Not Sold Separately
20	Cylinder	1	Not Sold Separately
30	O-Ring	7	5373573
	End Plate Set (Gear Side) (Includes Pc's 40,50,60 & 70)	1	5373472
40	End Plate	1	Not Sold Separately
50	Spacer	1	Not Sold Separately
60	Ball Bearing	1	5373582
70	Retainer Ring	1	5373331
80	Rotor	1	5373465
90	Countersunk Head Cap Screw	1	5373407
100	Vane	Set of 5	5373496
	End Plate Set (Brake Side) (Include Pc's 110,50,60,70 ,111,112, 113 & 120)	1	5373473
110	End Plate	1	Not Sold Separately
50	Spacer	1	Not Sold Separately
60	Ball Bearing	1	5373582
70	Retainer Ring	1	5373331
	Shuttle Valve Set (Pc's 111,112 & 113)	1	5373497
111	Ball	1	Not Sold Separately
112	Plug	1	Not Sold Separately
113	Spring Pin	1	Not Sold Separately
120	Spring Pin	1	5373425
130	Rotary Shaft Seal	1	5373498
140	Cover	1	5373474
150	Countersunk Head Cap Screw	3	5373410
160	Brake Cylinder	1	5373466
170	Key	1	5373499
180	Brake Disc	1	5373475
190	Retainer Ring, C-Type	1	5373419
200	Pressure Plate	1	5373476
210	O-Ring	1	5373428
220	Cylinder Cover	1	5373467
230	Brake Spring	Set of 6	5373500
240	Cap Screw	3	5373392
250	O-Ring	2	5373501
260	Brake Piston	1	5373477
270	C.D. Washer	1	5373562
280	Hex Head Bolt	1	5373390
290	Key	1	5373502
300	Brake Housing	1	5373458
310	Set Screw	1	5373461

Motor (Miner 36) (Cont.)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
320	C.D. Washer	4	5373561
330	Cap Screw	4	5373554
340	Handle	1	5373587
350	Spring Pin	2	5373416


Note: See main assembly parts list for part number for entire assembly.



Control Valve (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
	Valve Housing Complete (Including Pc's 10,11,12,13,14 & 15)	1	5373478
10	Valve Housing	1	Not Sold Separately
11	Sleeve R	1	Not Sold Separately
12	Sleeve L	1	Not Sold Separately
13	Plug	1	Not Sold Separately
14	O-Ring	1	Not Sold Separately
15	Set Screw	1	Not Sold Separately
20	Spring Pin	2	5373426
30	Valve Cone	2	5373479
40	O-Ring	2	5373503
50	O-Ring	2	5373430
60	Needle Valve	1	5373480
70	O-Ring	1	5373431
80	Packing	1	5373504
90	Plug	1	5373505
100	Packing	2	5373506
110	Plug	2	5373507
120	Hose Nippler	3	5373589
130	Protection Shield	4	5373481
140	Cap Screw	1	5373395
150	Nipple	1	Not Sold Separately
160	Cap	1	Not Sold Separately
170	Gasket	1	5373482
180	Valve Flange	1	5373468
190	Cap Screw	1	5373553
200	Protection Shield	1	5373483
210	Cap Screw	2	5373552


Note: See main assembly parts list for part number for entire assembly.



Suspension (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
10	Susp. Hook Holder Half	2	5373460
20	Chain Piece	2	Not Sold Separately
30	Hex Nut	3	5373557
40	C.D. Washer	3	5373563
50	Cap Screw	3	5373523


Note: See main assembly parts list for part number for entire assembly.



Pushbutton Valve (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
	Valve Housing Complete (Includes Pc's 10 & 11)	1	5373508
10	Valve Housing	1	Not Sold Separately
11	Liner	2	Not Sold Separately
20	Valve Pin	2	5373509
30	Push Button, Concave	1	5373510
40	Push Button, Convex	1	5373511
50	Retainer Ring	2	5373512
60	Ball	2	5373513
70	O-Ring	1	5373432
80	Plug	1	5373514
90	Handle	1	5373515
100	Grip	1	5373516
110	Spring Pin	1	5373422
120	Eyebolt	1	5373517


Note: See main assembly parts list for part number for entire assembly.



E-Type Control (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
10	Control Valve	1	5373440
20	Push Button Valve	1	5373441
30	Hose Nipple	3	5373589
40	Hose Clip	6	Not Sold Separately
50	Gasket	1	5373484
60	Cap Screw	4	5373397
70	Cap Screw	2	5373522



Note: See main assembly parts list for part number for entire assembly.



Load Sleeve (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
10	Hook Holder Half	2	5373459
20	Hex Nut	2	5373557
30	C.D. Washer	2	5373563
40	Cap Screw	2	5373404


Note: See main assembly parts list for part number for entire assembly.



Hook (Miner 36)

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.	
			3 TON	6 TON
10	Hook	1	Not Sold Separately	Not Sold Separately
	Hook Latch Set	1	5373546	5373526
20	Hook Latch	1	Not Sold Separately	Not Sold Separately
30	Hook Spring	1	Not Sold Separately	Not Sold Separately
40	Hook Pin	1	Not Sold Separately	Not Sold Separately
50	Screw	2	Not Sold Separately	Not Sold Separately

Note: See main assembly parts list for part number for entire assembly.



6 Ton, Bottom Block

ITEM NO.	DESCRIPTION OF PART	QTY TOTAL	PART NO.
10	Hook Case Half	2	5373452
20	Ball Bearing	2	5373590
30	Chain Wheel	1	5373551
40	Hex Nut	3	5373557
50	C.D. Washer	3	5373563
60	Cap Screw	3	5373556

Note: See main assembly parts list for part number for entire assembly.

