

# OPERATOR AND MAINTENANCE MANUAL

for

## AIR MOTOR DRIVEN TRACTOR

**MODEL TVH-1**  
**Pull Chain Control**



**MODEL TVH-2**  
**Pendent Control**

**MODEL TVHSR-1**  
**Pull Chain Control**  
**Spark-Resistant**

**MODEL TVHSR-2**  
**Pendent Control**  
**Spark-Resistant**

**Always operate, inspect and maintain this Tractor in accordance with American National Standards Institute Safety Code (ANSI 30.16) and any other applicable safety codes and regulations.**

**FOR TOP PERFORMANCE AND MAXIMUM DURABILITY OF PARTS, OPERATE THIS TRACTOR AT 90 psig (6.2 bar/620 kPa) WITH 1/2" (13 mm) (MINIMUM) AIR SUPPLY HOSE AND AN AIR LINE LUBRICATOR AND FILTER.**



(Dwg. TPC480)

**READ ALL THE ENCLOSED INSTRUCTIONS BEFORE INSTALLING, OPERATING OR REPAIRING THIS TRACTOR.**

Refer All Communications to the Nearest  
Ingersoll-Rand Office or Distributor.

© Ingersoll-Rand Company 1984

Printed in U.S.A.

**INGERSOLL-RAND®**  
**AIR HOISTS**

## HOW TO ORDER REPAIR PARTS FOR YOUR AIR MOTOR DRIVEN TRACTOR

Your Air Motor Driven Tractor is designed and constructed to give you long, trouble-free service. In time it may become necessary to order and install new parts to replace those that have been subject to wear. For prompt service and genuine Ingersoll-Rand parts, place orders with your nearest Ingersoll-Rand Distributor. The use of other than Ingersoll-Rand replacement parts may result in decreased Tractor performance, and may invalidate all warranties.

When ordering parts, give your Distributor the following data:

1. Complete model number of the Air Motor Driven Tractor as it appears on the nameplate.
2. Complete part number, part name and quantity needed as shown on the pages of this manual.

If it becomes necessary to return the complete Air Motor Driven Tractor or certain parts to the factory, contact the Distributor from whom you purchased the Tractor, or the nearest Ingersoll-Rand Distributor in your locality.

### LUBRICATION

**Weekly, or as experience indicates,** check the oil level in the Motor Housing (51). If the oil level is down to the line on the Sight Glass Window (76), remove the Oil Chamber Plug (56) from the top of the Motor Housing (51), and fill the oil chamber with Ingersoll-Rand Lubricant No. 10 or a good quality high-speed spindle oil.

**Semiannually:** Insert Ingersoll-Rand Lubricant No. 28 or a good quality No. 2 cup grease into the Grease Fitting (50) or the rim of the Motor Adapter (1). Six or eight strokes from a hand grease gun are sufficient.

Remove the Oil Level Plug (24) from the side of the Gear Case (23). If the oil is below the opening, remove the Vent Cap and add Ingersoll-Rand Lubricant No. 55, or a rust-inhibited oil such as Mobil DTE Extra Heavy Oil or Texaco Regal E Oil.

Remove each Trolley Wheel Assembly (155) from the Trolley Brackets (150). Remove the cover, snap ring and bearing from the wheel. Repack the bearing with Ingersoll-Rand Lubricant No. 28 or a good quality No. 2 cup grease.

**Annually:** Change the oil in the Gear Case. To drain out the old oil, disconnect the Tractor unit from its supporting Trolley Brackets (150), remove the Oil Level Plug (24), and rotate the unit until the oil level hole is at the bottom. After returning the Tractor to its normal position, remove the Vent Cap and fill the Gear Case to the level hole with Ingersoll-Rand Lubricant No. 55 or its substitute (see preceding paragraph). Approximately 6-1/2 oz (189 mL) is required.

### OILER ADJUSTMENT

The rate of oil flow from the oil chamber to the motor is properly set at the factory. Correct adjustment is indicated by a slight oil mist in the exhaust. If necessary, check the adjustment by holding a piece of paper up to the exhaust and operating the motor for about 30 seconds. If no oil is collected, or if an excessive amount is emitted, adjust as follows:

Drain the oil from the chamber and remove the Motor Housing Cover (75) from the Motor Housing (51). Rotate the Oiler Adjusting Screw (80), **clockwise to reduce** the oil flow; **counterclockwise to increase** the oil flow. If sufficient flow cannot be obtained, it is an indication that the Oiler Felt (79) is clogged. Remove the Felt, which is located under the Screw, and install a new one.

### LUBRICATOR ASSEMBLY

1. Insert the end of the Oiler Wick (81) with knot 1/2" from end, into the oiler hole.
2. Insert the Oiler Felt (79).
3. Thread the other end of the Oiler Wick through the hole in Oiler Adjusting Screw (80).
4. Screw in Oiler Adjusting Screw flush with face.

### PREPARING TRACTOR FOR SERVICE

1. Mount the trolley unit on the track, being sure to use an equal quantity of Spacers (165) on each end of the Trolley Bracket Bolts (157) so that the Suspension Bolt (160) and Traction Adjusting Bolt (170) will be centralized between the Trolley Brackets (150).
2. Pass the end of the Traction Adjusting Bolt (170) through the mounting hole in the Motor Bracket (14). In the following order, slide one Spring Seat (172), the Traction Adjusting Spring (171) and the other Spring Seat onto the Bolt. Retain them with Adjusting Bolt Nut (173). Apply and securely tighten the Suspension Bolt Nut (163).
3. Run the Adjusting Bolt Nut (173) onto the Adjusting Bolt until the Spring is compressed to approximately 6" (153 mm). Apply the Adjusting Bolt Locknut (174). **Note:** Forcing the Drive Wheel excessively tight against the bottom of the track will decrease the life of the rubber tire and increase the loading on bearings. Compress the Spring only enough to prevent slippage of the Drive Wheel (15) on the track. Make final adjustment under actual operating conditions.
4. Adjust the brake only if experience proves that the factory setting is unsatisfactory. To adjust: Remove the Brake Cover (48) and loosen each of the three Adjusting Screw Locknuts (47). Rotate each Brake Adjusting Screw (46) an equal amount, turning it clockwise to increase the braking action; counterclockwise to decrease. Do not rotate the Screws more than one-half turn at a time, and not more than a total of 1-1/2 turns in either direction from the factory setting.

## MAINTENANCE

Periodically, as experience indicates, remove the Inlet Swivel Body (58) and withdraw the Air Strainer Screen (61) from the Motor Housing (51). Clean the Screen with kerosene or other solvent.

When assembling the Multi-Vane® motor and installing it in the Motor Housing (51), proceed as follows:


1. Press the Rear Rotor Bearing (87) into the recess in the Rear End Plate (86). Press this assembly onto the short hub of the Rotor (88) as far as possible without binding the End Plate against the rotor face.
2. Place a Vane (89) in each vane slot in the Rotor.
3. Slip the Cylinder (91) over the Rotor, making sure that the eight holes running longitudinally through the cylinder wall can be aligned with the holes through the Rear End Plate. If the holes cannot be aligned, the Cylinder is inverted; turn it end for end.
4. Press the Front Rotor Bearing (94) into the recess in the Front End Plate (93). Press this assembly onto the long hub of the Rotor.
5. Align the dowel hole in the Cylinder with the dowel hole in each End Plate, and insert the Cylinder Dowel. **Note:** Because the dowel hole in the Front End Plate is not visible when the motor is assembled, the hole location is indicated by a drill point mark on the end plate rim.
6. Slip the rubber Motor Clamp Ring (95) onto the Front End Plate. Apply a little tacky grease to the Ring and End Plate to hold the Ring in position until the motor is installed in the Motor Housing. Place the Pinion Key (97) in the rotor hub, slide the Rotor Pinion (96) onto the hub, and retain with Ring (98).
7. Place the Motor Housing (51), open face up on the workbench. **Align the drill punch mark on the rim of the Front End Plate with a similar mark on the face of the Motor Housing (51)**, and insert the assembled motor. Do not drive the motor into the Housing. If properly aligned with the housing bore, it can be pushed into position with the fingers. **Note:** Before the motor reaches full depth, check and make sure the Motor Clamp Ring (95) is still in position on the Front End Plate (93).
8. Apply the Housing Cover Gasket (83) to the Housing Face.
9. Place the Motor Housing Cover (75) on the Motor Housing (51), entering the end of the Cylinder Dowel (92) in the dowel hole in the Cover, and making sure the free length of Oiler Wick (81) enters the oil chamber. Insert one Housing Cover Cap Screw (84) through the center hole in the Cover and start it into the Housing. Check the alignment of the other holes in the Cover and those in the Housing. Lightly tap the edge of the Cover with a soft hammer to correct any slight misalignment.
10. Start all of the Housing Cover Cap Screws, and draw the Cover firmly and evenly against the Gasket by tightening each Screw a little at a time.

Completely disassemble the Motor Housing before attempting to replace the Shuttle Valve Bushing (53). Press the old Bushing from the Motor Housing with a 13/16" (20 mm) arbor, preferably one with an 11/16" (17 mm) pilot. Use the No. 76663 Bushing Inserting Tool to press in the new Bushing. Ream the Bushing to size with Reamer No. 76662. Thoroughly clean the Motor Housing before reassembly.

Use the No. 74324 Valve Stem Bushing Inserting Tool to install new Valve Stem Bushings (52) in the Motor Housing (51).


When disassembling the tractor gearing, remove the Brake Plate Key (30) from the gear case wall before attempting to withdraw the Internal Gear (28).

When installing the Gear Cage Assembly (35) in the Gear Case, note the punch marks and lines on each gear face, and position the gears as indicated in the accompanying view.



TVH TRACTOR  
GEAR CAGE ASSEMBLY

(Dwg. TPD927)



Series TVH Tractor

(Dwg. TPB761)

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

⊕ 1	Motor Adapter . . . . .	TVH50A-100	27	Cap Screw Lock Washer (4) . . . . .	L01-67
2	Motor Mounting Large Screw (3) . . . . .	510-638	28	Internal Gear . . . . .	TVH50A-665
3	Large Screw Lock Washer (3) . . . . .	8U-58	29	Brake Rear Plate . . . . .	TVH50A-670
4	Motor Mounting Small Screw (2) . . . . .	4U-638	30	Brake Plate Key . . . . .	TVH50A-658
5	Motor Adapter Screw (2) . . . . .	4E-638	31	Brake Front Plate . . . . .	TVH50A-672
6	Screw Lock Washer (4) . . . . .	4U-58	32	Brake Rotating Disc . . . . .	TVH50A-671
7	Plain Washer (2) . . . . .	MF-37	33	Rotating Disc Driver . . . . .	TVH50A-667
8	Housing Gasket . . . . .	HRA20A-739	34	Disc Driver Screw (3) . . . . .	TVH50A-668
9	Drive Gear (40 teeth) . . . . .	HRA30A-9	35	Gear Cage Assembly . . . . .	TVH50A-A666
*	Drive Gear Key . . . . .	HWA20A-405	36	Drive Shaft Pinion . . . . .	TVH50A-669
12	Drive Shaft . . . . .	TVH50A-316	37	Brake Bracket . . . . .	TVH50A-682
13	Drive Shaft Front Bearing . . . . .	R2H-97	38	Bracket Cap . . . . .	TVH50A-683
14	Motor Bracket . . . . .	TVH50A-650	39	Bracket Plug Screw (2) . . . . .	TVH50A-681
*	Nameplate . . . . .	PCG107AC-99X	40	Plug Screw Lock Washer (2) . . . . .	L01-67
*	Nameplate Screw (4) . . . . .	R4K-302	41	Brake Bracket Screw	
15	Drive Wheel . . . . .	TVH50A-653		Short (5) . . . . .	TVH50A-688
16	Drive Wheel Key . . . . .	TVH50A-661		Long . . . . .	TVH50A-676
17	Drive Wheel Gear Assembly . . . . .	TVH50A-A662	42	Bracket Screw Lock Washer (6) . . . . .	R2-320
18	Wheel Gear Bushing . . . . .	TVH50A-663	43	Brake Bracket Gasket . . . . .	TVH50A-673
19	Wheel Gear Seal . . . . .	TVH50A-664	44	Brake Plunger (3) . . . . .	TVH50A-677
● 20	Wheel Gear Large Bearing . . . . .	TVH50A-659	45	Brake Spring (3) . . . . .	TVH50A-678
● 21	Wheel Gear Small Bearing . . . . .	AM-318	46	Brake Adjusting Screw (3) . . . . .	TVH50A-679
22	Wheel Bearing Spacer . . . . .	TVH50A-652	47	Adjusting Screw Locknut (3) . . . . .	TVH50A-680
23	Gear Case . . . . .	TVH50A-654	48	Brake Cover . . . . .	TVH50A-689
24	Oil Level Plug . . . . .	P250-368	*	Vent Cap Elbow . . . . .	TVH50A-907
*	Vent Cap . . . . .	TVH50A-660	*	3/8" Close Nipple . . . . .	D02-908
26	Gear Case Cap Screw (4) . . . . .	R2N-103			








\* Not illustrated.

● To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (●) for every four tools in service.

⊕ If ordering this part for a Tractor with Pull Chain Throttle, also order two Control Shaft Bearings (104) and one Spring Stop Pin (110).

9

PENDENT CONTROL PARTS



Series TVH Tractor Motor


(Dwg. TPA1005)

PART NUMBER FOR ORDERING

PART NUMBER FOR ORDERING

		PULL CHAIN THROTTLE	PENDENT THROTTLE			PULL CHAIN THROTTLE	PENDENT THROTTLE
50	Grease Fitting . . . . .	R1-188	R1-188	83	Housing Cover Gasket . . . . .	HRA20A-984	HRA20A-984
	Tractor Motor Assembly . . . . .	TVH50A-A40	TVH-A40-2	84	Housing Cover Cap Screw (9) . . . . .	34U-463	34U-463
51	Motor Housing Assembly . . . . .	HRA20A-B40A	HRA20A-B40A	85	Cover Cap Screw Lock Washer (9) . . . . .	4U-58	4U-58
52	Valve Stem Bushing (2) . . . . .	HRA20A-615	HRA20A-615	● 86	Rear End Plate . . . . .	HRA20A-12	HRA20A-12
53	Shuttle Valve Bushing . . . . .	HRA20A-247	HRA20A-247	● 87	Rear Rotor Bearing . . . . .	402-22	402-22
● 54	Drive Shaft Rear Bearing . . . . .	HRA20A-318	HRA20A-318	88	Rotor . . . . .	HRA20A-53	HRA20A-53
55	1/8" Pipe Plug . . . . .	R2-227	R2-227	● 89	Vane Packet (set of 7 Vanes) . . . . .	HRA20A-42-7	HRA20A-42-7
56	Oil Chamber Plug . . . . .	ROH-377	ROH-377	● 91	Cylinder . . . . .	TVH50A-3	TVH50A-3
57	Housing Plug . . . . .	GA57-95	---	92	Cylinder Dowel . . . . .	HRA20A-98	HRA20A-98
58	Swivel Inlet Body Assembly . . . . .	834-165	834-165	93	Front End Plate . . . . .	HRA20A-11	HRA20A-11
● 59	Swivel Inlet Seal (2) . . . . .	MT4-210	MT4-210	94	Front Rotor Bearing . . . . .	R1L-24	R1L-24
60	Swivel Inlet Sleeve . . . . .	HRA20A-166	HRA20A-166	95	Motor Clamp Ring . . . . .	ROB2J73-359	ROB2J73-359
61	Air Strainer Screen . . . . .	HRA20A-61	HRA20A-61	96	Rotor Pinion (12 teeth) . . . . .	HRA30A-17	HRA30A-17
62	Shuttle Valve . . . . .	HRA20A-246	HRA20A-246	97	Pinion Key . . . . .	HRA20A-405	HWA20A-405
63	Shuttle Valve Cap Assembly (2) . . . . .	HRA20A-A943A	TVH-B238A	98	Pinion Retaining Ring . . . . .	404-118	404-118
64	Cap Seal (one for each Cap) . . . . .	R4-210	R4-210	100	Throttle Cam Pivot Pin . . . . .	157H-530	---
65	Elbow (2) . . . . .	---	12SR-8	101	Throttle Cam . . . . .	HRA20A-941	---
66	Large Throttle Valve Assembly . . . . .	TVH50A-A940	TVH50A-A940	102	Throttle Control Shaft . . . . .	TVH50A-255	---
● 67	Large Throttle Valve Face . . . . .	ROAR-210	ROAR-210	103	Control Shaft Sector . . . . .	HRA20A-254	---
68	Small Throttle Valve Assembly . . . . .	HRA20A-A840	HRA20A-A840	104	Control Shaft Bearing (2) . . . . .	34U-367	---
● 69	Small Throttle Valve Face . . . . .	834-159	834-159	105	Control Shaft Collar . . . . .	HRA20A-33	---
70	Throttle Valve Stem Assembly (2) . . . . .	HRA20A-A161	HRA20A-A161	106	Control Shaft Pin (3) . . . . .	R1AF-524	---
● 71	Throttle Valve Stem Seal (one for each Stem) . . . . .	R2F-167	R2F-167	107	Control Shaft Washer . . . . .	D02-419	---
72	Throttle Valve Cap Assembly (2) . . . . .	HRA20A-A266	HRA20A-A266	108	Control Shaft Retainer . . . . .	404-118	---
73	Cap Seal (one for each Cap) . . . . .	R4-210	R4-210	109	Throttle Lever Spring . . . . .	TVH50A-412	---
74	Throttle Valve Spring (2) . . . . .	MR-942A	MR-942A	110	Spring Stop Pin . . . . .	5BM-278	---
75	Motor Housing Cover Assembly . . . . .	HRA20A-A102	HRA20A-A102	111	Throttle Lever . . . . .	TVH50A-556	---
76	Sight Glass Window . . . . .	HRA20A-116	HRA20A-116	112	Throttle Chain (2) (length as specified) . . . . .	CA110-B240	---
77	Sight Glass Seal . . . . .	HRA20A-117	HRA20A-117	113	S-Hook (2 for each Chain) . . . . .	D02-421	---
78	Sight Glass Retainer . . . . .	HRA20A-119	HRA20A-119	114	Throttle Handle (2) . . . . .	MR-415	---
79	Oiler Felt . . . . .	R1-75	R1-75	115	Throttle Handle Bar (optional equipment) . . . . .	MR-409	---
80	Oiler Adjusting Screw . . . . .	R1-71A	R1-71A				
81	Oiler Wick . . . . .	HRA20A-74	HRA20A-74				
82	Exhaust Bushing . . . . .	HRA20A-105	HRA20A-105				

● To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (●) for every four tools in service.



(Dwg. TPA1006)



**Series TVH Tractor Pendant Control**

PART NUMBER FOR ORDERING

119	Union 3/8" NPT (3) . . . . .	MR-129
	Pendent Throttle and Hose Assembly (7 ft long - standard)	
	standard . . . . .	MR-A269-7
	spark-resistant . . . . .	MR-AR269-7
121	Pendent Throttle Handle Assembly	
	standard . . . . .	MR-269
	spark-resistant . . . . .	MR-AR269
122	Throttle Lever Pin . . . . .	DLC-120
123	Pendent Throttle Lever (2)	
	standard . . . . .	R00H-273A
	spark-resistant . . . . .	MLK-R273
124	Pendent Throttle Valve (2) . . . . .	MR-264
● 125	Pendent Throttle Valve Seal Ring (2 for each Valve) . . . . .	AF120-289
126	Pendent Throttle Valve Spring (2) . . . . .	D10-51
127	Pendent Throttle Valve Cap (2)	
	standard . . . . .	D02-180
	spark-resistant . . . . .	D02-1180
128	Control Hose (3)	
	7 ft. long . . . . .	H6A-7
	length as specified . . . . .	BH6A
129	Hose Nipple (2 for each Hose) . . . . .	RV1-46
130	Hose Binder (3) . . . . .	CE110-4

● To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (●) for every four tools in service.





(Dwg. TPA1007)

**Series TVH Tractor Trolley**

**PART NUMBER FOR ORDERING** →

**PART NUMBER FOR ORDERING** →


	Trolley Bracket Assembly		158	Bracket Bolt Nut (4) (3/4"-10 thd.) . .	DU-562
	Standard . . . . .	TVH-A690	159	Bracket Bolt Lock Washer (4) (3/4") . .	D01-692
	Spark-Resistant . . . . .	TVH-AR690	160	Suspension Bolt . . . . .	TVH50A-699
150	Trolley Bracket (2) . . . . .	TVH50A-690	162	Suspension Bolt Lock Washer (5/8") . .	A-67
151	Guide Roller (4) . . . . .	TVH50A-719	163	Suspension Bolt Nut (5/8"-11 thd.) . .	HU-776
152	Guide Roller Bolt (4) . . . . .	HU-865	164	Drawbar Clevis . . . . .	TVH50A-703
153	Roller Bolt Nut (4) . . . . .	D02-418	165	Spacer (80 required) . . . . .	21-748
154	Roller Bolt Lock Washer (4) . . . . .	D02-321	166	Drawbar Pin . . . . .	TVH50A-705A
155	Trolley Wheel Assembly (4)		167	Drawbar Pin Retainer (2) . . . . .	D02-330
	universal Wheels for operation on		170	Traction Adjusting Bolt . . . . .	TVH50A-713
	flat or tapered track and beams		171	Traction Adjusting Spring . . . . .	TVH50A-715
	Standard . . . . .	TVH50A-A691	172	Spring Seat (2) . . . . .	24-741
	Spark-Resistant . . . . .	TVH50A-AR691	173	Adjusting Bolt Nut (5/8"-11 thd.) . . .	HU-776
156	Wheel Spacer (12) . . . . .	23-725	174	Adjusting Bolt Locknut (5/8"-11	
156A	Trolley Wheel Shaft Nut (1 for each			thd. Jam Nut) . . . . .	G7-18
	Wheel) . . . . .	D02-418A	*	Adjusting Bolt Spacer (2)	
156B	Trolley Wheel Lock Washer (1 for each	D10-322	†	(1-21/32" [42 mm] long) . . . . .	TVH50A-711-54
	Wheel) . . . . .			Drawbar	
157	Trolley Bracket Bolt (2) (12-1/2"	TVH50A-746-12		Universal Type . . . . .	TVH50A-704
	[318 mm] long) . . . . .			with 4" (102 mm) hole spacing . . . . .	TVH50A-704-4

\* Not illustrated.

† Refer to DRAWBAR on page 10.

## DRAWBAR AND DRAWBAR YOKE KITS

The top view in the following illustration shows how to make a suitable Drawbar, while the lower view illustrates a "universal" drawbar (Part No. TVH50A-704) available from Ingersoll-Rand. The latter is long enough for practically any application, and the spacing of the holes is such that it can be cut to produce one or more intermediate length drawbars. In addition, a Drawbar with holes spaced 4" (102 mm) (Part No. TVH50A-704-4) is available. This short Drawbar is satisfactory for connecting the Tractor to an Ingersoll-Rand Low Headroom Hoist or a Standard Headroom Hoist when the Hoist is mounted with the rope drum crosswise to the track.




(Dwg. TPD267)

### DO-IT-YOURSELF DRAWBAR

Use 3/8" x 1-1/2" cold rolled steel. It is unnecessary to cut the corners if the unit is used only on a straight track.

Dimension "A" must at least equal the distance between the centers of the drawbar pin hole in the clevis on the Tractor and the one on the hoist when the Tractor and hoist are as close as possible to each other on the track.



(Dwg. TPD268)

### UNIVERSAL DRAWBAR

**Drawbar Yoke Kits** have been established for connecting Tractors to Trolley Mounted Hoists. Following is a list of Hoists with Trolleys and the available Drawbar Yoke Kits for them. **Note:** Series HLK Hoists with Rigid Trolley do not require a Drawbar Yoke Kit.

**PART NUMBER FOR ORDERING**

For Series C6CA, C620C, C6H20A, C6H20B, C640A, C6H40A, D660A and D6H60A:	
Standard Headroom Hoists with Rigid Trolley . . . . .	C6CA-K1
Standard Headroom and Low Headroom Hoists with Swivel Trolleys . . . . .	C6H20A-K2
Low Headroom Hoists with Rigid Trolley . . . . .	C640ALH-K1
For Series HLA20A, HRA20A, HRA20ASR, HLE20B and HRE20B Hoists with Rigid Trolley . . . . .	HRA20A-K1
For Series HLA30A, HRA30A, HLA40A, HRA40A, HRA40ASR, HLA60A, HRA60A, HRE30B, HLE30B, HRE40B, HLE40B, HRE60B and HLE60B Hoists with Rigid Trolley . . . . .	HRA40A-K1
For all Series MR, ML, MRK and MLK Hoists and A and B Hoists with Rigid Trolley . . . . .	MR-K1
For Series CA110, CA120, CE110 and CE120 Hoists with Rigid Trolley . . . . .	CE120-K1

## MAINTENANCE TOOLS

TOOL NUMBER FOR ORDERING	TOOL NAME FOR ORDERING	OPERATION
P25-228 34766	Grease Gun . . . . .	Inserting grease into Grease Fitting (50).
74324	Control Shaft Bearing Inserting Tool (for Tractor with Pull Chain Throttle) . . . . .	Installing the Control Shaft Bearings (104) in the Motor Adapter (1).
76427	Valve Stem Bushing Inserting Tool . . . . .	Installing new Valve Stem Bushings (52) in the Motor Housing (51).
76662	Drive Shaft Bearing Inserting Tool . . . . .	Installing the Drive Shaft Rear Bearing (54) in the Motor Housing (51).
76662	Shuttle Valve Bushing Reamer . . . . .	Reaming a new Shuttle Valve Bushing (53) to size after pressing it into the Motor Housing (51).
76663	Shuttle Valve Bushing Inserting Tool . . . . .	Pressing a new Shuttle Valve Bushing (53) into the Motor Housing (51).
76664	Drive Shaft Rear Bearing Puller . . . . .	Removing the Drive Shaft Rear Bearing (54) from the Motor Housing (51).

