


STANLEY[®]

helps you do things right

Stanley Hydraulic Tools

Division of The Stanley Works
3810 S.E. Naef Road
Milwaukie, Oregon 97267
Phone: 503/659-5660
Telex: 360771

PARTS LIST



BR85


SPECIFICATIONS

| | |
|----------------------|---------------------------|
| Weight | 85 lbs/38 kg |
| Pressure Range | 1500-2000 psi/105-140 bar |
| Flow Range | 7-9 gpm/26-34 lpm |
| Optimum Flow | 8 gpm/30 lpm |
| Porting | 1/2" male pipe hose end |
| Overall Length | 27 in/68 cm |
| Width | 16 in/40 cm |
| System Type | o.c. or c.c. |

MODEL BR85

**HYDRAULIC
BREAKER**

*Not used on all units.



SEAL KIT DATA

| Part No. | Qty. | Description | Part No. | Qty. | Description |
|----------|------|-------------|----------|------|--------------|
| 0185 | 2 | O-Ring | 02023 | 1 | Cup Seal for |
| 01604 | 1 | O-Ring | 03452 | 1 | Kit 02825 |
| 00026 | 1 | O-Ring | | 1 | Cup Seal for |
| 00293 | 1 | O-Ring | | 1 | Kit 03478 |
| 02024 | 1 | O-Ring | | 1 | Wiper Seal |
| 00106 | 1 | O-Ring | 01900 | 1 | O-Ring |
| 02176 | 1 | Wiper Seal | 02177 | 1 | O-Ring |
| 02176 | 1 | Wiper Seal | 00143 | 1 | Piston Seal |
| 02022 | 1 | O-Ring | 01505 | 2 | O-Ring |
| 01414 | 1 | Seal | | | |

NOTE: Use Seal Kit Part Number 02825 when ordering for BR55. Part Number 03478 for BR55B models.

| Illus. Index No. | Part No. | Qty. Per Unit | PART NAME |
|------------------|----------|---------------|---|
| 1 | 03454 | 1 | Breaker Body Assembly |
| 2 | 01902 | 1 | Piston Sleeve |
| 3 | 02022 | 1 | O-Ring, 2-1/4 x 2-1/2 x 1/8 |
| 4 | 01414 | 1 | Seal w/Back-Up Ring |
| 5 | 03452 | 1 | Cup Seal |
| 6 | 01900 | 1 | O-Ring |
| 7 | 01998 | 1 | Wiper Seal |
| 8 | 02177 | 1 | Breaker Piston |
| 9 | 02176 | 1 | O-Ring, 2-1/8 x 2-1/4 x 3/32 (90 Duro) |
| 10 | 01505 | 1 | Accumulator Assembly — Consists of Items 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, and 55 |
| 11 | 00221 | 1 | Accumulator Sleeve |
| 12 | 01991 | 1 | Nylock Insert |
| 13 | 01993 | 1 | Nut — Piston Keeper |
| 14 | 01892 | 2 | Piston Seal — Polypak 12501500 |
| 15 | 01894 | 1 | Accumulator Piston |
| 16 | 01895 | 1 | O-Ring, .118 x 1.720 ID |
| 17 | 01850 | 1 | Accumulator End Cap |
| 18 | 02171 | 1 | Accumulator Change Valve |
| 19 | 02171 | 1 | O-Ring, .097 x .785 ID |
| 20 | 01897 | 1 | Accumulator Retaining Nut |
| 21 | 00721 | 1 | Nylock Insert |
| 22 | 01905 | 1 | Spring |
| 23 | 02163 | 1 | On-Off Valve Spool — c.c. Models |
| 24 | 02164 | 1 | On-Off Valve Spool — c.c. Models |
| 25 | 02017 | 1 | Pressure Control Valve |
| 26 | 00026 | 1 | O-Ring, 3/16 x 5/16 x 1/16 |
| 27 | 01903 | 1 | High Crown Nut |
| 28 | 02171 | 1 | Reversing Spool |
| 29 | 02891 | 1 | Spool Bore Plug (incl. Item 55) |
| 30 | 02026 | 1 | Roll Pin, 1/4 x 1-1/2 |
| 31 | 01844 | 1 | Roll Pin, 1/4 x 1-1/2 |
| 32 | 00844 | 2 | Handle Grip |
| 33 | 02494 | 1 | Valve Push Rod Sleeve |
| 34 | 02014 | 1 | O-Ring, 11/16 x 7/8 x 3/32 (90 Duro) |
| 35 | 00293 | 1 | O-Ring, 1-5/16 x 1-1/2 x 3/32 (90 Duro) |
| 36 | 02024 | 1 | O-Ring, 3/8 x 1/2 x 1/16 |
| 37 | 00106 | 1 | Wiper Seal |
| 38 | 01515 | 4 | Wiper Seal 1/2 NC x 1-1/2 USH |
| 39 | 02708 | 1 | Breaker Foot Assembly, 1-1/8 inch (Consists of Items 40 thru 49) |
| 40 | 01840 | 1 | Foot Body |
| 41 | 01914 | 1 | Hex Bushing (1-1/4 inch foot assembly only) |
| 42 | 01915 | 1 | Hex Bushing (1-1/8 inch foot assembly only) |
| 43 | 01744 | 1 | Impact Ring |
| 44 | 01745 | 1 | Impact Ring |
| 45 | 01897 | 1 | Latch |
| 46 | 01917 | 2 | Latch Impact Bushing |
| 47 | 02181 | 1 | Shoulder Bolt, 3/4 x 3-1/2 Soc. Hd |
| 48 | 01918 | 1 | Nut, Elastic Stop Jam, 5/8 x 11 |
| 49 | 02178 | 2 | Spring |
| 50 | 02180 | 2 | Foot Bolt |
| 51 | 02172 | 2 | Nut, 3/4 Buttress Trd. |
| 52 | 02022 | 2 | O-Ring, 1-1/2 x 1-1/2 x 1/8 |
| 53 | 00288 | 2 | Dose Assembly, 1/2 x 3/4 Lg. |
| 54 | 00288 | 2 | O-Ring, 1.475 x 1.701 x .118 90D |
| 55 | 03382 | 1 | |

NOTE: Breaker Foot Assembly Part Number 02078 or 01843 may be used on either open center or closed center models. NOTE: Use Part Number and Part Name When Ordering.

- A** Supplied with Item 20
- B** Supplied with Item 53

ACCUMULATOR CHARGING INSTRUCTIONS

To check or charge your accumulator you need:


1. A charging assembly with pressure gauge and accumulator valve adapter. The Stanley #02835 accumulator tester was developed for use with the BR85 breaker and is the best unit available.
2. A hose with fittings for tank and charging assembly.
3. A NITROGEN charged filler tank — 800 psi minimum.

TO CHECK ACCUMULATOR PRESSURE:

1. Holding the chuck end, turn the gauge counter clockwise until reaching the stop, to ensure the valve is completely retracted.
2. Remove protective cap on Tester charging valve and thread entire unit on to charging valve of accumulator. (Do not advance gauge end into chuck end, turn as a unit.)
3. Seat the chuck to the charging valve of the accumulator (hand tighten only).
4. Advance the valve by turning the gauge end clockwise until a pressure is read on the gauge.
5. Reverse above procedure.

TO CHARGE ACCUMULATOR:

1. Follow above procedure through item 3. (Item 4 optional.)
2. Attach chuck from Nitrogen supply to accumulator tester charge valve and charge accumulator to 600 psi. (NOTE: It may be required to adjust regulator to 650-700 psi to overcome pressure drop thru charging valve.)
3. Reverse above procedure.



STANLEY
helps you do things right

Stanley Hydraulic Tools
Division of The Stanley Works
3810 S.E. Naef Road
Milwaukie, Oregon 97267
Phone: 503/659-5660
Telex: 360771

STANLEY

helps you do things right

SERVICE INSTRUCTIONS BR85B BREAKER

PRIOR TO DISASSEMBLY.

- Clean exterior of tool.
- Obtain seal kit part no. 03478 so you can replace all seals exposed during disassembly.
- Note orientation of seals before removing them. Install new seals in same way.

BREAKER DISASSEMBLY.

1. Place breaker horizontally in appropriate fixture or vise.
2. Remove four 1/2-13 x 1-1/2 inch capscrews and remove handle from breaker body.
3. Remove the two nuts and springs, then remove foot assembly and foot bolts.
4. Push piston and piston sleeve out through handle end of body and remove piston sleeve from piston.
5. Carefully remove piston seals being careful not to damage the seal grooves. Note the orientation of seal lips.
6. Remove on-off valve and spring from breaker body.
7. Remove spool bore plug and withdraw the reversing spool.
8. Drive spirol pin out of handle with 1/4-inch punch to remove trigger.
9. Push the valve push rod sleeve out of handle from trigger side.

TO SERVICE FOOT ASSEMBLY.

1. The latch, detent, spring and impact bushings are accessible when the shoulder bolt is removed.
2. To remove hex bushings, a 1-3/8 inch diameter steel rod 10 inches long is required. Remove latch. Push hex bushing with rod from flange end of foot toward latch end. A 50 ton press is required.

3. To install hex bushing, push hex bushing from latch end toward flange end of foot. One end of hex bushing is tapered to aid assembly.

Note: Align hex as shown for proper gad alignment.



ACCUMULATOR REMOVAL AND DISASSEMBLY.

1. **Discharge accumulator** by depressing the valve stem of charging valve.
2. Remove retaining nut with wrench (part no. 02367).
3. Thread two 1/4-20 x 2 inch screws through cross bar (part no. 03114) into holes provided in accumulator, then pull accumulator out.
4. **After discharging accumulator**, clamp in appropriate fixture (DO NOT distort cylinder) and remove the charging valve end cap.
5. Push accumulator out of sleeve using a soft instrument (brass, aluminum, wood, etc.).
6. Remove seals using brass or plastic o-ring tools making sure not to damage grooves.

PRIOR TO ASSEMBLY.

- Clean all parts with a degreasing solvent.
- Ensure that all seals that were exposed have been replaced with new parts.
- Apply clean grease or o-ring lubricant to all parts during reassembly.

ACCUMULATOR ASSEMBLY AND INSTALLATION.

1. Replace polypac piston seals with lips facing corresponding end of piston.

Caution: Do not damage seal grooves.

2. Insert piston into accumulator sleeve and push piston gently, large counterbore first, into accumulator sleeve until it bottoms on piston keeper nut (which was not removed).
3. Place one drop of Loctite #242 on middle of accumulator end cap and thread into accumulator sleeve.
4. Place assembly in appropriate fixture (do not distort cylinder) and tighten end cap to 150 ft.-lb./200 Newton-m.
5. Replace 2-1/8 O.D. x 1/16 inch o-ring around accumulator sleeve and install 2-1/16 O.D. x 3/32 inch o-ring in bottom of accumulator chamber of breaker body.
6. Push accumulator cartridge into housing, with charging valve facing outward, until it bottoms.
7. Thread in retaining nut and tighten to 150 ft.-lb./200 Newton-m.
8. Charge accumulator to 500-600 psi (nitrogen only).
9. Replace accumulator valve cap.

TO COMPLETE ASSEMBLY.

1. Install lower piston seal, with lips facing

handle end of breaker body, using installation tool part no. 03590.

2. Snap wiper seal in place, lip facing foot end of breaker body.
3. Install upper piston seal in piston sleeve with lips facing chamfered end of bore. Install back-up ring on side opposite lips.
4. Slide piston sleeve over small end of breaker piston, chamfered side first.
5. Install breaker piston through handle end of breaker body.
6. Install on-off valve spring and valve.
7. Install reversing spool, small diameter first, and replace spool bore plug. Tighten to 75 ft.-lb./100 Newton-m.
8. Install valve push rod sleeve in handle, wiper seal end first.
9. Place handle on breaker body, locating on two dowel pins and secure with four 1/2-13 x 1-1/2 inch capscrews. Use Loctite #242 on clean, dry threads and tighten in even increments in a cross pattern to 100 ft.-lb./135 Newton-m.
10. Assemble breaker foot, foot bolts, springs and nuts to breaker body and tighten nut to compress spring .250 in./6 mm from free length.

TROUBLESHOOTING BR85B BREAKER

| PROBLEM | CAUSE | SOLUTION |
|--|---|--|
| Accumulator loses charge after short period of use. | Bad charge valve. | Replace. |
| | Accumulator piston seals damaged or worn. | Inspect and replace seals using proper installation techniques. |
| Breaker doesn't run. | Power unit not functioning. | Check power unit for proper flow and pressure (7-9 gpm @ 1500-2000 psi). |
| | Couplers or hoses blocked. | Remove restriction. |
| | Pressure and return line hoses reversed at ports. | Be sure hoses are connected to their proper ports. |
| | Mechanical failure of piston or reversing spool. | Disassemble breaker and inspect for damaged parts. |
| Breaker doesn't hit effectively. | Power unit not functioning. | Check power unit for proper flow and pressure (7-9 gpm @ 1500-2000 psi). |
| | Couplers or hoses blocked. | Remove restriction. |
| | Accumulator charge (pressure hose will pulse more than normal). | Discharge to remove any accumulated oil and recharge accumulator. If charge loss continues, replace accumulator seals using proper installation techniques. |
| | Oil too hot (above 150°F). | Provide cooler to maintain proper oil temperature (100-130°F). |
| Breaker operates slow. | Low gpm supply from power unit. | Check power unit for proper flow (7-9 gpm). |
| | High backpressure. | Check hydraulic system for excessive backpressure (over 250 psi). |
| | Couplers or hoses blocked. | Remove restriction. |
| | Oil too hot (above 150°F) or too cold (below 60°F). | Check power unit for proper oil temperature. Bypass cooler to warm oil up, provide cooler to maintain proper temperature. |
| Breaker gets hot. | Hot oil going through tool. | Check power unit. Be sure flow rate is not too high causing part of the oil to go through the relief valve. Provide cooler to maintain proper oil temperature (100-130°F). |
| | | Eliminate flow control devices. |
| Oil leakage on gad. | Lower piston seal failure. | Replace seal. |
| Oil leakage through vent or between handle and breaker body. | Upper piston seal failure. | Replace seals. |
| | On-off valve, seals failed, piston sleeve, o-ring failure. | Replace seals. |