


# RD10 RAIL DRILL

---



## **Safety, Operation and Maintenance Manual**

---

*Focused on performance™*

**STANLEY®**

helps you do things right

22982 8/92

# SAFETY PRECAUTIONS

Tool operators and maintenance personnel must always comply with the safety precautions given in this manual and on the stickers and tags attached to the tool and hose.

These safety precautions are given for your safety. Review them carefully before operating the tool and before performing maintenance or repairs.

Supervising personnel should develop additional precautions relating to the specific work area and local safety regulations. If so, place the added precautions in the space provided on page 3.

---


## GENERAL SAFETY PRECAUTIONS

---

The RD10 Rail Drill provides safe and dependable service if operated in accordance with the instructions given in this manual. Read and understand this manual and any stickers and tags attached to the tool and hose before operation. Failure to do so can result in personal injury or equipment damage.


- Operators must start in a work area without bystanders. Flying debris can cause serious injury.
- The operator must be familiar with all prohibited work areas such as excessive slopes and dangerous terrain conditions.
- Always wear safety equipment such as goggles, ear and head protection, leg protection, gloves, snug fitting clothing, and safety shoes at all times when operating the tool.
- Do not overreach. Maintain proper footing and balance at all times.
- Do not inspect or clean the tool while the hydraulic power source is connected. Accidental engagement of the tool can cause serious injury.
- Always connect hoses to the tool hose couplers before energizing the hydraulic power source. Make sure all hose connections are tight.
- Establish a training program for all operators to ensure safe operation.
- Do not operate the tool unless thoroughly trained or under the supervision of an instructor.
- Do not operate the tool at fluid temperatures above 140° F/60° C. Operation at higher temperatures can cause higher than normal temperatures at the tool which can result in operator discomfort.
- Never wear loose clothing that can get entangled in the working parts of the tool.
- To avoid personal injury or equipment damage, all tool repair, maintenance and service must only be performed by authorized and properly trained personnel.

# TOOL STICKERS AND TAGS



The stickers and tags attached to the rail drill prior to shipment from the factory are shown on this page. The pressure and flow rate specified must never be exceeded. All stickers and tags must be read and understood prior to operating the tool.

The information listed on stickers and tags must be legible at all times. Always replace stickers that have become worn or damaged. Replacements are available from your local Stanley distributor.



GPM/PRESSURE DANGER STICKER



PINCH POINT WARNING STICKER

## SAFETY TAG

The safety tag at right is attached to the rail drill when shipped from the factory. Read and understand the safety instructions listed on this tag before removal. We suggest you retain this tag and attach it to the rail drill when not in use.

**DANGER**

1. FAILURE TO USE HYDRAULIC HOSE LABELED AND CERTIFIED AS NON-CONDUCTIVE WHEN USING HYDRAULIC TOOLS ON OR NEAR ELECTRICAL LINES MAY RESULT IN DEATH OR SERIOUS INJURY.  
BEFORE USING HOSE LABELED AND CERTIFIED AS NON-CONDUCTIVE ON OR NEAR ELECTRICAL LINES BE SURE THE HOSE IS MAINTAINED AS NON-CONDUCTIVE. THE HOSE SHOULD BE REGULARLY TESTED FOR ELECTRIC CURRENT LEAKAGE IN ACCORDANCE WITH YOUR SAFETY DEPARTMENT INSTRUCTIONS.
2. A HYDRAULIC LEAK OR BURST MAY CAUSE OIL INJECTION INTO THE BODY OR CAUSE OTHER SEVERE PERSONAL INJURY.
  - A. DO NOT EXCEED SPECIFIED FLOW AND PRESSURE FOR THIS TOOL. EXCESS FLOW OR PRESSURE MAY CAUSE A LEAK OR BURST.
  - B. DO NOT EXCEED RATED WORKING PRESSURE OF HYDRAULIC HOSE USED WITH THIS TOOL. EXCESS PRESSURE MAY CAUSE A LEAK OR BURST.
  - C. CHECK TOOL HOSE COUPLERS AND CONNECTORS DAILY FOR LEAKS. DO NOT FEEL FOR LEAKS WITH YOUR HANDS. CONTACT WITH A LEAK MAY RESULT IN SEVERE PERSONAL INJURY.

**IMPORTANT**

READ OPERATION MANUAL AND SAFETY INSTRUCTIONS FOR THIS TOOL BEFORE USING IT.

USE ONLY PARTS AND REPAIR PROCEDURES APPROVED BY STANLEY AND DESCRIBED IN THE OPERATION MANUAL.

TAG TO BE REMOVED ONLY BY TOOL OPERATOR.

SEE OTHER SIDE 15875

**DANGER**

- D. DO NOT LIFT OR CARRY TOOL BY THE HOSES. DO NOT ABUSE HOSE. DO NOT USE KINKED, TORN OR DAMAGED HOSE.
3. MAKE SURE HYDRAULIC HOSES ARE PROPERLY CONNECTED TO THE TOOL BEFORE PRESSURIZING SYSTEM. SYSTEM PRESSURE HOSE MUST ALWAYS BE CONNECTED TO TOOL "IN" PORT. SYSTEM RETURN HOSE MUST ALWAYS BE CONNECTED TO TOOL "OUT" PORT. REVERSING CONNECTIONS MAY CAUSE REVERSE TOOL OPERATION WHICH CAN RESULT IN SEVERE PERSONAL INJURY.
4. DO NOT CONNECT CLOSED-CENTER TOOLS TO OPEN-CENTER HYDRAULIC SYSTEMS. THIS MAY CAUSE EXTREME SYSTEM HEAT AND/OR SEVERE PERSONAL INJURY.  
DO NOT CONNECT OPEN-CENTER TOOLS TO CLOSED-CENTER HYDRAULIC SYSTEMS. THIS MAY RESULT IN LOSS OF OTHER HYDRAULIC FUNCTIONS POWERED BY THE SAME SYSTEM AND/OR SEVERE PERSONAL INJURY.
5. BYSTANDERS MAY BE INJURED IN YOUR WORK AREA. KEEP BYSTANDERS CLEAR OF YOUR WORK AREA.
6. WEAR HEARING, EYE, FOOT, HAND AND HEAD PROTECTION.
7. TO AVOID PERSONAL INJURY OR EQUIPMENT DAMAGE, ALL TOOL REPAIR, MAINTENANCE AND SERVICE MUST ONLY BE PERFORMED BY AUTHORIZED AND PROPERLY TRAINED PERSONNEL.

**IMPORTANT**

READ OPERATION MANUAL AND SAFETY INSTRUCTIONS FOR THIS TOOL BEFORE USING IT.

USE ONLY PARTS AND REPAIR PROCEDURES APPROVED BY STANLEY AND DESCRIBED IN THE OPERATION MANUAL.

TAG TO BE REMOVED ONLY BY TOOL OPERATOR.

SEE OTHER SIDE 15875



---

## EQUIPMENT PROTECTION AND CARE

---

### **IMPORTANT**

In addition to the Safety Precautions on pages 1 thru 3 of this manual, observe the following for equipment protection and care.

- Always store the tool in a clean, dry space, safe from damage or pilferage.
- Always keep critical tool markings, such as labels and stickers, legible.
- Always replace hoses, couplings, and other parts with replacement parts recommended by Stanley Hydraulic Tools. Supply hoses must have a minimum working pressure rating of 2500 psi/175 bar.
- Always use hoses that have a fluid resistant inner surface and an abrasive resistant outer surface. Whenever near electrical conductors, use **clean** hose labeled and certified non-conductive.
- To avoid personal injury or equipment damage, all tool repair, maintenance and service must only be performed by authorized and properly trained personnel.
- Make sure all couplers are wiped clean before connection.
- The hydraulic circuit control valve must be in the "OFF" position when coupling or uncoupling hydraulic tools. Failure to do so can result in damage to the quick couplers and cause overheating of the hydraulic system.
- Keep the rail drill clean and lubed, especially the slides and feed screw.

# HYDRAULIC HOSE REQUIREMENTS

## HOSE TYPES

Hydraulic hose types authorized for use with Stanley Hydraulic Tools are as follows:

- 1 Labeled and certified non-conductive
- 2 Wire braided (conductive)
- 3 Fabric braided (not certified or labeled non-conductive)

Hose 1 listed above is the only hose authorized for use near electrical conductors.


Hoses 2 and 3 listed above are **conductive** and **must never** be used near electrical conductors.

To help ensure your safety, the following DANGER tags are attached to all hoses purchased from Stanley Hydraulic Tools. **DO NOT REMOVE THESE TAGS.**

If the information on a tag is illegible because of wear or damage, replace the tag immediately. A new tag can be obtained at no charge from your Stanley distributor.


### 1 CERTIFIED NON-CONDUCTIVE HOSE

This tag is attached to all certified and labeled **non-conductive** hose.



### 2 AND 3 WIRE- AND FABRIC-BRAIDED (NOT CERTIFIED OR LABELED NON-CONDUCTIVE)

This tag is attached to all **conductive** hose.



## HOSE PRESSURE RATING

The rated working pressure of the hydraulic hose **must be equal to or higher than** the relief valve setting on the hydraulic system used to power the rail drill.

# HYDRAULIC SYSTEM REQUIREMENTS

- The hydraulic system should provide a flow of 5-10 gpm/20-38 lpm at an operating pressure of 2000 psi/140 bar. Recommended relief valve setting is 2100 psi/145 bar.
- The hydraulic system should not have more than 250 psi/17 bar backpressure measured at the tool end of the operating hoses. The system conditions for measurement are at maximum fluid viscosity of 400 ssu/82 centistokes (minimum operating temperatures).
- The hydraulic system should have sufficient heat rejection capacity to limit the maximum fluid temperature to 140° F/60° C at the maximum expected ambient temperature. The recommended minimum cooling capacity is 5 hp/3.73 kW at a 40° F/4° C difference between ambient temperature and fluid temperature.
- The hydraulic system should have a minimum of 25 micron full-flow filtration. It is recommended that filter elements be sized for a flow of at least 30 gpm/114 lpm for cold temperature startup and maximum dirt holding capacity.
- The hydraulic fluid used should have a viscosity between 100 and 400 ssu/20 and 82 centistokes at the maximum and minimum expected operating temperatures. Hydraulic fluids of petroleum base with antiwear and non-conductive properties and viscosity indexes over 140 meet the recommended requirements over a wide range of operating temperatures.
- The recommended hose size is 0.500-inch/12 mm I.D. to 50 ft/15 m long and 0.625-inch/16 mm I.D. minimum up to 100 ft/30 m long.

# OPERATION

## PREOPERATION PROCEDURES

### CHECK POWER SOURCE

1. Using a calibrated flowmeter and pressure gauge, check that the hydraulic power source develops a flow of 5-10 gpm/20-38 lpm at 2000 psi/140 bar.
2. Make certain that the hydraulic power source is equipped with a relief valve set to open at 2100-2250 psi/145-155 bar, maximum.
3. Make certain that the power source return pressure does not exceed 250 psi/17 bar.

### CONNECT HOSES

1. Wipe all hose couplers with a clean lint-free cloth before making connections.
2. Connect the hoses from the hydraulic power source to the couplers on the rail drill or rail drill hoses. It is a good practice to connect the return hose first and disconnect it last to minimize or eliminate trapped pressure within the rail drill motor.

**Note:** If uncoupled hoses are left in the sun, pressure increase inside the hoses can make them difficult to connect. Whenever possible, connect the free ends of hoses together.

3. Observe the "IN" and "OUT" port lettering on the valve block assembly to ensure that the hydraulic flow is in the proper direction. The "IN" port lettering indicates the inlet (pressure) side.

### USING COOLANT

The RD10 rail drill is equipped with a separate coolant can assembly that is used to deliver coolant to the drill bit. To use the coolant can assembly with the rail drill:

1. If operating the rail drill at temperatures

above 32° F/0° C, fill the coolant can with ordinary tap water.

2. If operating the rail drill at temperatures below 32° F/0° C, fill the coolant can with a mixture of 50% ordinary tap water and 50% antifreeze.
3. Pressurize the coolant can using the carrying handle/pump.
4. Connect the coolant can assembly to the rail drill using the supplied quick-disconnect coupler.

## RAIL DRILL OPERATION

1. Observe all safety precautions.
2. Make sure the rail drill is clean and properly lubed, especially the guide rods and feed screw.

**Note:** Check the slipping torque of the feed screw and make sure its between 14.5-18 ft lb/19.6-24.4 Nm. Refer to the RAIL DRILL ADJUSTMENTS section of this manual for further information.

3. Make sure the drill bit you intend to use is sharp and the shank is not damaged.
4. Install the appropriate drill bit into the two halves of the split chuck. Make sure the beaded portion of the drill bit engages the center slot in each of the chuck halves (figure 1).





Figure 1. Installing a Drill Bit.



- Place the split chuck (with drill bit) inside the spindle. Make sure the ends of the split chuck line up with the notches in the spindle (figure 2).



**Figure 2. Installing the Split Chuck.**

- Using a permanent ink marker, carefully mark the rail web where you intend to drill. A vertical and horizontal mark is required.
- Make sure the feed screw guard is in its fully raised position. If not, push forward on it to disengage it from the feed screw.
- Using the handle, slide the motor carriage toward the rail until it comes to a complete stop.
- Line up the rail drill with the rail at the first drill position.
- Adjust the knob assembly to center the drill bit at the horizontal ink mark on the rail web.
- Adjust the crutch weldment until the rail drill is perpendicular to the rail.
- Prior to clamping the tightening lever assembly, make sure there is a 1/4-inch/6 mm space between adjustment yoke and stop-plate of the operating lever.
- Clamp the tightening lever assembly to the rail web. Make sure the height adjusting lever lines up with the vertical ink mark on the rail web.
- Set the feed speed of the drill (FAST, MED, SLOW) that gives the best performance for the hardness of the rail and the type of drill bit being used.
- Move the hydraulic circuit control valve to the "ON" position.

- Open the coolant can assembly valve and then direct the modular hose towards the hole you intend to drill.
- Begin drilling by pushing down on the feed screw guard until it engages the feed screw.
- To stop drilling, disengage the feed screw guard and then pull the motor carriage toward the feed screw guard until it comes to a complete stop.
- Close the coolant can assembly water valve.
- Move the hydraulic circuit control valve to the "OFF" position.

---

## REMOVING THE DRILL BIT

---

Removing a drill bit requires a drift, Stanley part number 22308, and a hammer. To remove a drill bit:

- Insert the drift through a cross hole in the spindle, positioning the flat of the drift against the end of the split chuck.
- Using a hammer, drive the drift into the spindle to loosen the split chuck from the spindle.
- Remove the drill bit from the split chuck.

---

## DRILLING IN HARDENED RAIL (CURVE RAIL)

---

When drilling in hardened rail (curve rail), attention must be paid to the drill RPM and feed speed. The feed speed lever must be put into the slow position. The drill should also be operated at 5 g.p.m. Attention must be paid to directing a generous amount of coolant to the bit using the coolant system included with the RD-10. Failure to follow this procedure can cause rapid dulling of the drill bit and may damage the RD-10.

# RAIL DRILL ADJUSTMENTS

## INTRODUCTION

The following two adjustments might be required due to normal wear of the feed screw and feed screw guard mechanisms.

## ADJUSTING THE FEED SCREW SLIP CLUTCH

1. Remove the split chuck (with drill bit) if installed. Refer to the OPERATION section of this manual for further information.
2. Install a solid metal bar into the two slots at the front of the spindle. Turn the bar until the spindle is locked in place.
3. Thread two nuts onto the end of the feed screw just enough to install a torque wrench. Tighten one nut against the other.
4. Using the torque wrench, carefully turn the feed screw to get an accurate torque reading. If the reading is between 14.5-18 ft lb/19.6-24.4 Nm, then no adjustment is required. If not, equally tighten (or loosen) the four 1/4-inch free wheel body lock nuts until the correct reading is attained.
5. Remove the torque wrench, two nuts, and bar.
6. Replace the split chuck (with drill bit). Refer to the OPERATION section of this manual for further information.

## ADJUSTING THE FEED SCREW AUTOMATIC ADVANCE

1. Using the handle, slide the motor carriage toward the feed screw guard until it comes to a complete stop.
2. Lower the feed screw guard to engage the feed screw. If properly engaged, the feed screw guard should move towards the operator approximately 1/4 inch/7 mm and lock into place. If it does not, manually turn the feed screw and re-engage the feed screw guard.
3. Loosen the 1/4-inch x 3/4-inch/6 mm capscrews securing the lower half shell weldment.
4. Loosen the 5/16-inch jam nut. Tighten the 5/16-inch set screw to bring zero clearance between the feed screw and the feed nut.
5. Tighten the 1/4-inch capscrews of the lower half shell weldment.
6. Loosen the 5/16-inch set screw to allow approximately 0.010-inch clearance between set screw and the lower half shell weldment.
7. Remove the 5/16-inch capscrews securing the nut support weldment to the rear bridge. Remove the shims beneath the nut support weldment.

8. Replace front capscrews allowing a 0.010-inch clearance between the nut support weldment and the head of the capscrew.
9. Measure the maximum and minimum clearance between the nut support weldment and the rear bridge, while moving the feed screw up and down.
10. Loosen the 1/4-inch capscrews securing the lower half weldment. Remove front capscrews of the nut support weldment.
11. Insert shims between the nut support weldment and the rear bridge equal to the average maximum and minimum clearance measured.
12. Replace and tighten the front capscrews of the nut support weldment. Replace and tighten the rear capscrews of the nut support weldment.
13. Tighten the 5/16-inch set screw to allow a 0.004-0.008 inch maximum clearance between the feed screw and the lower half shell weldment.
14. Tighten the 5/16-inch jam nut.
15. Tighten the 1/4-inch capscrews of the lower half shell weldment.

# TROUBLESHOOTING

If symptoms of poor performance develop, the following chart can be used as a guide to correct the problem.

When diagnosing faults in operation of the rail drill, always check that the hydraulic power

source is supplying the correct hydraulic flow and pressure to the rail drill as listed in the table. Use a flow meter known to be accurate. Check the flow with the hydraulic fluid at a temperature of 80° F/27° C.

PROBLEM	CAUSE	REMEDY
Rail drill will not operate.	No hydraulic fluid flow or pressure.	Turn on power unit and check that 5-10 gpm/20-38 lpm at 2000 psi/140 bar is available at the rail drill.
	Defective hydraulic motor.	Repair or replace the hydraulic motor.
Spindle rotates, but drill does not advance.	Clutch slips. Feed screw not engaged.	Adjust the feed screw slip clutch and feed screw auto advance as described in the RAIL DRILL ADJUSTMENTS section of this manual.
Drilled holes not straight or aligned.	Split chuck incorrectly installed in the spindle.	Correctly install the split chuck. Refer to the OPERATION section of this manual.
Poor rail drill performance.	Hydraulic flow reversed.	Check that the hoses are correctly connected to the rail drill. The female coupler should be connected to the "IN" port. The return fluid must never flow through a reversing valve.
	Improper hydraulic fluid flow.	Check that 5-10 gpm/20-38 lpm at 2000 psi/140 bar is available at the rail drill.
Drill bit dulls quickly	Feed speed or drill rpm too fast.	Replace drill bit. Reduce feed speed.
		Replace drill bit. Reduce hydraulic flow.
	Using insufficient amount of coolant.	Replace drill bit. Increase flow of coolant.

# SPECIFICATIONS

**Bit Capacity** ..... 1-1/2-inch/38.10 mm  
**Bit Type** ..... Spade Drill bits (3/8 inch Thick, Flat Bead)  
**Output Torque @ 2000 psi/140 bar** ..... 72 ft lbs/97.6 Nm  
**Weight** ..... 100 lbs/45.3 kg  
**Height** ..... 16.44 inches/41.76 cm  
**Length** ..... 39.59 inches/100.3 cm  
**Width** ..... 13.3 inches/33.85 cm  
**Pressure, Maximum** ..... 2,000 psi/140 bar  
**Flow Range** ..... 5-10 gpm/20-38 lpm  
**Porting, Valve** ..... 1/2 SAE Female  
**Connect Size and Type** ..... 1/2 NPT Male

### NOTE

Weights, dimensions, and operating specifications listed are subject to change without notice. Where specifications are critical to your application, please consult the factory.

## ACCESSORIES

### GUIDES

Size of Rail	Hole Spacing		Part No.
90 lb & 100 lb	2 11/16 x 5 1/2 x 5 1/2	Guide Template	22631
115 lb, 132 lb, 136 lb, 140 lb	3 1/2 x 6 x 6	Guide Template	22625

### TEMPLATES

Size of Rail		Part No.
90 lb	Template	22787
115-119 lb	Template	22788
132-136 lb	Template	22789
140 lb	Template	72790

# WARRANTY

Hand held tools and their parts are warranted against defect in materials and workmanship for a period of 12 months from the date of purchase. Exceptions are cutting parts, steels, and other parts not manufactured by Stanley (such as impact mechanisms, alternators, regulators, and hoses), and parts subject to normal wear and tear (such as -o-rings, saw blades, and other parts that become worn through normal use of the tool).

The Warranty Registration Card packed with the tool must be filled out and returned to Stanley upon receipt of the tool.

Stanley reserves the right to replace or repair only those parts which under our examination prove to have been defective at the time of purchase.

Shipping charges are prepaid by the customer unless otherwise authorized by Stanley.


The warranty is void if maximum flow and pressure ratings are exceeded.

There is no other warranty expressed or implied.



Item No.	Part No.	Qty.	Description
A	08672	1	Valve Lock
B	08645	1	Valve Block/Control Valve Assy (incl items 1, B thru D)
C	01362	3	O-Ring, 2-1/16 x 2-1/4 X3/32 90D
D	08646	1	Valve Block Assy (incl item C)

**PARTS LIST**




NOTE: Use Part Number and Part Name when ordering.

**PARTS LIST**

Item No.	Part No.	Qty.	Description
1	08647	1	Manual Control Valve
2	00667	4	Capcrew, 5/16 -18 UNC x 2-1/4 LG, HSH
3	22538	1	Male Pipe Adaptor, 8 x 1/2 NPT F50X-S
4	03031	11	Lockwasher, 5/16
5	21736	1	Insulated Clamp
6	22472	1	Hydraulic Motor Tag
7	16275	1	Male Connector - 8 FTX-S
8	16275	1	Straight Thread Elbow - 8 F50X-S
9	04660	1	Tube Assy
10	22539	1	GPM Sticker 7 - 10 2000 psi
11	03787	1	Adaptor
12	22263	1	Retaining Ring
13	22467	1	Ball Bearing
14	22471	1	Set Screw, 1/4-2 UNC x 1/4 Flat Point
15	00550	4	DU Bushing
16	22539	4	1-1/4 Rod Wiper
17	22523	2	Guide Rod
18	22236	2	Bearing Retainer
19	22290	6	Lockwasher, 5/16
20	00145	6	Capcrew, 5/16 -18 UNC x 7/8 HSH
21	02685	2	Capcrew, 3/8 -16 UNC x 2 HSH
22	370156	2	Bridge Clamp Mount
23	22234	2	Postoner
24	22234	2	Capcrew, 3/8 -11 UNC x 1 HSH
25	22236	2	Capcrew, 5/16 -18 UNC x 1 HSH
26	22236	2	Capcrew, 5/16 -18 UNC x 1 HSH
27	22390	1	Ball Chuck
28	22331	1	Ball Thrust
29	00097	1	Soft Chuck - Tapped
30	22331	7	Roll Pin, 3/16 x 3/4
31	01459	6	Position Pointer
32	04273	6	Lockwasher, 3/8
33	04273	6	Capcrew, 3/8 -16 UNC x 1 HSH
34	03906	2	Nylock Nut, 5/16 -18 UNC
35	22532	1	Modular Hose
36	22532	1	Coaxial Nozzle Bracket
37	10368	1	Capcrew, 5/16 -18 UNC x 1 HSH
38	01220	2	Lube Fitting, 1/8 -27 NPT
39	19511	2	Set Screw, 3/8 -16 UNC x 1/4 Flat Point
40	22316	1	Spring
41	22316	1	Pin
42	22198	1	Pin
43	22198	1	Pin
44	22199	1	Operating Lever Weldment
45	22237	1	Retaining Ring
46	00167	1	Adjusting Ring
47	22207	1	Adjustment Screw
48	22201	1	Adjustment Knob
49	22231	1	Adjustment Nut
50	22272	1	Tightening Lever Assy
51	22272	2	Stop Washer
52	01236	12	Lockwasher, 1/4
53	01236	12	Capcrew, 1/4 -20 UNC x 1/2 Hex Head
54	22461	2	Nylock Nut, 1/2 -13 UNC
55	20228	1	Plan Washer, 1/2
56	04951	1	Print Point Warning Sticker
57	177572	2	Print Point
58	22221	1	Shoulder Bolt
59	370507	1	Capcrew, 5/16 -18 UNC x 3 Hex Head
60	22255	1	Height Adjusting Lever
61	22220	1	Knob Assy (Includes items 62 thru 64)
62	22219	1	Threaded Shaft
63	00129	1	Roll Pin, 5/32 x 1.000 LG
64	22218	1	Knob
65	22228	1	Position Washer
66	22418	1	Clamp Arm
67	22214	1	Shim .005
68	22214	1	Shim .010
69	22318	1	Shim .015
70	22318	1	Shim .020
71	02688	7	Capcrew, 5/16 -18 UNC x 3/4 HSH





**PARTS LIST**

Item No.	Part No.	Qty.	Description
72	22311	1	Shim
73	22260	1	Nut Support Weldment
74	22392	1	Feed Screw Guard
75	00757	1	Roll Pin, 1/8 x 3/4
76	22206	4	Pin
77	22268	2	Feed Nut
78	22205	1	Purging
79	22220	1	Pin
80	02445	1	Pin
81	00889	1	Capcrew, 1/4-20 UNC x 7/8 HSH
82	00719	4	Lockout, 1/4
83	22466	16	Spring Washer, 1/4
84	22224	4	Slud
85	22197	1	Plate
86	22215	1	Stop Washer
87	22233	1	Feed Screw
88	22269	1	Lower Half Shell Weldment
89	04539	2	Flatwasher, 1/4-20 UNC x 3/4 Hex Head
90	02445	2	Capcrew, 1/4-20 UNC x 7/8 HSH
91	22546	10	Speed Control Dial
92	22546	1	Stanley Slicker 1.000 x 2.000
93	06153	1	Cover
94	22492	1	Plate
95	22208	1	Flat Washer, 5/8 (Hardened)
96	371061	2	Gear Axle
97	22204	2	DU Bushing
98	06916	1	Ratchet Gear Weldment
99	22381	2	Plastic Control Ball 1.000 Dia.
100	22321	1	Fastener, 3/16 Thread
101	751059	1	Assisting Cam Weldment
102	22486	1	Slud
103	22371	1	Capcrew Modified
104	22372	1	Cone Grip
105	22372	1	Outer Collet
106	22373	1	Hub Adapter
107	22370	1	3/8 Dia. Steel Ball
108	08298	1	Support
109	22311	1	Handic Weldment
110	22472	4	Capcrew, 1/2-13 UNC x 1-1/4 Hex Head
111	04861	1	Adapter
112	22389	1	Spring
113	22317	1	Tdb
114	22328	1	Lockwasher #10
115	22328	1	Capcrew, #10-24 UNC x 1/2 Hex Head
116	04420	1	Thrust Washer
117	22460	2	Needle Thrust Bearing
118	22469	1	Retaining Ring
119	22470	1	Washer
120	22461	1	Ratchet Sector Gear
121	22465	1	Pin
122	22364	3	Spring
123	22389	3	Plate
124	22322	1	Free Wheel Body
125	22310	1	Ball Bearing
126	22465	1	Retaining Ring
127	22465	1	Spacer
128	04166	1	Brake Washer
129	22196	2	Bumper
130	22232	1	Decal "Made in USA"
131	22766	2	Nut, 5/16-18 UNC
132	14089	1	Roll Pin, 3/32 x 3/4
133	00429	1	Adjustment Nut
134	00180	1	Capcrew, 1/2-13 UNC x 1-1/2 Hex Head
135	22205	2	Pin
136	22205	2	Bridge Thrust Nut
137	02594	1	Roll Pin, 5/32 x 1
138	22256	1	Crutch Weldment
139	00114	1	Base Plate
140	22245	2	Set Screw, 5/16-18 UNC x 1 FHCS
141	22195	1	Jan Nut, 5/16
142	22769	1	Coordant Can Assy (Not Shown)
143	22767	1	Drift (Not Shown)
144	22534	1	Drift (Not Shown)
	22308	1	

NOTE: Use Part Number and Part Name when ordering.

**STANLEY**<sup>®</sup>

helps you do things right

**Stanley Hydraulic Tools**

Division of The Stanley Works

3810 S.E. Naef Road  
Milwaukie, Oregon 97267-5698

Phone: 503/659-5680

Telex: 360771

Fax: 503/652-1780