



Troubleshooting
Troubleshooting

intellifit

Intelligent Lifting Systems

OVERVIEW

 **Identifying Leakage Source (Mech/ Elec)**

 **Mechanical Air Leak- Down**


 **Mechanical Air Leak- Up**

 **Electronic Drift- Up/ Down**

 **Load Cell Operation**

 **Understanding Indicator Lights**

 **Pinout for 12 pin connector**



InteLift Display

Main Power 'On'

Power Indicator

Speed Indicator

Power Cord

InteLift Indicator

Set-up Select

Pendent Connector

2000 11 14

UNIT DRIFTS **DOWN**

Depress E-Stop on Pendant (Turn off unit)

Does the load drift down?

YES

GO TO:
MECHANICAL AIR
LEAK DOWN

NO

GO TO:
ELECTRONIC DRIFT
UP/ DOWN

UNIT DRIFTS UP

Depress E-Stop on Pendant (Turn off unit)

Does the load drift up?

YES

GO TO:
MECHANICAL AIR
LEAK UP

NO

GO TO:
ELECTRONIC DRIFT
UP/ DOWN


Mechanical Leak Down

- Pressure from the balancer is releasing to atmosphere.
- Listen for air leaks.
- If the environment is noisy, use leak detection solution.
- Apply the leak detection solution to critical areas.
- The solution will bubble if leakage is present.

•Air leaking at manifold O-ring or end cap bolt seal.

!CAUTION Relieve pressure from balancer before removing any solenoid valves!


1. Check the manifold at the end cap for leakage.



•Air leaking through one of the 3 “Down” solenoid valves

!CAUTION Relieve pressure from balancer before removing any solenoid valves!



1. Check at the base of each down solenoid for leakage.



•Air leaking through one of the 3 “Down” solenoid valves

!CAUTION Relieve pressure from balancer before removing any solenoid valves!

2. Check O-rings for cuts, nicks or tears.




Solenoid Removed

•Air leaking through one of the 3 “Down” solenoid valves (Cont.)

!Use care not to lose any of the parts!

3. Disassemble solenoid, check for foreign particles in the valve.

Step 1. Remove nut.




•Air leaking through one of the 3 “Down” solenoid valves (Cont.)

Use care not to lose any of the parts!

3. Disassemble solenoid (Cont.)

Step 2. Remove body from stem.




•Air leaking through one of the 3 “Down” solenoid valves (Cont.)

Use care not to lose any of the parts!

3. Disassemble solenoid (Cont.)

Step 3. Check O-rings and seals for cuts, nicks or tears.




•Air leaking through one of the 3 “Down” solenoid valves (Cont.)

Use care not to lose any of the parts!

3. Disassemble solenoid (Cont.)

Step 4. Check for broken or damaged parts and debris.



•**Air leaking at end cap**

1. Pressurize InteLift. Apply solution at black end cap & yellow housing.



Check entire end cap

•Leaking fitting or airline

1. Apply leak detection solution at fittings, pressure transducer, Z-stop and Interlock.



Pressure Transducer




Z-Stop



On end effector

•**Air leaking from inside unit.**

1. Remove the cable guide, raise the load to the full up position and listen for air leaking from inside the balancer housing.
2. If blowing air can be felt or heard this indicates that the piston is leaking. Inspect and clean piston chamber, lubricate or replace piston. Refer to the Balancer Service Manual for maintenance instructions.





•Listen for air leakage.

Mechanical Leak Up

- Air leaking through one of the 3 “Up” solenoid valves

!CAUTION Relieve pressure from balancer before removing any solenoid valves!

2. Check O-rings for cuts, nicks or tears.




Solenoid Removed

- **Use same process as for Down leak disassembly**

!Use care not to lose any of the parts!


Disassemble solenoid, check for foreign particles in the valve.



Electronic Drift Up or Down


1. Tare control handle. Refer to InteLift Maintenance Manual.

☹ **No external forces should be applied to the load cell or rocker switches during the “Tare” function.**





1. Tare control handle (Cont.)

☹️ **If the pre-coil cable is not properly secured it will exert force on the load cell. Secure the cable so that it does not pull or push the load cell when the load is moved.**



1. Tare control handle (Cont.)

☹️ **The load cell should not rotate more than 10 degrees from vertical when loading and unloading parts.**



2. Determine if one of the rocker switches is sticking by:


- Press the rocker switch lightly in the opposite direction of the drift. If the drifting stops, replace the control handle and repeat “Tare” function.



Float Mode Troubleshooting


1. 2.5 seconds is required the dwell time between last operator input (Up/DN switch) and changing back to Float mode.

☹ **No external forces should be applied to the load cell or end effector during the “dwell” function.**



2. The Intelift indicator will not be illuminated or flashing during the dwell time.

☹ **Wait until the Intelift indicator begins to flash before moving the end effector.**




Top Wires Contract

Fixed End
(Mount to
Device)


Bottom wires stretch

Dynamic End
(Mount to handle)

Force in Upward
Direction Sends "Up"
Signal to Controller




Understanding Intelift Indicators and Lights




Power Indicator

One steady green light indicates normal operation



Understanding Intelift Indicators and Lights



One steady green light indicates normal operation

&

One flashing red light indicates Intelift mode is active

Understanding Intelift Indicators and Lights



Steady red and green lights indicate an error condition

Restart the unit- "Tare" the pendent- ensure no controls are activated

Understanding Intelift Indicators and Lights



No lights illuminated indicates the unit is in “SET-UP” mode or the power is off

Press the “Set up” button

Understanding Intelift Indicators and Lights



No lights illuminated indicates the unit is in "SET-UP" mode or the power is off (Cont.)

Ensure Main Power is "On"- Press pendent "Power On" button

Understanding Intelift Indicators and Lights



Steady red and no green lights indicate an error condition

Contact the factory

InteLift Control Panel

Keypad Buttons

“Shift” - Initiates “QA” Testing

“Setup” - Enters and exits you out of the Setup menu

“Next” - Steps through each of four InteLift functions
which may be changed

- Control Mode
- InteLift Mode
- Control Handle Tare
- End Effector Tare


“Up/Down” - Selects value or entry for function

Intelift Set up Procedure

3. Initial Set up (cont.)

3. Select Operational Modes

4. Tare End Effector/ Pendent



Intelift Set up Procedure

Press Set up- Computer will beep/ Power LED will extinguish (Green light)

Depending on software version- Software version will be displayed at start up of Intelift

Version 2.12 or lower- The first screen will show Intelift options-

FLOAT DUMP NONE

Press and release the up/ down key to select an option

The selected option will appear on the bottom of line of the screen

Press next to go to the next screen

If none is currently selected use that setting

InteLift Set up Procedure

Version 2.12 or lower- The third screen will show Tare procedure-

PRESS UP/ DN TO TARE END EFFECTOR

Press and release the up/ down key for the computer to calculate the weight of the load

The screen will flash momentarily while the unit calculates the weight of the load

Press next to go to the next screen

Intelift Set up Procedure

Version 2.12 or lower- The fourth screen will show Tare procedure-

PRESS UP/ DN TO TARE PENDENT

Press and release the up/ down key for the computer to calculate the null (zero) setting for the pendent

The screen will flash momentarily while the unit calculates the weight of the load

Press next to go to the next screen

Intelift Set up Procedure

Version 2.12 or lower- The second screen will show
Interlock options-

SMART DROP INTERLOCK NONE

Press and release the up/ down key to select an option

The selected option will appear on the bottom of line of the
screen

Press next to go to the next screen

If none is currently selected use that setting

Intelift Set up Procedure

Version 2.12 or lower- The fifth screen will show-

PRESS SET UP TO START MACHINE

Press and release the SET UP button

The screen will flash momentarily while the unit writes the parameters you have just input to the EPROM

The power LED should illuminate (Green light)

The unit should be ready for operation

Intelift Set up Procedure

Press Set up- Computer will beep/ Power LED will extinguish
(Green light)

Depending on software version- Software version will be displayed
at start up of Intelift

Version 2.15 - The first two screens will show Intelift instructions-

Screen 1- PRESS NEXT TO CHANGE TO NEXT SCREEN

Press next to go to the next screen

Screen 2- PRESS UP/ DN TO CHANGE MENU SELECTION

Press next to go to the next screen

InteLift Set up Procedure

Version 2.15 - The third screen will show InteLift pendent options-

IAW- Rocker switch pendent with coiled cable to pendent

ISW- Rocker switch pendent with straight cable to pendent

ICW- Load cell pendent (no rocker switches) with coiled cable to pendent

Press and release the up/ down key to select pendent type

The selected pendent will appear on the bottom of line of the screen

Press next to go to the next screen

Intelift Set up Procedure

Version 2.15- The fourth screen will show Intelift options-

FLOAT

DUMP

NONE

Press and release the up/ down key to select an option

The selected option will appear on the bottom of line of the screen

Press next to go to the next screen

If none is currently selected use that setting

Intelift Set up Procedure

Version 2.15- The fifth screen will show Interlock options-

SMART DROP INTERLOCK NONE

Press and release the up/ down key to select an option

The selected option will appear on the bottom of line of the
screen

Press next to go to the next screen

If none is currently selected use that setting

InteLift Set up Procedure

Version 2.15- The sixth screen will show Tare procedure-

PRESS UP/ DN TO TARE END EFFECTOR

Press and release the up/ down key for the computer to
calculate the weight of the load

The screen will flash momentarily while the unit calculates
the weight of the load

Press next to go to the next screen

Intelift Set up Procedure

Version 2.15- The seventh screen will show Tare procedure-

PRESS UP/ DN TO TARE PENDENT

Press and release the up/ down key for the computer to calculate the null (zero) setting for the pendent

The screen will flash momentarily while the unit calculates the weight of the load

Press next to go to the next screen

Intelift Set up Procedure

Version 2.15- The eighth screen will show-

PRESS SET UP TO START MACHINE

Press and release the SET UP button

The screen will flash momentarily while the unit writes the parameters you have just input to the EPROM

The power LED should illuminate (Green light)

The unit should be ready for operation

Pendent Auxiliary Receptacle

Pin "B" 24VAC (low)
to clamp solenoid


Pin "A" 24 VAC Auxiliary
supply

Pin "C" 24VAC (coil)
to clamp solenoid

Pin "D" Not Used

Pin "E" Not Used

Pin "F" Not Used



Pendent Auxiliary Receptacle

